

WTI Part No. 14184  
Rev. C

# CCM Series

Contact Manager

## User's Guide





## Warnings and Cautions: Installation Instructions



### Secure Racking

If Secure Racked units are installed in a closed or multi-unit rack assembly, they may require further evaluation by Certification Agencies. The following items must be considered.

1. The ambient within the rack may be greater than room ambient. Installation should be such that the amount of air flow required for safe operation is not compromised. The maximum temperature for the equipment in this environment is 55°C. Consideration should be given to the maximum rated ambient.
2. Installation should be such that a hazardous stability condition is not achieved due to uneven loading.
3. Side vents are used to dissipate heat generated within the unit. When mounting the unit in an equipment rack, make certain to allow adequate clearance for venting.

### Input Supply

Check nameplate ratings to assure there is no overloading of supply circuits that could have an effect on overcurrent protection and supply wiring.

### Grounding

Reliable earthing of this equipment must be maintained. Particular attention should be given to supply connections when connecting to power strips, rather than direct connections to the branch circuit.

### No Serviceable Parts Inside; Authorized Service Personnel Only

Do not attempt to repair or service this device yourself. Internal components must be serviced by authorized personnel only.

- **Shock Hazard - Do Not Enter**
- **Lithium Battery**  
**CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.**

### Disconnect Power

If any of the following events are noted, immediately disconnect the unit from the outlet and contact qualified service personnel:

1. If the power cord becomes frayed or damaged.
2. If liquid has been spilled into the device or if the device has been exposed to rain or water.

# Agency Approvals

## FCC Part 15 Regulation

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

**WARNING:** *Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment*

## EMC, Safety, and R&TTE Directive Compliance

The CE mark is affixed to this product to confirm compliance with the following European Community Directives:

- **Council Directive 89/336/EEC of 3 May 1989 on the approximation of the laws of Member States relating to electromagnetic compatibility;**  
and
- **Council Directive 73/23/EEC of 19 February 1973 on the harmonization of the laws of Member States relating to electrical equipment designed for use within certain voltage limits;**  
and
- **Council Directive 1999/5/EC of 9 March on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.**

## Industry Canada - EMI Information

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

# Table of Contents

<b>1. Introduction</b> .....	<b>1-1</b>
<b>2. Unit Description</b> .....	<b>2-1</b>
2.1. Front Panel .....	2-1
2.2. Back Panel .....	2-2
2.3. Additional Button Functions .....	2-3
<b>3. Getting Started</b> .....	<b>3-1</b>
3.1. Installing the CCM Hardware .....	3-1
3.1.1. Apply Power to the CCM .....	3-1
3.1.2. Connecting to the Switched Contacts .....	3-1
3.1.3. Wall Mount Brackets .....	3-2
3.1.4. Connect your PC to the CCM .....	3-2
3.2. Communicating with the CCM .....	3-3
<b>4. Hardware Installation</b> .....	<b>4-1</b>
4.1. Connecting the Power Supply Cable .....	4-1
4.1.1. Installing the Power Supply Cable Keepers .....	4-1
4.1.2. Connect the CCM to Your Power Supply .....	4-1
4.2. Connecting to the Switched Contacts .....	4-1
4.3. Connecting to the Switched Plug .....	4-2
4.4. Serial SetUp Port Connection .....	4-2
4.4.1. Connecting a Local PC .....	4-2
4.4.2. Connecting an External Modem .....	4-2
4.5. Connecting the Network Cable .....	4-2
4.6. Wall Mounting .....	4-2
4.7. Emergency Shut Off Function .....	4-3
<b>5. Basic Configuration</b> .....	<b>5-1</b>
5.1. Communicating with the CCM Unit .....	5-1
5.1.1. The Text Interface .....	5-1
5.1.2. The Web Browser Interface .....	5-3
5.1.3. Access Via PDA .....	5-4
5.2. Configuration Menus .....	5-5
5.3. Defining System Parameters .....	5-6
5.3.1. The Real Time Clock and Calendar .....	5-10
5.3.2. The Invalid Access Lockout Feature .....	5-12
5.3.3. Log Configuration .....	5-15
5.3.3.1. Audit Log and Alarm Log Configuration Options .....	5-15
5.3.3.2. Reading, Downloading and Erasing Logs .....	5-16
5.3.4. Callback Security .....	5-17
5.3.5. Power Source Configuration (For Switched AC Plug Only) .....	5-18
5.3.6. Scripting Options .....	5-19
5.3.6.1. Automated Mode .....	5-20
5.4. User Accounts .....	5-21
5.4.1. Command Access Levels .....	5-21
5.4.2. Switched Plug and Switched Contact Access .....	5-22
5.4.3. Port Access .....	5-22
5.5. Managing User Accounts .....	5-23
5.5.1. Viewing User Accounts .....	5-23
5.5.2. Adding User Accounts .....	5-23
5.5.3. Modifying User Accounts .....	5-26
5.5.4. Deleting User Accounts .....	5-26

---

<b>5. Basic Configuration (continued)</b>	
5.6. The Plug Group Directory	5-27
5.6.1. Viewing Plug Groups	5-27
5.6.2. Adding Plug Groups	5-28
5.6.3. Modifying Plug Groups	5-28
5.6.4. Deleting Plug Groups	5-28
5.7. Defining Contact and Plug Parameters	5-29
5.7.1. The Boot Priority Parameter	5-30
5.7.1.1. Example 1: Change Contact C2 to Priority 1	5-30
5.7.1.2. Example 2: Change Contact C4 to Priority 2	5-31
5.8. Serial Port Configuration	5-32
5.9. Network Configuration	5-35
5.9.1. Network Port Parameters	5-36
5.9.2. Network Parameters	5-37
5.9.3. IP Security	5-41
5.9.3.1. Adding IP Addresses to the Allow and Deny Lists	5-42
5.9.3.2. Linux Operators and Wild Cards	5-43
5.9.3.3. IP Security Examples	5-43
5.9.4. Static Route	5-44
5.9.5. Domain Name Server	5-44
5.9.6. SNMP Access Parameters	5-45
5.9.7. SNMP Trap Parameters	5-47
5.9.8. LDAP Parameters	5-48
5.9.8.1. Adding LDAP Groups	5-50
5.9.8.2. Viewing LDAP Groups	5-51
5.9.8.3. Modifying LDAP Groups	5-51
5.9.8.4. Deleting LDAP Groups	5-51
5.9.9. TACACS Parameters	5-52
5.9.10. RADIUS Parameters	5-54
5.9.10.1. Dictionary Support for RADIUS	5-55
5.9.11. Email Messaging Parameters	5-57
5.10. Save User Selected Parameters	5-58
5.10.1. Restore Configuration	5-58
<b>6. Reboot Options</b>	<b>6-1</b>
6.1. Ping-No-Answer Reboot	6-2
6.1.1. Adding Ping-No-Answer Reboots	6-2
6.1.2. Viewing Ping-No-Answer Reboot Profiles	6-4
6.1.3. Modifying Ping-No-Answer Reboot Profiles	6-4
6.1.4. Deleting Ping-No-Answer Reboot Profiles	6-4
6.2. Scheduled Reboot	6-5
6.2.1. Adding Scheduled Reboots	6-5
6.2.2. Viewing Scheduled Reboot Actions	6-6
6.2.3. Modifying Scheduled Reboots	6-6
6.2.4. Deleting Scheduled Reboots	6-6
<b>7. Alarm Configuration</b>	<b>7-1</b>
7.1. The Over Current Alarms (Switched Plug Only)	7-2
7.1.1. Over Current Alarms - Load Shedding and Auto Recovery	7-4
7.2. The Over Temperature Alarms	7-6
7.2.1. Over Temperature Alarms - Load Shedding and Auto Recovery	7-8
7.3. The Circuit Breaker Open Alarm	7-9
7.4. The Ping-No-Answer Alarm	7-10
7.5. The Serial Port Invalid Access Lockout Alarm	7-12
7.6. The Power Cycle Alarm	7-14
7.7. The No Dialtone Alarm	7-15

<b>8. The Status Screens</b> .....	<b>8-1</b>
8.1. Product Status .....	8-1
8.2. The Network Status Screen .....	8-1
8.3. The Plug Status Screen .....	8-2
8.4. The Plug Group Status Screen .....	8-3
8.5. The Current Metering Status Screen .....	8-4
8.6. The Current History Screen .....	8-5
8.7. The Power Range Status Screen .....	8-7
8.8. The Power History Screen .....	8-8
8.9. The Port Diagnostics Screen .....	8-9
8.10. Alias Status Screen .....	8-9
8.11. The Alarm Status Screen .....	8-9
8.12. The Serial Port Parameters Screen .....	8-9
<b>9. Operation</b> .....	<b>9-1</b>
9.1. Operation via the Web Browser Interface .....	9-1
9.1.1. The Plug Control Screen - Web Browser Interface .....	9-1
9.1.2. The Plug Group Control Screen - Web Browser Interface .....	9-2
9.2. Operation via the Text Interface .....	9-3
9.2.1. Switching and Reboot Commands - Text Interface .....	9-3
9.2.2. Applying Commands to Several Contacts/Plugs - Text Interface .....	9-5
9.3. The Automated Mode .....	9-6
9.4. The SSH/Telnet Connect Function (Web Browser Interface Only) .....	9-7
9.4.1. Initiating an SSH Shell Session via the Web Browser Interface .....	9-7
9.4.2. Initiating a Telnet Session via the Web Browser Interface .....	9-8
9.4. Manual Operation .....	9-8
9.5. Logging Out of Command Mode .....	9-8
<b>10. SSH Encryption</b> .....	<b>10-1</b>
<b>11. Syslog Messages</b> .....	<b>11-1</b>
11.1. Configuration .....	11-1
<b>12. SNMP Traps</b> .....	<b>12-1</b>
12.1. Configuration: .....	12-1
<b>13. Operation via SNMP</b> .....	<b>13-1</b>
13.1. CCM SNMP Agent .....	13-1
13.2. SNMPv3 Authentication and Encryption .....	13-1
13.3. Configuration via SNMP .....	13-2
13.3.1. Viewing Users .....	13-3
13.3.2. Adding Users .....	13-3
13.3.3. Modifying Users .....	13-3
13.3.4. Deleting Users .....	13-3
13.4. Plug and Contact Control via SNMP .....	13-4
13.4.1. Plug and Contact Status and Control .....	13-4
13.4.2. Plug Group Status and Control .....	13-5
13.5. Viewing CCM Status via SNMP .....	13-6
13.5.1. System Status - Ethernet Port Mac Addresses .....	13-6
13.5.2. Plug and Contact Status .....	13-6
13.5.3. Unit Environment Status .....	13-6
13.5.4. Alarm Status .....	13-7
13.6. Sending Traps via SNMP .....	13-8
<b>14. Setting Up SSL Encryption</b> .....	<b>14-1</b>
14.1. Creating a Self Signed Certificate .....	14-2
14.2. Creating a Signed Certificate .....	14-3
14.3. Downloading the Server Private Key .....	14-4
14.4. TLS Mode .....	14-5

<b>15. Saving and Restoring Configuration Parameters</b> .....	<b>15-1</b>
15.1. Sending Parameters to a File .....	15-1
15.1.1. Downloading & Saving Parameters via Text Interface .....	15-1
15.1.2. Downloading & Saving Parameters via Web Browser Interface .....	15-2
15.2. Restoring Saved Parameters .....	15-2
15.3. Restoring Previously Saved Parameters .....	15-3
<b>16. Upgrading CCM Firmware</b> .....	<b>16-1</b>
16.1. WMU Enterprise Management Software (Recommended) .....	16-1
16.2. The Upgrade Firmware Function (Alternate Method) .....	16-1
<b>17. Command Reference Guide</b> .....	<b>17-1</b>
17.1. Command Conventions .....	17-1
17.2. Command Summary .....	17-2
17.3. Command Set .....	17-3
17.3.1. Display Commands .....	17-3
17.3.2. Control Commands .....	17-6
17.3.3. Configuration Commands .....	17-12
 <b>Appendices:</b>	
<b>A. Specifications</b> .....	<b>Apx-1</b>
<b>B. Interface Descriptions</b> .....	<b>Apx-2</b>
B.1. SetUp Port (RS232) .....	Apx-2
<b>C. Customer Service</b> .....	<b>Apx-3</b>

---

## List of Figures

2.1.	Front Panel .....	2-1
2.2.	Back Panel.....	2-2
5.1.	Boot Priority Example 1.....	5-30
5.2.	Boot Priority Example 2.....	5-31
14.1.	Web Access Parameters (Text Interface Only) .....	14-1
B.1.	RS232 SetUp Port Interface .....	Apx-2



# 1. Introduction

WTI's CCM Series Contact Managers allow secure, remote management of AC and DC powered equipment via SSL, SSH, SNMP, web browser, telnet, external modem or local terminal. CCM units include both a switched AC outlet, plus switched dry contacts that can be opened, closed or rebooted in response to user commands. CCM units provide the ability to perform power reboot and power switching functions and can also automatically notify you when changes in rack temperature, ping command response and other factors are detected.

In addition to these power management and alarm functions, the CCM Switched AC Outlet also includes the ability to monitor power to your equipment, and automatically notify you when changes in current consumption exceed user-defined threshold values.

## **Security and Co-Location Features:**

Secure Shell (SSHv2) encryption and address-specific IP security masks help to prevent unauthorized access to command and configuration functions.

The CCM provides four different levels of security for user accounts: Administrator, SuperUser, User and ViewOnly. The Administrator level provides complete access to all plug and contact functions, operating features and configuration menus. The SuperUser level allows switching and rebooting of all plugs and contacts but does not allow access to configuration functions. The User level allows access to only a select group of Administrator-defined plugs and contacts. The ViewOnly level allows you to check plug and contact status and unit status, but does not allow switching or rebooting of plugs or contacts or access to configuration menus.

The CCM also includes full Radius support, LDAP capability, TACACS capability, MIB capability, DHCP and an invalid access lockout feature. An Audit Log records all user access, login and logout times and command actions.

## **Current and Power Metering (Switched AC Plug Only):**

CCM series units can measure and report current and power consumption trends. If the CCM detects that user defined thresholds for current consumption have been exceeded the unit can provide prompt notification to network administrators and IT personnel. The CCM also records current consumption data to a convenient log file, which can be retrieved in ASCII, XML, or CSV format or displayed in graph format.

## WTI Management Utility

CCM units include the WTI Enterprise Management Utility (WMU,) which allows you to manage multiple WTI units via a single menu. For more information on the Enterprise Management Utility, please refer to the WMU User's Guide, which can be downloaded from the WTI web site at: <http://www.wti.com/t-product-manuals.aspx>.

## Typographic Conventions

^ (e.g. ^x)	Indicates a control character. For example, the text " <b>^x</b> " (Control X) indicates the <b>[Ctrl]</b> key and the <b>[X]</b> key must be pressed simultaneously.
<b>COURIER FONT</b>	Indicates characters typed on the keyboard. For example, / <b>AC</b> or / <b>ON A2</b> .
<b>[Bold Font]</b>	Text set in bold face and enclosed in square brackets indicates a specific key. For example, <b>[Enter]</b> or <b>[Esc]</b> .
< >	Indicates required keyboard entries. For Example: / <b>P</b> < <b>n</b> >.
[ ]	Indicates optional keyboard entries. For Example: / <b>P</b> [ <b>n</b> ].

## 2. Unit Description

### 2.1. Front Panel




Figure 2.1: Front Panel

As shown in Figure 2.1, the CCM Front Panel includes the following components:

1. **Output Status Indicators:** LEDs light when corresponding contact or plug is switched On.

#### Notes:

- **LED On:** The Status LEDs will light when the corresponding contact is in the "Normal" Position (for example, the Normal position for an NC contact is Closed.)
  - **LED Off:** The Status LEDs will be off when the corresponding contact is in the "Non-Normal" Position (for example, the Non-Normal position for an NC contact is Open.)
  - **Switched Plug:** The Status LED for the Switched Plug will light when power is applied to the plug, and will be switched off when power to the plug is Off.
  - **Power Supply Interruptions:** If AC power to the CCM Power Inlet is interrupted, all Switched Contacts will be automatically switched to the "Normal" position. For example, if AC power is lost, Normally Closed contacts will be switched to the "Closed" position.
2. **"RDY" Indicator:** (Ready) Flashes if unit is ready to receive commands.
  3. **Default Button:** Toggles Switched Contacts Open/Closed and/or the Switched Plug On/Off or resets unit to factory default parameters as described in Section 2.3.
  4. **Reset Button:** Reboots and/or resets the CCM to factory defaults as described in Section 2.3.

**Note:** All Front Panel Button functions can also be disabled via the System Parameters menu, as described in Section 5.3.

5. **Network Port:** An RJ45 Ethernet port for connection to your 10/100Base-T, TCP/IP network. Note that the CCM features a default IP address (192.168.168.168). This allows you to connect to the unit without first assigning an IP address. Note that the Network Port also includes two, small LED indicators for Link and Data Activity. For more information on Network Port configuration, please refer to Section 5.9.
6. **Setup Port:** An RJ45 RS232 serial port (DCE configuration) used for connection to a local terminal or external modem, as described in Section 4.4. For a description of the Setup Port interface, please refer to Appendix B.1.

## 2.2. Back Panel

As shown in Figure 2.2, the CCM Back Panel includes the following components:

1. **Power Inlet:** An IEC320-C20 AC inlet which supplies power to CCM control functions and the Switched Plug. Also includes cable keeper (not shown.)
2. **Switched Plug:** An AC Outlet that can be switched On, Off, rebooted or set to default state in response to user commands.
3. **Switched Contacts:** Four dry contacts that can be Opened, Closed, Rebooted or set to default state in response to user commands. Each contact includes three pins: A Normally Closed (NC) pin, a Common (COM) pin and a Normally Open (NO) pin. The switched contacts are rated for 100 to 240 Volts at 15 Amps AC; 0 to 48 volts at 10 Amps DC.

**Note:** If AC power to the CCM unit is lost, all contacts will be automatically set to their "Normal" positions. For example, all "NC" contacts will be set to the Closed Position.




Figure 2.2: Back Panel

---

## 2.3. Additional Button Functions

The Default and Reset buttons on the CCM front panel can be used to perform the functions described below:

**Notes:**

- *All Front Panel Button functions can also be disabled via the System Parameters menu, as described in Section 5.3.*
- *When the CCM is reset to factory defaults, all user-defined configuration parameters will be cleared, and the default "super" user account will also be restored.*

**1. Reboot Operating System:**

- a) Press and hold the Reset button for five seconds, and then release it.
- b) The CCM will reboot its operating system; all the switched contacts and switched plug will be left in their current state.

**2. Set Parameters to Factory Defaults:**

- a) Simultaneously press both the Default button and the Reset button, hold them for five seconds, and then release them.
- b) All CCM parameters will be reset to their original factory default settings, and the unit will then reboot. All switched contacts and the switched plug will be left in their current state.

**3. Toggle/Default All Switched Contacts and Switched Plug:**

- a) Press the Default button, hold it for five seconds, and then release the Default Button.
- b) The CCM will switch all contacts and the switched plug to the Off state. If all switched contacts and the switched plug are already in the Off state, then the unit will reset all switched contacts and the switched plug to their user defined default states.

## 3. Getting Started

This section describes a simplified installation procedure for the CCM series hardware, which will allow you to communicate with the unit in order to demonstrate basic features and check for proper operation. In order to take full advantage of the features provided by this unit, it is recommended that you should also refer to the remainder of this User's Guide.

### 3.1. Installing the CCM Hardware

#### 3.1.1. Apply Power to the CCM

Refer to the warnings and cautions at the beginning of this guide and the power rating nameplate on the CCM back panel, and then connect the unit to an appropriate power source. Connect the AC power cable to the AC power inlet, install the cable keeper (as described in Section 4.1.1,) then connect the cable to an appropriate AC power supply.

**Note:** *If you need to determine the exact model number for your CCM unit, either refer to the nameplate on the back of the unit, or access command mode as described in Section 5.1 and then type /J \* and press [Enter].*

#### 3.1.2. Connecting to the Switched Contacts

The switched contacts are rated for 100 to 240 Volts at 15 Amps AC; 0 to 48 volts at 10 Amps DC. When connecting to the dry contacts, note that the screw terminals are removable for easier access during installation, and that polarity is not significant. Connect to the Common (COM) pin as well as the Normally Closed (NC) pin and/or Normally Open (NO) pin. To ensure that wires are securely connected, insert the wire into the screw terminal and then tighten the corresponding retaining screw on top of the connector.

### **3.1.3. Wall Mount Brackets**

The CCM includes wall mount brackets that allow the unit to be mounted to a vertical or horizontal surface. Note that optional rack mount brackets are also available.

### **3.1.4. Connect your PC to the CCM**

The CCM unit can either be controlled by a local PC, that communicates with the unit via the SetUp port, controlled via external modem, or controlled via TCP/IP network. In order to switch plugs or select parameters, commands are issued to the CCM via either the Network Port or SetUp Port. Note that it is not necessary to connect to both the Network and SetUp Ports, and that the SetUp Port can be connected to either a local PC or External Modem.

- **Network Port:** Connect your 10Base-T or 100Base-T network interface to the CCM Network port.
- **Setup Port:** Use the DX9F-DTE-RJ Adapter supplied with the unit to connect your PC COM port to the CCM SetUp Port.
- **External Modem:** Use the optional DX9M-RJ-KIT (not included) to connect your external modem to the CCM Setup (RS232) Port.

## 3.2. Communicating with the CCM

In order to ensure security, both Telnet and Web Browser Access are disabled when the CCM is shipped from the factory. To enable Telnet and/or Web Browser access, please refer to Section 5.9. When properly installed and configured, the CCM will allow command mode access via Telnet, Web Browser, SSH client, modem, or local PC.

### Notes:

- *Default CCM serial port parameters are set as follows: 9600 bps, RTS/CTS Handshaking, 8 Data Bits, One Stop Bit, No Parity. Although these parameters can be easily redefined, for this Quick Start procedure, it is recommended to configure your communications program to accept the default parameters.*
  - *The CCM feature a default IPv4 format IP Address (192.168.168.168) and a default Subnet Mask (255.255.255.0.) This allows network access to command mode, providing that you are contacting the CCM from a node on the same subnet. When attempting to access the CCM from a node that is not on the same subnet, please refer to the Section 5.1 for further configuration instructions.*
  - *When connecting a PC or Laptop directly to the CCM SetUp Port via crossover cable, make certain that the subnet IP for your PC or Laptop matches the subnet IP range for the CCM.*
1. **Access Command Mode:** The CCM includes two user interfaces; the Text Interface and the Web Browser Interface. The Text Interface is available via Local PC, SNMP, SSH Client, Telnet, or Modem, and the Web Browser interface is only available via TCP/IP network. In addition, when contacted via PDA, the CCM will also present a third interface, which is similar to the Web Browser Interface, but offers limited command functions.
    - a) **Via SetUp Port:** Start your communications program and then press **[Enter]**.
    - b) **Via SSH Client:** Start your SSH client, enter the default IPv4 format IP address (192.168.168.168) for the CCM and invoke the connect command.
    - c) **Via Web Browser:** Make certain that Web Browser access is enabled as described in the Section 5.9 in this User's Guide. Start your JavaScript enabled Web Browser, enter the CCM's default IPv4 format IP address (192.168.168.168) in the Web Browser address bar, and then press **[Enter]**.
    - d) **Via Telnet:** Make certain that Telnet access is enabled as described in Section 5.9. Start your Telnet client, and enter the CCM's default IPv4 format IP address (192.168.168.168).
    - e) **Via Modem:** Make certain the CCM SetUp Port is configured for Modem Mode as described in Section 5.8, then use your communications program to dial the number for the external Modem connected to the SetUp Port.
  2. **Username / Password Prompt:** A message will be displayed, which prompts you to enter your username and password. The default username is “**super**” (all lower case, no quotes), and the default password is also “**super**”. If a valid username and password are entered, the CCM will display either the Main Menu (Web Browser Interface) or the Port Status Screen (SSH, Telnet, or Modem.)



3. **Test Switching Functions:** You may wish to perform the following tests in order to make certain that the CCM is responding to commands. When switching and reboot commands are executed, the Status LED(s) will also turn On or Off to indicate the current status of the switched contacts and switched plug.

**Notes:**

- **LED On:** *The Status LEDs will light when the corresponding contact is in the "Normal" Position (for example, the Normal position for an NC contact is Closed.)*
  - **LED Off:** *The Status LEDs will be off when the corresponding contact is in the "Non-Normal" Position (for example, the Non-Normal position for an NC contact is Open.)*
  - **Switched Plug:** *The Status LED for the Switched Plug will light when power is applied to the plug, and will be switched off when power to the plug is Off.*
  - **Power Supply Interruptions:** *If AC power to the CCM Power Inlet is interrupted, all Switched Contacts will be automatically switched to the "Normal" position. For example, if AC power is lost, Normally Closed contacts will be switched to the "Closed" position.*
- a) **Reboot Contact or Plug:** When a Contact or Plug is rebooted, the attached device will be cycled Off and then Back On again:
- i. **Web Browser Interface:** Click on the "Plug Control" link on the left hand side of the screen to display the Plug Control Menu. From the Plug Control Menu, click the down arrow in the row for Contact C1 or Plug A1 to display the dropdown menu, then select "Reboot" from the drop down menu and click on the "Confirm Actions" button.
  - ii. **Text Interface:** To reboot the switched plug, type `/BOOT A1` and press **[Enter]**. To reboot Contact C1, type `/BOOT C1` and press **[Enter]**.
- b) **Switch Contact to Normal Position (On):** When a Contact is switched to the Normal position, the corresponding LED will switch On:
- i. **Web Browser Interface:** From the Plug Control Menu, click the down arrow in the "Action" column for Contact C1 to display the drop down menu, then select "On" from the drop down menu and click on the "Confirm Actions" button.
  - ii. **Text Interface:** To switch Contact C1 to the Normal position, type `/ON C1` and press **[Enter]**.
- c) **Switch Contact to Non-Normal Position (Off):** When a Contact is switched to the Non-Normal position, the corresponding LED will switch Off:
- i. **Web Browser Interface:** From the Plug Control Menu, click the down arrow in the "Action" column for Contact C1 to display the drop down menu, then select "Off" from the drop down menu and click on the "Confirm Actions" button.
  - ii. **Text Interface:** To switch Contact C1 to the Non-Normal position, type `/OFF C1` and press **[Enter]**.

- d) **Switch Plug On:**
    - i. **Web Browser Interface:** From the Plug Control Menu, click the down arrow in the "Action" column for Plug A1 to display the drop down menu, then select "On" from the drop down menu and click on the "Execute Plug Actions" button.
    - ii. **Text Interface:** To switch On the switched plug, type `/ON A1` and press **[Enter]**.
  - e) **Switch Plug Off:**
    - i. **Web Browser Interface:** From the Plug Control Menu, click the down arrow in the "Action" column for Plug A1 to display the drop down menu, then select "Off" from the drop down menu and click on the "Confirm Actions" button.
    - ii. **Text Interface:** To switch Off the switched plug, type `/OFF A1` and press **[Enter]**.
4. **Logging Out:** When you log off using the proper CCM command, this ensures that the unit has completely exited from command mode, and is not waiting for the inactivity timeout to elapse before allowing additional connections.
- a) **Web Browser Interface:** Click on the "LOGOUT" link on the left hand side of the screen.
  - b) **Text Interface:** Type `/x` and press **[Enter]**.

This completes the Quick Start Guide for the CCM. Prior to placing the unit into operation, it is recommended to refer to the remainder of this User's Guide for important information regarding advanced configuration capabilities and more detailed operation instructions. If you have further questions regarding the CCM unit, please contact WTI Customer Support as described in Appendix C.

## 4. Hardware Installation

### 4.1. Connecting the Power Supply Cable

#### 4.1.1. Installing the Power Supply Cable Keepers

The CCM includes a cable keeper, which is intended to prevent the AC power supply cable from being accidentally disconnected from the unit. When attaching the AC power supply cable to the unit, first swing the cable keeper out of the way, then plug the power cable securely into the AC power input. When the cable is in place, snap the cable keeper over the plug to secure the cable to the unit.

#### 4.1.2. Connect the CCM to Your Power Supply

Refer to the cautions listed below and at the beginning of this User's Guide, and then connect the CCM unit to an appropriate power supply.



#### CAUTIONS:



- *Before attempting to install this unit, please review the warnings and cautions listed at the front of the user's guide.*
- *This device should only be operated with the type of power source indicated on the instrument nameplate. If you are not sure of the type of power service available, please contact your local power company.*
- *Reliable earthing (grounding) of this unit must be maintained. Particular attention should be given to supply connections when connecting to power strips, rather than directly to the branch circuit.*

### 4.2. Connecting to the Switched Contacts

The switched contacts are rated for 100 to 240 Volts at 15 Amps AC; 0 to 48 volts at 10 Amps DC. When connecting to the dry contacts, note that the screw terminals are removable for easier access during installation, and that polarity is not significant. Connect to the Common (COM) pin as well as the Normally Closed (NC) pin and/or Normally Open (NO) pin. To ensure that wires are securely connected, insert the wire into the screw terminal and then tighten the corresponding retaining screw on top of the connector.

**Note:** *If AC power to the CCM unit is lost, all contacts will be automatically set to their "Normal" positions. For example, all "NC" contacts will be set to the Closed Position.*

### 4.3. Connecting to the Switched Plug

Connect the power cord from your switched device to the switched AC Plug on the CCM back panel. Note that when power is applied to the CCM, the AC Plug will be switched “ON” by default.

### 4.4. Serial SetUp Port Connection

The CCM SetUp Port is a female, RJ45 RS232 connector, wired in a DCE configuration. In the default state, the Setup port is configured for 9600 bps, no parity, 8 data bits, one stop bit. The Setup Port can be connected to either an external modem or a local PC, but not both items at the same time. Appendix B.1 describes the Setup Port interface.

#### 4.4.1. Connecting a Local PC

Use the DX9F-WTI Adapter supplied with the unit to connect your PC COM port to the CCM Setup Port. Make certain that the Serial Port Mode is set to “Normal” as described in Section 5.8.

#### 4.4.2. Connecting an External Modem

When connecting directly to an external modem, use the optional DX9M-RJ-KIT (not included) to connect your external modem to the CCM Setup Port. Make certain that the modem is initialized at the same default parameters as the CCM Setup Port and that the CCM Serial Port Mode is set to “Modem” as described in Section 5.8.

### 4.5. Connecting the Network Cable

The Network Port is an RJ45 Ethernet jack, for connection to a TCP/IP network. Connect your 100Base-T cable to the Network Port. Note that the CCM include a default IPv4 format IP address (192.168.168.168) and a default subnet mask (255.255.255.0.) When installing the CCM in a working network environment, it is recommended to define network parameters as described in Section 5.9.

### 4.6. Wall Mounting

The CCM includes wall mount brackets that allow the unit to be mounted to a vertical or horizontal surface. Note that optional rack mount brackets are also available.

#### **4.7. Emergency Shut Off Function**

CCM units also include an Emergency Shut Off function, that can be used to immediately shut off all CCM dry contacts and power outlets in case of emergency. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).

This completes the CCM installation instructions. Please proceed to the next Section for instructions regarding unit configuration.

## 5. Basic Configuration

This section describes the basic configuration procedure for all CCM units. For more information on Reboot Options and Alarm Configuration, please refer to Section 6 and Section 7.

### 5.1. Communicating with the CCM Unit

In order to configure the CCM, you must first connect to the unit, and access command mode. Note that, the CCM offers two separate configuration interfaces; the Web Browser Interface and the Text Interface.

In addition, the CCM also offers three different methods for accessing command mode; via network, via external modem, or via local console. The Web Browser interface is only available via network, and the Text Interface is available via network (SSH or Telnet), modem or local PC.

#### 5.1.1. The Text Interface

The Text Interface consists of a series of simple ASCII text menus, which allow you to set options and define parameters by entering the number for the desired option using your keyboard, and then typing in the value for that option.

Since the Web Browser Interface and Telnet accessibility are both disabled in the default state, you will need to use the Text Interface to contact the CCM via Local PC or SSH connection when setting up the unit for the first time. After you have accessed command mode using the Text Interface, you can then enable Web Access and Telnet Access, if desired, in order to allow future communication with the unit via Web Browser or Telnet. You will not be able to contact the unit via Web Browser or Telnet until you have enabled these options.

Once Telnet Access is enabled, you will then be able to use the Text Interface to communicate with the CCM via local PC, Telnet or SSH connection. You can also use the Text Interface to access command mode via an external modem installed at the CCM serial Setup Port.

In order to use the Text Interface, your installation must include:

- **Access via Network:** The CCM must be connected to your TCP/IP Network, and your PC must include a communications program (such as HyperTerminal.)
- **Access via Modem:** An external modem must be installed at the CCM RS232 Setup Port (see Section 4.4.2), a phone line must be connected to the external modem, and the Setup Port must be configured for Modem Mode. In addition, your PC must include a communications program.
- **Access via Local PC:** Your PC must be physically connected to the CCM RS232 Setup Port as described in Section 4.4.1, the CCM Setup Port must be configured for Normal Mode, and your PC must include a communications program.

To access command mode via the Text Interface, proceed as follows:

**Note:** *When communicating with the unit for the first time, you will not be able to contact the unit via Telnet, until you have accessed command mode, via Local PC or SSH Client, and used the Network Parameters Menu to enable Telnet as described in Section 5.9.2.*

1. Contact the CCM Unit:
  - a) **Via Local PC:** Start your communications program and press **[Enter]**. Wait for the connect message, then proceed to Step 2.
  - b) **Via Network:** The CCM includes a default IP address (192.168.168.168) and a default subnet mask (255.255.255.0.) This allows you to contact the unit from any network node on the same subnet, without first assigning an IP Address to the unit. For more information, please refer to Section 5.9.2.
    - i. **Via SSH Client:** Start your SSH client, and enter the CCM IP Address. Invoke the connect command, wait for the connect message, then proceed to Step 2.
    - ii. **Via Telnet:** Start your Telnet Client, and then Telnet to the CCM IP Address. Wait for the connect message, then proceed to Step 2.
  - c) **Via Modem:** Use your communications program to dial the number for the external modem which you have connected to the CCM Setup Port.
2. **Login / Password Prompt:** A message will be displayed, which prompts you to enter a username (login name) and password. The default username is "super" (all lower case, no quotes), and the default password is also "super".
3. If a valid username and password are entered, the CCM will display the Plug and Contact Status Screen.

**Note:** *If a Login Banner has been defined as described in Section 5.3, then a banner page will appear before the command prompt is displayed. The Login Banner can be used to display legal warnings or other information.*

### 5.1.2. The Web Browser Interface

The Web Browser Interface consists of a series of web forms, which can be used to select configuration parameters and perform reboot operations, by clicking on buttons and/or entering text into designated fields.

**Note:** *In order to use the Web Browser Interface, Web Access must first be enabled via the Text Interface Network Parameters Menu (IN), the CCM must be connected to a TCP/IP network, and your PC must be equipped with a JavaScript enabled web browser.*

1. Start your JavaScript enabled Web Browser, key the CCM IP address (default = 192.168.168.168) into the web browser's address bar, and press **[Enter]**.
2. **Username / Password Prompt:** A message box will prompt you to enter your username and password. The default username is "super" (all lower case, no quotes), and the default password is also "super".
3. If a valid username and password are entered, the Plug and Contact Control Screen will be displayed.

**Note:** *If a Login Banner has been defined as described in Section 5.3, then a banner page will appear before the command prompt is displayed. The Login Banner can be used to display legal warnings or other information.*



### 5.1.3. Access Via PDA

In addition to the Web Browser Interface and Text Interface, the CCM command mode can also be accessed by PDA devices. Note however, that due to nature of most PDAs, only a limited selection of CCM operating and status display functions are available to users who communicate with the unit via PDA.

When the CCM is operated via a PDA device, only the following functions are available:

- Product Status Screen (Section 8.1)
- Plug (and Contact) Status Screen (Section 8.3)
- Plug Group Status Screen (Section 8.4)
- Plug (and Contact) Control Screen (Section 9.1.1)
- Plug Group Control Screen (Section 9.1.2)
- Current & Power Metering (Section 8.5)
- Current History Graph (Section 8.6) (For Switched AC Plug Only)

These screens will allow PDA users to review Plug Status and Plug Group Status, invoke switching and reboot commands and display the Site I.D. and firmware version. In addition, the CCM will also display Current Metering Readings and show Current History for the Switched AC Plug. Note however, that PDA users are not allowed to change or review CCM configuration parameters.

To configure the CCM for access via PDA, first consult your IT department for appropriate settings. Access the CCM command mode via the Text Interface or Web Browser interface as described in this section, then configure the CCM Network Port accordingly, as described in Section 5.9.

In most cases, this configuration will be adequate to allow communication with most PDAs. Note however, that if you wish to use a BlackBerry® to contact the CCM, you must first make certain to configure the BlackBerry to support HTML tables, as described below:

1. Power on the BlackBerry, and then click on the BlackBerry Internet Browser Icon.
2. Press the Menu button, and then choose "Options."
3. From the Options menu, choose "Browser Configuration," then verify to make certain that "Support HTML Tables" is checked (enabled.)
4. Press the Menu button, and select "Save Options."

When you have finished communicating with the CCM via PDA, it is important to always close the session using the PDA's menu functions, rather than by simply closing the browser window, in order to ensure that the CCM has completely exited from command mode, and is not waiting for the inactivity timeout period to elapse. For example, to close a session on a BlackBerry, press the Menu button and then choose "Close."

## 5.2. Configuration Menus

Although the Web Browser Interface and Text Interface provide two separate means for selecting parameters, both interfaces allow access to the same set of basic parameters, and parameters selected via one interface will also be applied to the other. To access the configuration menus, proceed as follows:

- **Text Interface:** Refer to the Help Screen (/H) and then enter the appropriate command to access the desired menu. When the configuration menu appears, key in the number for the parameter you wish to define, and follow the instructions in the resulting submenu.
- **Web Browser Interface:** Use the links and fly-out menus on the left hand of the screen to access the desired configuration menu. To change parameters, click in the desired field and key in the new value or select a value from the pull-down menu. To apply newly selected parameters, click on the "Change Parameters" button at the bottom of the menu or the "Set" button next to the field.

The following sections describe options and parameters that can be accessed via each of the configuration menus. Please note that essentially the same set of parameters and options are available to both the Web Browser Interface and Text Interface.

### Notes:

- *Configuration menus are only available when you have logged into command mode using a password that permits Administrator Level commands. SuperUser accounts are able to view configuration menus, but are not allowed to change parameters.*
- *Configuration menus are not available when you are communicating with the CCM via PDA*
- *When defining parameters via the Text Interface, make certain to press the **[Esc]** key to completely exit from the configuration menu and save newly defined parameters. When parameters are defined via the Text Interface, newly defined parameters will not be saved until the "Saving Configuration" message has been displayed and the cursor returns to the command prompt.*

### 5.3. Defining System Parameters

The System Parameters menus are used to define the Site ID Message, set the system clock and calendar, and configure the Invalid Access Lockout feature and Callback feature. To access the System Parameters menu via the Text Interface, type `/P` and press **[Enter]**. To access the System Parameters menu via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear and then click on the "System Parameters" link. The System Parameters Menus are used to define the following:

- **User Directory:** This function is used to view, add, modify and delete user accounts and passwords. As discussed in Section 5.4 and Section 5.5, the User Directory allows you to set the security level for each account as well as determine which plugs each account will be allowed to control.

**Note:** *The "User Directory" option does not appear in the Web Browser Interface's System Parameters menu, and is instead, accessed via the "User Configuration" link on the left hand side of the menu.*

- **Site ID:** A text field, generally used to note the installation site or name for the CCM unit. (Up to 64 characters; Default = undefined)

**Notes:**

- *The Site I.D. will be cleared if the CCM is reset to default settings.*
- *When viewed via the Text Interface (CLI) Site I.D. messages that are over 30 characters long will be truncated. To display the entire Site I.D. message via the Text Interface, type `/J*` and press **[Enter]***
- **Real Time Clock:** This prompt provides access to the Real Time Clock menu, which is used to set the clock and calendar, and to enable and configure the NTP (Network Time Protocol) feature as described in Section 5.3.1.
 

**Note:** *The "Real Time Clock" option does not appear in the Web Browser Interface's System Parameters menu, and is instead, accessed via the "Real Time Clock" link in the General Parameters fly-out menu.*
- **Invalid Access Lockout:** If desired, this feature can be used to temporarily disable Console Port access, SSH access, Telnet access and/or Web access to the CCM command mode after a user specified number of unsuccessful login attempts are made. For more information, please refer to Section 5.3.2. (Default = On)
 

**Note:** *The "Invalid Access Lockout" item does not appear in the Web Browser Interface's System Parameters menu, and is instead, accessed via the link in the General Parameters fly-out menu.*
- **Temperature Format:** Determines whether the temperature is displayed as Fahrenheit or Celsius. (Default = Fahrenheit)
- **Temperature Calibration:** Used to calibrate the unit's internal temperature sensing abilities. To calibrate the temperature, place a thermometer inside your equipment rack, in a location that usually experiences the highest temperature. After a few minutes, take a reading from the thermometer, and then key the reading into the configuration menu. In the Web Browser Interface, the temperature is entered at the System Parameters menu, in the Temperature Calibration field; in the Text Interface, the temperature is entered in a submenu of the System Parameters menu, accessed via the Temperature Calibration item. (Default = undefined)

- **Log Configuration:** Configures the Audit Log, Alarm Log and Current Metering Log. For more information on the CCM's event logging functions, please refer to Section 5.3.3. (Defaults: Audit Log = On without Syslog, Alarm Log = On without Syslog, Current Metering Log = On)

**Notes:**

- *The Audit Log will create a record of all port connection/disconnection and login/logout activity at the CCM unit.*
  - *The Alarm Log will create a record of each instance where the Invalid Access Alarm is triggered or cleared at the CCM unit.*
  - *The Temperature Log will create a record of ambient rack temperature over time.*
- **Callback Security:** Enables and configures the Callback Security Function as described in Section 5.3.4. In order for this feature to function, a Callback number must also be defined for each desired user account as described in Section 5.5. (Default = On, Callback, Without Password Prompt)

**Notes:**

- *In the Text Interface, Callback Security Parameters are defined via a submenu of the Systems Parameters Menu, which is accessed via the Callback Security item.*
  - *In the Web Browser Interface, Callback Security Parameters are defined via the "Callback Security" link in the General Parameters fly-out menu.*
- **Front Panel Buttons:** This item can be used to disable all front panel button functions. (Default = On)
  - **Modem Phone Number / IP Address:** If an optional external modem is connected to the CCM Setup Port, the Modem Phone Number parameter can be used to denote the phone number for the external modem. In cases where the CCM application includes a cellular modem, the IP address for the cellular modem can be entered via this parameter. (Default = undefined.)
  - **Management Utility:** Enables/Disables the Enterprise Management Utility (WMU.) When enabled, the WMU allows you to manage multiple WTI units via a single menu. (Default = Off.) For more information on the WMU, please refer to the WMU User's Guide, which can be found on the WTI website at:

<http://www.wti.com/t-product-manuals.aspx>

**Note:** *Although the Enterprise Management Utility can be enabled/disabled via either the Web Browser Interface and Text Interface, the Management Utility can only be accessed and operated via the Web Browser Interface.*

- **Scripting Options:** Provides access to a submenu that is used to configure the Command Confirmation, Automated Mode, Command Prompt and IPS Mode parameters as described in Section 5.3.6.

**Note:** *In the Text Interface, the Scripting Options submenu is accessed via item 12. To access the Scripting Options parameters via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear, then click on the "Scripting Options" link.*

- **Power Configuration:** (Applies to Switched AC Plug Only) In the Web Browser Interface, the Voltage Calibration parameter, Power Factor parameter and Power Efficiency parameter are defined via the System Parameters Menu. In the Text Interface, these parameters reside in a separate submenu, which is accessed via the Power Configuration option. For more information on Power Configuration, please refer to Section 5.3.5.
- **Asset Tag:** Allows a descriptive tag or tracking number to be assigned to the CCM unit. Once defined, the Asset Tag can be displayed via the Product Status Screen in the Web Interface or via the `/J*` command in the Text Interface. (Default = Undefined)
- **Login Banner:** Allows definition of a banner/message that will be displayed when a valid username and password are entered during log in. The Login Banner can be used to post legal warning regarding unauthorized access to the unit or to display other user-defined information or instructions. (Default = Undefined)

**Notes:**

- *Although the Login Banner will be displayed when the CCM is accessed via both the Text Interface and Web Browser Interface, the Login Banner can only be defined via the Text Interface.*
- *The Login Banner can be up to 1024 characters long.*
- *The Login Banner text must begin with the `<banner>` command and end with the `</banner>` command.*
- *Banner text can be copied and pasted from a text editor, or sent in from a file.*
- *For best results, the individual text lines in the Login Banner should be less than 80 characters wide.*

- **EnergyWise Configuration:** Defines parameters that are needed in order for the CCM to serve as an element in a Cisco EnergyWise network. This item allows the following parameters to be defined. (Default = Off)  
**Note:** *In the Web Browser Interface, EnergyWise parameters are defined via the "EnergyWise" link in the General Parameters fly-out menu.*
  - ◆ **Enable:** Enables/disables the CCM unit's ability to participate in a Cisco Energywise network. (Default = Off)
  - ◆ **Domain:** The Energywise Domain Name; up to eighty characters long. (Default = Undefined)
  - ◆ **Secret:** A password that is used to authenticate each element in a Cisco Energywise network. The Secret parameter can be up to eighty characters long. (Default = Undefined)
- **Serial Number:** Allows the serial number for the CCM unit to be saved and displayed. When this parameter is defined, the serial number can be displayed via the Product Status screen in the Web Browser or by invoking the /J\* command in the Text Interface. Since the serial number plate on the CCM unit is not always easily accessible after installation, it is often helpful to define the serial number here in order to simplify the process of determining the serial number later. (Default = undefined)

### 5.3.1. The Real Time Clock and Calendar

The Real Time Clock menu is used to set the CCM's internal clock and calendar. The configuration menu for the Real Time Clock offers the following options:

- **Date:** Sets the Month, Date, Year and day of the week for the CCM real-time clock/calendar.
- **Time:** Sets the Hour, Minute and Second for the CCM real time clock/calendar. Key in the time using the 24-hour (military) format.
- **Time Zone:** Sets the time zone, relative to Greenwich Mean Time. Note that the Time Zone setting will function differently, depending upon whether or not the NTP feature is enabled and properly configured. (Default = GMT (No DST))
  - ◆ **NTP Enabled:** The Time Zone setting is used to adjust the Greenwich Mean Time value (received from the NTP server) in order to determine the precise local time for the selected time zone.
  - ◆ **NTP Disabled:** If NTP is disabled, or if the CCM is not able to access the NTP server, then status screens and activity logs will list the selected Time Zone and current Real Time Clock value, but will not apply the correction factor to the displayed Real Time Clock value.
- **NTP Enable:** When enabled, the CCM will contact an NTP server (defined via the NTP Address prompts) once a day, and update its clock based on the NTP server time and selected Time Zone. (Default = Off)

#### Notes:

- *The CCM will also contact the NTP server and update the time whenever you change NTP parameters.*
- *To cause CCM to immediately contact the NTP server at any time, make certain that the NTP feature is enabled and configured, then type /F and press [Enter]. When the System Parameters menu appears, press [Esc]. The CCM will save parameters and then attempt to contact the server, as specified by currently defined NTP parameters.*
- **Primary NTP Address:** Defines the IP address or domain name (up to 64 characters long) for the primary NTP server. (Default = undefined)

#### Notes:

- *In order to use domain names for web addresses, DNS parameters must first be defined as described in Section 5.9.5.*
- *The Web Browser Interface includes two separate fields that are allowed to define both an IPv4 protocol and IPv6 protocol format Primary NTP Address and Secondary NTP Address.*
- *When the Primary NTP Address and Secondary NTP Address are defined via the Text Interface, the CCM will display a prompt that instructs the user to select IPv4 or IPv6 protocol.*
- *The CCM allows parameters for both IPv4 and IPv6 protocols to be defined and saved.*

- **Secondary NTP Address:** Defines the IP address or domain name (up to 64 characters long) for the secondary, fallback NTP Server. (Default = undefined)

**Notes:**

- *In order to use domain names for web addresses, DNS parameters must first be defined as described in Section 5.9.5.*
  - *The Web Browser Interface includes two separate fields that are allowed to define both an IPv4 protocol and IPv6 protocol format Primary NTP Address and Secondary NTP Address.*
  - *When the Primary NTP Address and Secondary NTP Address are defined via the Text Interface, the CCM will display a prompt that instructs the user to select IPv4 or IPv6 protocol.*
  - *The CCM allows parameters for both IPv4 and IPv6 protocols to be defined and saved.*
- **NTP Timeout:** The amount of time in seconds, that will elapse between each attempt to contact the NTP server. When the initial attempt is unsuccessful, the CCM will retry the connection four times. If neither the primary nor secondary NTP server responds, the CCM will wait 24 hours before attempting to contact the NTP server again. (Default = 3 Seconds)
  - **Test NTP Servers:** Allows you to ping the IP addresses or domain names defined via the Primary and Secondary NTP Address prompts, or to ping a new address or domain defined via the Test NTP Servers submenu in order to check that a valid IP address or domain name has been entered.

**Note:** *In order for the Test NTP Servers feature to function, your network and/or firewall must be configured to allow ping commands.*



### 5.3.2. The Invalid Access Lockout Feature

When properly configured and enabled, the Invalid Access Lockout feature can watch all login attempts made via SSH connection, Telnet connection, web browser or the serial SetUp Port. If the counter for any of these exceeds the user-defined threshold for maximum invalid attempts, then the corresponding port or protocol will be automatically disabled for the length of time specified by the Lockout Duration parameter.

When Invalid Access Attempt monitoring is enabled for the serial SetUp Port, the CCM will count invalid access attempts at the serial SetUp Port. If the number of invalid access attempts exceeds the defined Lockout Attempts trigger value, the CCM will lock the serial SetUp Port for the defined Lockout Duration period. When Invalid Access Attempt monitoring for SSH, Telnet or Web are selected, a lockout will be triggered when the number of invalid access attempts during the defined Lockout Duration period exceeds the defined Hit Count for the protocol. For example, if the SSH Hit Count is set at 10 and the SSH Lockout Duration period is set at 120 seconds, then if over 10 invalid access attempts are detected within 120 seconds, the CCM will then lock out the MAC address that generated the excessive attempts for 120 seconds.

Note that when an Invalid Access Lockout occurs, you can either wait for the Lockout Duration period to elapse (after which, the CCM will automatically reactivate the port or protocol), or you can issue the /UL command (type /UL and press [Enter]) via the Text Interface to instantly unlock all CCM logical network ports and communication protocols.

#### Notes:

- *When the Serial Port Invalid Access Lockout Alarm has been enabled as described in Section 7.5, the CCM can also provide notification via email, Syslog Message, and/or SNMP trap whenever an Invalid Access Lockout occurs at the serial SetUp Port.*
- *If the Network Port has been locked by the Invalid Access Lockout feature, it will still respond to the ping command (providing that the ping command has not been disabled at the Network Port.)*

The Invalid Access Lockout configuration menus allow you to select the following parameters:

- **Serial Port Protection:** Enables/Disables the Invalid Access Lockout function for the serial SetUp Port and selects lockout parameters. When this item is enabled and excessive Invalid Access attempts are detected at the SetUp Port, the SetUp Port will be locked until the user-defined Lockout Duration period elapses, or until the /UL command is issued.
- **Serial Port Protection:** Enables/Disables the Invalid Access Lockout feature for the serial SetUp Port. (Default = On)
- **Lockout Attempts:** The number of invalid attempts that must occur in order to trigger the Invalid Access Lockout feature at the serial SetUp Port. (Default = 9)
- **Lockout Duration:** This option selects the length of time that the serial SetUp Port will remain locked when Invalid Access Lockout occurs. If the duration is set at "Infinite", then ports will remain locked until the /UL command is issued. (Default = 30 Minutes)

- **SSH Protection:** Enables/Disables and configures the Invalid Access function for SSH connections. When this item is enabled and excessive Invalid Access Attempts via SSH are detected, then the CCM will lock out the offending MAC address for the user-defined SSH Lockout Duration Period or until the /UL command is issued. Note that for SSH protection, the lockout trigger is a function of the SSH Hit Count parameter and the SSH Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for SSH connections. (Default = On)
- **SSH Hit Count:** The number of invalid attempts that must occur during the length of time specified by the SSH Lockout Duration period in order to trigger the Invalid Access Lockout feature for SSH protocol. For example, if the SSH Hit Count parameter is set to 10 and the SSH Lockout Duration parameter is set to 30 minutes, then the CCM will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 10)
- **SSH Lockout Duration:** This option selects both the length of time that an SSH Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When an SSH Lockout occurs, the offending MAC address will be prevented from establishing an SSH connection to the CCM for the defined SSH Lockout Duration period. (Default = 120 Seconds)
- **Telnet Protection:** Enables/Disables and configures the Invalid Access function for Telnet connections. When this item is enabled and excessive Invalid Access Attempts via Telnet are detected, then the CCM will lock out the offending MAC address for the user-defined Telnet Lockout Duration Period or until the /UL command is issued. Note that for Telnet protection, the lockout trigger is a function of the Telnet Hit Count parameter and the Telnet Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for Telnet connections. (Default = On)
- **Telnet Hit Count:** The number of invalid attempts that must occur during the length of time specified by the Telnet Lockout Duration period in order to trigger the Invalid Access Lockout feature for the Telnet protocol. For example, if the Telnet Hit Count parameter is set to 10 and the Telnet Lockout Duration parameter is set to 30 minutes, then the CCM will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 5)
- **Telnet Lockout Duration:** This option selects both the length of time that a Telnet Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When a Telnet Lockout occurs, the offending MAC address will be prevented from establishing a Telnet connection to the CCM for the defined Telnet Lockout Duration period. (Default = 120 Seconds)

- **Web Protection:** Enables/Disables and configures the Invalid Access function for Web connections. When this item is enabled and excessive Invalid Access Attempts via Web are detected, then the CCM will lock out the offending MAC address for the user-defined Web Lockout Duration Period or until the /UL command is issued. Note that for Web protection, the lockout trigger is a function of the Web Hit Count parameter and the Web Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for web connections. (Default = On)
- **Web Hit Count:** The number of invalid attempts that must occur during the length of time specified by the Web Lockout Duration period in order to trigger the Invalid Access Lockout feature for Web access. For example, if the Web Hit Count parameter is set to 10 and the Web Lockout Duration parameter is set to 30 minutes, then the CCM will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 20)
- **Web Lockout Duration:** This option selects both the length of time that a Web Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When a Web Lockout occurs, the offending MAC address will be prevented from establishing a Web connection to the CCM for the defined Telnet Lockout Duration period. (Default = 60 Seconds)

### 5.3.3. Log Configuration

This feature allows you to create records of command activity, alarm actions, temperature readings and current and power consumption for the CCM unit. The Log features are enabled and configured via the System Parameters Menus.

- **Audit Log:** Creates a record of all power switching at the CCM unit, including reboots and switching caused by Load Shedding, Load Shedding Recovery, Ping No Answer Reboots and Scheduled Reboots. Each Log record includes a description of the activity that caused the power switching, the username for the account that initiated the power switching or reboot and the time and date that the power switching or reboot occurred. In addition to power switching activity, the Audit Log will also include login/logout activity for each user account.
- **Alarm Log:** Creates a record of all Alarm Activity at the CCM unit. When an alarm is triggered, the CCM will generate a record that lists the time and date of the alarm, the name of the Alarm triggered, and a description of the Alarm.
- **Current Metering Log:** (Applies to Switched AC Plug Only) Provides a record of current consumption for the Switched AC Plug. Log records include the time and date, current and voltage readings and temperature readings. In addition, the Current Metering Log will also list temperature data. Current Metering Log data can be downloaded in ASCII, CSV or XML format.
- **Power Metering Log:** (Applies to Switched AC Plug Only) Lists power consumption data for the Switched AC Plug, including Kilowatt Hours, Average Current and Average Power. Power Metering Log data can be saved in ASCII format or downloaded in CSV or XML format

#### 5.3.3.1. Audit Log and Alarm Log Configuration Options

The Log Configuration options in the System Parameters menu allows you to enable/disable and configure the Audit Log and Alarm Log. The Audit Log and Alarm Log both offer the following parameters:

- **Off:** The Log is disabled; command activity and/or alarm events will not be logged.
- **On - With Syslog:** The Log is enabled and the CCM will generate a Syslog Message every time a Log record is created.
- **On - Without Syslog:** The Log is enabled, but the CCM will *not* generate a Syslog Message every time a Log record is created. (Default Setting)

#### Notes:

- *In order for the Audit Log or Alarm Log to generate Syslog Messages, Syslog Parameters must first be defined as described in Section 11.*
- *The Audit Log will truncate usernames that are longer than 22 characters, and display two dots (..) in place of the remaining characters.*

### 5.3.3.2. Reading, Downloading and Erasing Logs

To read or download the status logs, proceed as follows:

- **Text Interface:** Type `/L` and press **[Enter]** to access the Display Log menu. Select the desired option, key in the appropriate number, press **[Enter]** and then follow the instructions in the "Display Logs" submenu. In the text interface, The Display Logs menu is used to download or display the Audit Log and Alarm Log as well as the Current Metering Log and Power Metering Log.
- **Web Browser Interface:** Move the cursor over the "Current Metering," "Power Metering" or "Logs" link. When the flyout menu appears, click on the desired option and then follow the instructions in the resulting submenu.

**Note:** *You can also display current readings via the Current Metering function. In the Text Interface, type `/M` and then press **[Enter]**.*

Proceed as follows to download, display or erase logged data:

- **Audit Log and Alarm Log:** The Audit Log and Alarm Log can be displayed or downloaded via either the Text Interface or Web Browser Interface. When the Audit Log or Alarm Log are displayed via the Text Interface, the CCM will also offer the option to erase Audit Log or Alarm Log data.
- **Current Metering Log and Power Metering Log:** (Applies to Switched AC Plug Only) The Current Metering Log and Power Metering Log can be displayed or downloaded via either the Text Interface or Web Browser Interface. When the Current Metering Log is selected via the Text Interface, the CCM will also offer the option to erase Current Metering Log data.

#### **Notes:**

- *Temperature data is included in the Current History Log.*
- *When the Current Metering Log is erased, the Power Metering Log will also be erased.*
- *The CCM dedicates a fixed amount of internal memory for log records, and if log records are allowed to accumulate until memory is filled, data will eventually "wrap around," and older data will be overwritten by newer data.*
- *Once records have been erased, they cannot be recovered.*

### 5.3.4. Callback Security

The Callback function provides an additional layer of security for access command mode via modem. When properly configured, modem users will not be granted immediate access to command mode upon entering a valid password; instead, the unit will disconnect, and dial a user-defined number before allowing access. If desired, users may also be required to re-enter the password *after* the CCM dials back. In order for Callback Security to function properly, you must first enable and configure the feature via the System Parameters menu as described in this section, and then define a callback number for each desired user account as described in Section 5.5.

To access the Callback Security menu via the Text Interface, type `/F` and press **[Enter]** and then select the Callback Security option. To access the Callback Security menu via the Web Browser Interface, place the cursor over the General Parameters link, wait for the flyout menu to appear, and then Click on the "Callback Security" link. The Callback Security Menu offers the following options:

- **Callback Enable:** This prompt offers five different configuration options for the Callback Security feature: (Default = On - Callback (Without Password Prompt)
  - ◆ **Off:** All Callback Security is disabled.
  - ◆ **On - Callback (Without Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the login prompt will *not* be displayed. If the account *does not* include a Callback Number, that user will be granted immediate access.
  - ◆ **On - Callback (With Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the login prompt *will* be displayed (accounts that include a Callback Number will be required to re-enter their username/password when their modem answers.) If the account *does not* include a Callback Number, then that user will be granted immediate access.
  - ◆ **On - Callback ONLY (Without Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the username/password prompt will *not* be displayed. Accounts that *do not* include a Callback Number will *not* be able to access command mode via modem.
  - ◆ **On - Callback ONLY (With Password Prompt):** Callbacks will be performed for accounts that include a Callback Number, and the username/password prompt *will* be displayed (users will be required to re-enter their username/password when their modem answers.) Accounts that *do not* include a Callback Number will *not* be able to access command mode via modem.
- **Callback Attempts:** The number of times the CCM will attempt to contact the Callback number. (Default = 3 attempts)
- **Callback Delay:** The amount of time the CCM will wait between Callback attempts. (Default = 30 seconds)

#### Notes:

- *After configuring and enabling Callback Security, you must define a callback number for each desired account in order for this feature to function properly.*
- *When using "On - Callback (With Password Prompt)", remember that accounts that do not include a callback number will be allowed to access command mode without callback verification.*

### 5.3.5. Power Source Configuration (For Switched AC Plug Only)

The Power Configuration menu allows you to adjust power measurements in order to obtain a more accurate determination of how much "real power" is being used by devices connected to the CCM's Switched AC Plug. Real Power is determined by the following equation:

$$\text{Real Power} = \frac{(\text{Voltage} * \text{Amps}) * \text{Power Factor}}{\text{Power Efficiency}}$$

To define Power Configuration parameters, access command mode using an account that permits Administrator level commands, then activate the System Parameters Menu.

#### Notes:

- *In the Text Interface, power source configuration parameters are defined via the Power Configuration submenu.*
- *In the Web Browser Interface, power source configuration parameters are selected via the main System Parameters menu.*

The following Power Source Configuration parameters are available:

- **Voltage Calibration:** This option is used to calibrate voltage readings. To calibrate the voltage, first determine the approximate voltage and then select the Voltage Calibration option and key in the correct voltage. In the Web Browser Interface, the voltage is entered at the System Parameters menu in the Voltage Calibration field. In the Text Interface, the voltage is entered in a submenu of the System Parameters menu. (Default = undefined)
- **Power Factor:** Can be any value from 0.1 to 1.00. (Default = 1.00)
- **Power Efficiency:** Can be any whole number from 1% to 100%. (Default = 100%)

### 5.3.6. Scripting Options

The Scripting Options submenu provides access to parameters that are used to set up the CCM unit for running various scripts.

#### Notes:

- To access Scripting Options parameters via the Text Interface, first type `/F` and press **[Enter]** to display the System Parameters Menu, then key in the number for the Scripting Options item and press `[Enter]`.
- To access the Scripting Options parameters via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear, then click on the "Scripting Options" link.

The Scripting Options menu allows the following parameters to be defined:

- **Command Confirmation:** Enables/Disables the Command Confirmation feature. When enabled, a "Sure" prompt will be displayed before power switching and reboot commands are executed. When disabled, commands will be executed without further prompting. (Default = On)
- **Automated Mode:** When enabled, the CCM will execute switching and reboot commands without displaying a confirmation prompt, status screen or confirmation messages. For more information, please refer to Section 5.3.6.1 or Section 9.3. (Default = Off)

**Note:** When the Automated Mode is enabled, security functions are suppressed, and users are able to access configuration menus and control plugs without entering a password. If security is a concern and the Automated Mode is required, it is recommended to use the IP Security feature (Section 5.9.3) to restrict access.

- **Command Prompt:** Allows the Text Interface command prompt to be set to either MPC, IPS, NPS, NBB, VMR, CCM, RPC or the currently defined Site ID Message. (Default = CCM)
- **IPS Mode:** This parameter sets up the CCM for use with command scripts that were written for WTI's IPS Series Remote Reboot Switches. When the IPS Mode is enabled, the "IPS" command prompt will be displayed in Text Mode, User Accounts will not allow definition of a Username, and only the "password" prompt will be displayed when logging into the unit (IPS Mode units will not display a "username" prompt.) (Default = Off)
  - The "IPS" command prompt will be displayed in the Text Mode.
  - Providing that no Administrator level user accounts are defined, the CCM will not display the username or password prompts upon login to command mode.
  - If one or more Administrator level user accounts have been defined, then the CCM will only display the password prompt upon login to command mode. If all Administrator level user accounts (aside from the default "super" account) are deleted, then the CCM will return to the status where no username or password prompts are displayed upon login to command mode.



### 5.3.6.1. Automated Mode

The Automated Mode allows the CCM to execute switching and reboot commands, without displaying menus or generating response messages. Automated Mode is designed to allow the CCM to be controlled by a device which can generate commands to control power switching functions without human intervention.

When Automated Mode is enabled, power switching and reboot commands are executed without a confirmation prompt and without command response messages; the only reply to these commands is the command prompt, which is re-displayed when each command is completed.

Although Automated Mode can be enabled using either the Web Browser Interface or Text Interface, Automated Mode is designed primarily for users who wish to send ASCII commands to the CCM without operator intervention, and therefore does not specifically apply to the Web Browser Interface. When Automated Mode is enabled, the Web Browser Interface can still be used to invoke switching and reboot commands.

#### **Notes:**

- *When the Automated Mode is enabled, password prompts will not be displayed at login, and you will be able to access Administrator Level command functions (including the configuration menus) and control plugs without entering a password.*
- *If you need to enable the Automated Mode, but want to restrict network access to configuration menus, it is strongly recommended to enable and configure the IP Security Function as described in Section 5.9.3.*

To enable/disable the Automated Mode, go to the System Parameters menu and then set the “Automated Mode” option to “On”. When Automated Mode is enabled, CCM functions will change as follows:

1. **All Password Security Suppressed:** When a user attempts to access command mode, the password prompt will not be displayed at either the Setup Port or Network Port. Unless specifically restricted by the IP Security Function, all users will be allowed to access switching and configuration functions, and all commands will be immediately accepted without the requirement to enter a password.
2. **Status Screen Suppressed:** The plug status screen will not be automatically displayed after commands are successfully executed. Note however, that the /S command can still be invoked to display the status screen as needed.
3. **“Sure?” Prompt Suppressed:** All commands are executed without prompting for user confirmation.
4. **Error Messages Suppressed:** Most error messages will be suppressed. Note however, that an error message will still be generated if commands are invoked using invalid formats or arguments.

All other status display and configuration commands will still function as normal.

## 5.4. User Accounts

Each time you attempt to access command mode, you will be prompted to enter a username and password. The username/password entered at login determine which contacts and plug you will be allowed to control and what type of commands you will be allowed to invoke. Each username/password combination is defined within a "user account."

The CCM allows up to 128 user accounts; each account includes a username, password, security level, plug access rights, service access rights and an optional callback number.

### 5.4.1. Command Access Levels

In order to restrict access to important command functions, the CCM allows you to set the command access level for each user account. The CCM offers four access levels: Administrator, SuperUser, User and View Only. Command privileges for each account are set using the "Access Level" parameter in the Add User or Modify User menus.

Each access level grants permission to use a different selection of commands; lower access levels are restricted from invoking configuration commands, while Administrators are granted access to all commands. The four different access levels are listed below:

- **Administrator:** Administrators are allowed to invoke all configuration and power switching commands, can view all status screens, and can always direct switching commands to all the Switched Plug and all Switched Contacts.
- **SuperUser:** SuperUsers are allowed to invoke all power switching commands and view all status screens. SuperUsers can view configuration menus, but are not allowed to change configuration parameters. SuperUsers are granted access to the Switched Plug plus all Switched Contacts.
- **User:** Users are allowed to invoke power switching commands and view all status screens, but can only apply commands to plugs and contacts that they are specifically granted access to. In addition, Users are not allowed to view configuration menus or change configuration parameters.
- **ViewOnly:** Accounts with ViewOnly access, are allowed to view Status Menus, but are not allowed to invoke switching commands, and cannot view configuration menus or change parameters. ViewOnly accounts can display the Plug Status screen, but can only view the status of plugs that are allowed by the account.

Section 17.2 summarizes command access for all four access levels.

In the default state, the CCM includes one predefined account that provides access to Administrator commands and allows control of the Switched Plug plus all Switched Contacts. The default username for this account is "**super**" (lowercase, no quotation marks), and the password for the account is also "**super**".

#### Notes:

- *In order to ensure security, it is recommended that when initially setting up the unit, a new user account with Administrator access should be created, and the "super" account should then be deleted.*
- *If the CCM is reset to default parameters, all user accounts will be cleared, and the default "super" account will be restored.*

### 5.4.2. Switched Plug and Switched Contact Access

Each account can be granted access to a different selection of Switched Contacts, plus the Switched AC Plug and user-defined plug groups. When accounts are created, the Plug Access parameter and the Plug Group Access parameter in the Add User menu or Modify User menu are used to grant or deny access to each contact, plug or plug group. In addition, each access level also restricts the contacts, plug and plug groups that the account will be allowed to access:

- **Administrator:** Administrator level accounts are always allowed to control all contacts, plug and plug groups. Switched Plug and Switched Contact access cannot be disabled for Administrator level accounts.
- **SuperUser:** SuperUser accounts allow access to all contacts, the switched plug and plug groups. Contact, plug and plug group access cannot be disabled for SuperUser accounts.
- **User:** User level accounts are only allowed to issue switching commands to the plugs and plug groups that have been specifically permitted via the "Plug Access" parameter in the Add User and Modify User menus.
- **ViewOnly:** ViewOnly level accounts are not allowed to issue switching commands. ViewOnly accounts can display the On/Off state of plugs and plug groups, but are limited to the plugs and plug groups specified by the account.

### 5.4.3. Port Access

The Port Access parameter is used to grant or deny access to the CCM RJ45 Setup Port. Normally, the Setup port is used for connection to a local control device or an external modem.

The command access level will also determine which ports the account will be allowed to access, as summarized below:

- **Administrator and SuperUser:** Accounts with Administrator or SuperUser level command access are always allowed to connect to the Setup Port. Port access cannot be disabled for Administrator and SuperUser level accounts.
- **User:** User level accounts are only allowed to connect to the Setup Port when port access has been specifically enabled for the account.
- **ViewOnly:** Accounts with ViewOnly access are not allowed to create connections to the Setup Port.

## 5.5. Managing User Accounts

The User Directory function is employed to create new accounts, display parameters for existing accounts, modify accounts and delete accounts. Up to 128 individual user accounts can be created. The "User Directory" function is only available when you have logged into command mode using an account that permits Administrator commands.

In both the Text Interface and the Web Browser Interface, the User Directory menu offers the following functions:

- **View User Directory:** Displays currently defined parameters for any CCM user account as described in Section 5.5.1.
- **Add User to Directory:** Creates new user accounts, and allows you to assign a username, password, command level, plug access plug group access, service access and callback number, as described in Section 5.5.2.
- **Modify User Directory:** This option is used to edit or change account information, as described in Section 5.5.3.
- **Delete User from Directory:** Clears user accounts, as described in Section 5.5.4.

**Note:** *After you have finished selecting or editing user account parameters, make certain to save the new account information before proceeding. In the Web Browser Interface, click on the "Add User" button to save parameters; in the Text Interface, press the [Esc] key several times until the CCM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 5.5.1. Viewing User Accounts

The "View User Directory" option allows you to view details about each account. The View User option will not display actual passwords, and instead, the password field will read "defined". The View User Accounts function is only available when you have accessed command mode using a password that permits Administrator Level commands.

### 5.5.2. Adding User Accounts

The "Add Username" option allows you to create new accounts. Note that the Add User function is only available when you have accessed command mode using a password that permits Administrator Level commands. The Add User Menu can define the following parameters for each new account:

- **Username:** Up to 32 characters long, and cannot include non-printable characters. Duplicate usernames are not allowed. (Default = undefined)
- **Password:** Five to sixteen characters long, and cannot include non-printable characters. Note that passwords are case sensitive. (Default = undefined)
- **Access Level:** Determines which commands this account will be allowed to access. This option can set the access level for this account to "Administrator", "SuperUser", "User" or "ViewOnly." For more information on Command Access Levels, please refer to Section 5.4.1 and Section 17.2. (Default = User)

- **Port Access:** Determines whether or not the account will be allowed to connect to the serial Setup Port. (Defaults; Administrator and SuperUser = Always Enabled, User = Disabled)

**Note:** *ViewOnly level accounts cannot be granted access to the Setup Port.*

- **Plug Access:** Determines which Switched Contacts and/or Switched Plug this account will be allowed to control. (Defaults; Administrator and SuperUser = All Contacts and Plug On, User = All Contacts and Plug Off, ViewOnly = All Contacts and Plug Off)

**Notes:**

- *Administrator and SuperUser level accounts always have access to all Switched Contacts and the Switched Plug.*
  - *User level accounts will only have access to the Switched Contacts and Switched Plug that are defined via the "Plug Access" parameter.*
  - *ViewOnly accounts are allowed to display the Switched Plug and Contact Status Screen, but are limited to the items specified by the account. ViewOnly accounts are not allowed to invoke switching and reboot commands.*
- **Plug Group Access:** Determines which plug groups this account will be allowed to control. For more information on Plug Groups, please refer to Section 5.6. (Defaults; Administrator and SuperUser = All Plug Groups On, User = All Plug Groups Off, ViewOnly = All Plug Groups Off)

**Notes:**

- *In order to use this feature, you must first define at least one Plug Group as described in Section 5.6.*
  - *Administrator and SuperUser level accounts will always have access to all plug groups.*
  - *User Level accounts will only have access to the plug groups defined via the Plug Group Access parameter.*
  - *ViewOnly accounts are allowed to display the On/Off status of plug groups via the Plug and Contact Status Screen, but are limited to the plug groups specified by the account. ViewOnly accounts are not allowed to invoke switching and reboot commands.*
- **Service Access:** Determines whether this account will be able to access command mode via Serial Port, Telnet/SSH or Web and whether or not the account will be allowed to initiate outbound connections. For example, if Telnet/SSH Access is disabled for this account, then this account will not be able to access command mode via Telnet or SSH. (Default = Serial Port = On, Telnet/SSH = On, Web = On, Outbound Access = Off.)

**Note:** *The Service Access Parameter is only used to select permitted access services for an individual user account. To separately enable/disable all SSH or Telnet Access for the CCM unit, please refer to Section 5.9.2.*

- **Current/Power Metering:** (Applies to Switched AC Plug Only) Enables/Disables current and power metering for this account. When disabled, this account will not be able to view current or power readings or display current or power history. Note that in order for accounts to be able to display these logs, Current and Power Metering must be enabled via the Systems Parameters menu as described in Section 5.3. (Default = On)
- **Callback Phone Number:** Assigns a number that will be called when this account attempts to access command mode via modem, and the Callback Security Function has been enabled as described in Section 5.3.4. (Default = undefined)

**Notes:**

- *If the Callback Number is not defined, then Callbacks will not be performed for this user.*
  - *If the Callback Number is not defined for a given user, and the Callback Security feature is configured to use either of the "On - Callback" options, then this user will be granted immediate access to command mode via modem.*
  - *If the Callback Number is not defined for a given user, and the Callback Security feature is configured to use the "On - Callback ONLY" option, then this user will not be able to access command mode via Modem.*
  - *When using the "On - Callback (With Password Prompt)" option, it is important to remember that accounts that do not include a callback number will be allowed to access command mode without callback verification.*
- **Authorization Keys:** This item can be used to assign an SSH Authorization Key to the user account, view assigned authorization keys or delete assigned authorization keys. When a valid authorization key is assigned to a given user, that user will be able to access CCM command mode without entering a password. When assigning an authorization key, the CCM offers the option to define a name for the key and upload a key from the user's server.

**Note:** *After you have finished selecting or editing account parameters, make certain to save the new account information before proceeding. In the Web Browser Interface, click on the "Add User" button to save parameters; in the Text Interface, press the [Esc] key several times until the CCM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 5.5.3. Modifying User Accounts

The "Edit User Directory" function allows you to edit existing accounts in order to change parameters, plug access rights or Administrator Command capability. Note that the Edit/Modify User function is only available when you have accessed command mode using a password that permits Administrator Level commands. Once you have accessed the Modify Users menu, use the menu options to redefine parameters in the same manner employed for the Add User menu, as discussed in Section 5.5.2.

**Note:** *After you have finished changing parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Modify User" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the CCM displays the "Saving Configuration" message.*

### 5.5.4. Deleting User Accounts

This function is used to delete individual user accounts. Note that the Delete User function is only available when you have accessed command mode using a password that permits Administrator Level commands.

**Notes:**

- *Deleted accounts cannot be automatically restored.*
- *The CCM allows you to delete the default "super" account, which is included to permit initial access to command mode. Before deleting the "super" account, make certain to create another account that permits Administrator Access. If you do not retain at least one account with Administrator Access, you will not be able to invoke Administrator level commands.*

## 5.6. The Plug Group Directory

The Plug Group Directory allows you to designate "groups" of Switched Contacts and the Switched AC Plug that are dedicated to a similar function, and will most likely be switched or rebooted at the same time or controlled by the same type of user account.

For example, an individual equipment rack might include an assortment of devices belonging to different departments or clients. In order to simplify the process of granting power switching access rights to the accounts that will control power to these devices, you could assign all of the Switched Contacts and/or Switched Plug for the devices belonging to Department A to a Plug Group named "Dept\_A". When user accounts are defined later, this would allow you to quickly grant access rights for all of the Switched Contacts and/or Switched Plug for devices belonging to Department A to the appropriate user accounts, by merely granting access to the Dept\_A Plug Group, rather than by selecting the individual contacts or plug for each user account.

Likewise, Plug Groups allow you to direct On/Off/Boot commands to a series of Switched Contacts and/or the Switched Plug, without addressing each contact or plug individually. Given the example above, you could quickly reboot all plugs for Department A, by either including the "Dept\_A" Plug Group name in a /BOOT command line via the Text Interface, or by using the Plug Group Control menu in the Web Browser Interface.

The Plug Group Directory function is only available when you have logged in using an account that permits Administrator commands. In both the Text Interface and the Web Browser Interface, the Plug Group Directory menu offers the following functions:

- **View Plug Group Directory:** Displays currently defined power switching access rights for any CCM Plug Group as described in Section 5.6.1.
- **Add Plug Group to Directory:** Creates new Plug Groups, and allows you to assign power switching access rights to each group as described in Section 5.6.2.
- **Modify Plug Group Directory:** This option is used to edit or change power switching access rights for each Plug Group, as described in Section 5.6.3.
- **Delete Plug Group from Directory:** Clears Plug Groups that are no longer needed, as described in Section 5.6.4.

### 5.6.1. Viewing Plug Groups

The "View Plug Group Directory" option allows you to view the configuration of each Plug Group. Note that the View Plug Group Directory function is only available when you have accessed command mode using a password that permits Administrator Level commands. In the Web Browser Interface, the Plug Group Directory can be viewed by clicking on the link on the left hand side of the page. In the Text Interface, the Plug Group Directory can be viewed by typing /G and pressing **[Enter]** and then selecting the option from the resulting submenu.



### 5.6.2. Adding Plug Groups

The "Add Plug Group to Directory" option allows you to create new Plug Groups and assign plug access rights to each group. The Add Plug Group function is only available when you have accessed command mode using a password that permits Administrator Level commands. The Add Plug Group Menu can be used to define the following parameters for each new account:

- **Plug Group Name:** Assigns a name to the Plug Group. (Default = undefined)
- **Plug Access:** Determines which Switched Contacts and/or the Switched Plug this Plug Group will be allowed to control. (Default = undefined)

**Note:** *After defining or editing Plug Group parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Add Plug Group" button to save parameters; in the Text Interface, press the [Esc] key several times until the CCM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 5.6.3. Modifying Plug Groups

The "Modify Plug Group" function allows you to edit existing Plug Groups in order to change power switching access rights. Note that this function is only available when you have accessed command mode using a password that permits Administrator Level commands. Once you have accessed the Modify Plug Group menu, use the menu options to redefine parameters in the same manner that is used for the Add Plug Group menu, as discussed in Section 5.6.2.

**Note:** *After changing or editing parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Modify Plug Groups" button to save parameters; in the Text Interface, press the [Esc] key several times until the CCM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 5.6.4. Deleting Plug Groups

This function is used to delete individual Plug Groups. Note that this function is only available when you have accessed command mode using a password that permits Administrator Level commands.

**Note:** *Deleted Plug Groups cannot be automatically restored.*

## 5.7. Defining Contact and Plug Parameters

The Plug Parameters Menu is used to define Plug Names, boot/sequence delay times, Power Up Default values and other parameters for each Switched Contact, plus the Switched AC Plug. Note that this function is only available when you have accessed command mode using a password that permits Administrator Level commands. The Plug Parameters Menu allows you to define the following parameters:

- **Plug Name:** (Up to 16 Characters, Default = undefined)

**Note:** *Plug Names must begin with either a lower case alphabetic letter or upper case alphabetic letter. Plug Names cannot begin with a number character or symbol character.*

- **Boot/Seq. Delay:** When more than one contact and/or plug is switched On or a reboot cycle is initiated, the Boot/Sequence delay determines how much time will elapse before the next contact or plug is switched On. When the Boot/Sequence Delay is applied, the CCM will wait for the user-defined delay period before switching On the next contact or plug. When Reboot cycles and switching actions are initiated, the Boot/Sequence Delay will be applied as follows:  
(Default = 0.5 Second)
  - ◆ **Reboot Cycle Delay:** During a reboot cycle, the CCM will first switch all selected contacts and plugs "Off" (with a 0.5 second pause between each "Off" operation), and then begin to switch selected contacts and/or plugs back On again, pausing for the user-defined Boot/Sequence Delay before switching On the next contact or plug. For example, if the Boot/Sequence Delay for Plug 3 is ten seconds, then the CCM will pause for ten seconds before proceeding to the next contact or plug.
  - ◆ **"On" Sequence Delay:** When two or more plugs are switched On, the CCM will pause for the user-defined Boot/Sequence Delay before switching the next plug.
- **Power Up Default:** Determines how this contact or plug will react when the Default command (/DPL) is invoked, or after power to the unit has been interrupted and then restored. After the default command is invoked, or power is restored, the CCM will automatically switch each contact or plug On or Off as specified by the Power-Up Default. (Default = On).

**Note:**

- *If you have accessed command mode using an account that permits Administrator or SuperUser level commands, then the Default command will be applied to all Switched Contacts, plus the Switched AC Plug.*
- *If you have accessed command mode via an User Level account, then the Default command will only be applied to contacts/plug allowed by your account.*
- **Boot Priority:** The Boot Priority parameter determines the order in which contacts and plugs will be switched On. The contact or plug that has been assigned a Boot Priority of "1" will always be switched on first, followed by the contact/plug that has been assigned the Boot Priority of "2", and so forth. For more information on the Boot Priority parameter, please refer to Section 5.7.1. (Default = Switched Plug first, then all Switched Contacts according to contact number)

### 5.7.1. The Boot Priority Parameter

Normally, when an "On" or "Reboot" command is invoked, the CCM will switch on the Switched Plug and Contacts according to their default, numeric order. Although in many cases, the default, numeric order will work fine, there are other cases where an individual device (such as a router) must be switched on first, in order to support a second device that will be switched on later.

The Boot Priority Parameter simplifies the process of setting the order in which the Switched Plug and Switched Contact are switched On, by assigning a priority number to each plug/contact, rather than by requiring the user to make certain that devices are always connected to the CCM in a set order. Likewise, when new devices are added to your equipment rack, the Boot Priority Parameter eliminates the need to disconnect all existing devices and then rearrange the plugs and contacts connected to the CCM (and re-define plug parameters) to ensure that they are switched on in the desired order.

#### Notes:

- *No two plugs/contacts can be assigned the same Boot Priority number.*
- *When a higher Boot Priority is assigned to any given plug/contact, all subsequent plug/contacts will have their boot priorities lowered by a factor of 1.*
- *The Boot Priority is also displayed on the Plug Status Screen.*

#### 5.7.1.1. Example 1: Change Contact C2 to Priority 1

In the Example shown in Figure 5.1, we start out with all contacts and the Switched Plug set to their default Boot Priorities, with The Switched Plug (A1) first, Switched Contact C1 second and so forth.

Next, the Boot Priority for Switched Contact C2 is changed to Priority 1. This means that contact C2 will now be switched On first after a reboot, and that the Switched Plug (A1) will now be switched On second, Contact C1 will be third, etc..

Note that when the Boot Priority for Contact C2 is set to 1, the Boot Priorities for all Plugs and Contacts that were previously Booted before Contact C2 are now lowered by a factor of one.

BEFORE (Plug No.)	Priority	(Assign Contact C2 to Priority 1)	AFTER (Plug No.)	Priority
(A1)	1		(A1)	2
(C1)	2		(C1)	3
(C2)	3	→ (1) →	(C2)	①
(C3)	4		(C3)	4
(C4)	5		(C4)	5

Figure 5.1: Boot Priority Example 1

### 5.7.1.2. Example 2: Change Contact C4 to Priority 2

In the second Example shown in Figure 5.2, we start out with Boot Priorities for the Switched Plug and Switched Contacts set as they were at the end of Example 1; Contact C2 is first, the Switched Plug (A1) is second, Contact C1 is third, Contact C3 is fourth, and Contact C4 is last.

Next, the Boot Priority for Contact C4 is changed to Priority 2. This means that Contact C2 will continue to be switched on first after a reboot, but now Contact C4 will be switched on second, the Switched Plug (A1) will be third, Contact C1 will be fourth, and Contact C3 will be last.

Once again, note that when the Boot Priority for Contact C4 is set to 2, the Boot Priorities for all Plugs and Contacts that were previously Booted before Contact C4 are now lowered by a factor of one

<b>BEFORE</b> (Plug No.)	<b>Priority</b>	<b>(Assign Contact C4 to Priority 2)</b>	<b>AFTER</b> (Plug No.)	<b>Priority</b>
(A1)	2		(A1)	3
(C1)	3		(C1)	4
(C2)	1		(C2)	1
(C3)	4		(C3)	5
(C4)	5	→ (2) →	(C4)	(2)

Figure 5.2: Boot Priority Example 2

## 5.8. Serial Port Configuration

The Serial Port Configuration menus allow you to select parameters for the CCM Setup Port. The Setup Port (Port 1) can be configured for connection to a local PC or Modem. In addition, the Serial Port Configuration menu (Port Parameters) can also be used to set communications parameters, disable Administrator level commands at the Setup Port and also select a number of other Setup Port Parameters described below.

### Communication Settings:

- **Baud Rate:** Any standard rate from 300 bps to 115.2K bps. (Default = 9600 bps)
- **Bits/Parity:** (Default = 8-None)
- **Stop Bits:** (Default = 1)
- **Handshake Mode:** XON/XOFF, RTS/CTS (hardware), Both, or None. (Default = RTS/CTS)

### General Parameters:

- **Administrator Mode:** In WTI console server products, this parameter is used to permit or deny port access to Administrator level accounts. The CCM does not allow Administrator access to the serial port to be disabled.
- **Logoff Character:** The Logoff Character determines the command(s) or character(s) that must be issued at this port in order to disconnect this port from another port. Note that the Logoff Character does not apply to Direct Connections. (Default = ^x)
- **Sequence Disconnect:** Enables/Disables and configures the disconnect command. This item offers the option to disable the Sequence Disconnect, select a one character format or a three character format. (Default = One Character)
- **Inactivity Timeout:** Enables and selects the Timeout Period for this port. If enabled, the Setup Port will disconnect when no additional data activity is detected for the duration of the timeout period. (Default = 5 Minutes)
- **Command Echo:** Enables or Disables command echo at the Setup Port. When disabled, commands that are sent to the Setup Port will still be invoked, but the actual keystrokes will not be displayed on your monitor. (Default = On)
- **Accept Break:** Determines whether the port will accept breaks received from the attached device. When enabled, breaks received at the port will be passed to any port that this port is connected to. When disabled, breaks will be refused at this port. (Default = On)

**Port Mode Parameters:**

- **Port Name:** Allows you to assign a name to the Setup Port. (Default = undefined)
- **Port Mode:** Selects the port mode for the Serial port. The port mode can be set to Normal Mode, Modem Mode or Modem PPP Mode. (Default = Normal Mode)

Depending on the Port Mode selected, the CCM will display additional prompts listed below. In the Text Interface, these parameters are accessible via a submenu, which will only be active when the appropriate port mode is selected. In the Web Browser Interface, fields will be "grayed out" unless the corresponding port mode is selected.

- ◆ **Normal Mode:** Allows communication with a local PC and permits access to command mode. When the Normal Mode is selected, the following mode-specific parameter can also be defined:
  - **DTR Output:** Determines how DTR will react when the port disconnects. DTR can be held low, held high, or pulsed for 0.5 seconds and then held high. (Default = Pulse)
- ◆ **Modem Mode:** Permits access to command mode and simplifies connection to an external modem. Modem Mode ports can perform all functions normally available in Normal Mode, but Modem Mode also allows definition of the following, additional parameters:
  - **Modem Reset String:** Redefines the modem reset string. The Reset String can be sent prior to the Initialization string. (Default = `ATZ`.)
  - **Modem Initialization String:** Defines a command string that can be sent to initialize a modem to settings required by your application. (Default = `AT&C1&D2S0=1&B1&H1&R2`)
  - **Modem Hang-Up String:** Although the CCM will pulse the DTR line to hang-up an attached modem, the Hang-Up string is often useful for controlling modems that do not use the DTR line. (Default = undefined.)
  - **Reset/No Dialtone Interval:** Determines how often the Reset String will be sent to the modem at this port and also sets the trigger value for the No Dialtone Alarm. For more information on the No Dialtone Alarm, please refer to Section 7.7. (Default = 15 Minutes)
  - **No Dialtone Alarm Enable:** When this item is "On" the No Dialtone Alarm can be enabled as described in Section 7.7. When the No Dialtone Alarm is enabled and properly configured, the CCM can provide notification if the unit detects that a phone line connected to a modem installed at this port is dead. (Default = Off.)

**Note:** When communicating with the CCM via modem, these parameters will not be changed until after you exit command mode and disconnect.

- ◆ **Modem PPP Mode:** Allows data that is normally sent via ethernet to be sent via phone line. When Modem PPP Mode is selected, the following modem-related parameters will be available:
  - **Reset String:** Redefines the modem reset string. The Reset String can be sent prior to the Initialization string. (Default = **ATZ**.)
  - **Initialization String:** Defines a command string that is used to initialize the modem to settings required for PPP communication (Default = **ATQ0V1E1S0=0&C1&D2**)
  - **Hang-Up String:** Although the CCM will pulse the DTR line to hang-up an attached modem, the Hang-Up string is often useful for controlling modems that do not use the DTR line. (Default = undefined.)
  - **Reset/No Dialtone Interval:** Determines how often the Reset String will be sent to the modem at this port and also sets the trigger value for the No Dialtone Alarm. For more information on the No Dialtone Alarm, please refer to Section 7.7. (Default = 15 Minutes)
  - **No Dialtone Enable:** When this item is "On" the No Dialtone Alarm can be enabled as described in Section 7.7. When the No Dialtone Alarm is enabled, the CCM can provide notification if the unit detects that a phone line connected to a modem installed at this port is dead. (Default = Off.)
  - **Periodic Reset Location:** The IP address or URL for the website that will be used to keep the PPP connection alive when not in use. The CCM will regularly ping the selected IP address or URL in order to keep the connection alive. (Default = undefined)

**Notes:**

- *In order to select a domain name as the Periodic Reset Location, you must first define the Domain Name Servers as described in Section 5.9.5.*
- *The IP Address, P-t-P and Subnet Mask parameters cannot be defined by the user and will be automatically supplied by the ISP when a PPP communication is started..*
- **PPP Phone Number:** The phone number for the line that will be used for PPP communication. (Default = undefined)
- **User Name:** The user name for the ISP account that will be used for PPP communication. (Default = undefined)
- **Password:** The password for the ISP account that will be used for PPP communication (Default = undefined)
- **IP Address:** The temporary IP address that will be assigned to the PPP communication session by the ISP. Note that this item cannot be defined by the user and will be automatically supplied by the ISP when a PPP communication session is started. (Default = undefined)
- **P-t-P:** This item cannot be defined by the user and will be automatically set by the ISP when a PPP communication session is started. (Default = undefined)
- **Subnet Mask:** This item cannot be defined by the user and will be automatically set by the ISP when a PPP communication session is started. (Default = undefined)

## 5.9. Network Configuration

The Network Parameters Menus are used to select parameters and options for the Network Port and also allow you to implement IP Security features, which can restrict access based on the user's IP Address.

Although the Web Browser Interface and Text Interface allow definition of essentially the same parameters, parameters are arranged differently in the two interfaces. In the Text Interface, most network parameters are defined via one menu which is accessed using the /N command. In the Web Browser Interface, network parameters are divided into separate menus which are accessed via the Network Configuration flyout menu.

### Notes:

- *Settings for network parameters depend on the configuration of your network. Please contact your network administrator for appropriate settings.*
- *The Network Parameters Menu selects parameters for all 16 logical Network Ports.*
- *The IP Address, Subnet Address and Gateway Address cannot be changed via the Web Browser Interface. In order to change these parameters, you must access the unit via the Text Interface.*
- *When a new IP Address is selected, or the status of the DHCP feature is changed, the unit will disconnect and reconfigure itself with the new values when you exit the Network Parameters Menu. When configuring the unit, make certain your DHCP server is set up to assign a known, fixed IP address in order to simplify reconnection to the unit after the new address has been assigned. DHCP Parameters cannot be changed via the Web Browser Interface.*
- *The Network Parameters menu is only available when you have logged into command mode using an account and port that permit Administrator level commands (Supervisor Mode enabled.)*

The Network Parameters menu allows you to define the parameters discussed in the following sections. Note that although the descriptions of network parameters are arranged according to the Web Browser Interface, in the Text Interface, most parameters are found in two large menus: one for IPv4 and one for IPv6. Note that both the IPv4 configuration menu and the IPv6 configuration menu offer essentially the same parameters. To access the network configuration menus, proceed as follows

- **Text Interface:** To define network parameters for the IPv4 protocol, type /N and press **[Enter]**. To define network parameters for the IPv6 protocol, type /N6 and press **[Enter]**.
- **Web Browser Interface:** Place the cursor over the "Network Configuration" link on the left hand side of the screen. When the fly-out menu appears, click on the appropriate link to display the desired menu. Note that some submenus offer the option to define IPv4 or IPv6 parameters and that IPv4 and IPv6 menus include a button that can be used to jump to the other protocol.



### 5.9.1. Network Port Parameters

In the Text Interface, these parameters are found in the main Network Configuration menu. In the Web Browser Interface, these parameters are found by placing the cursor over the "Network Configuration" link on the left hand side of the screen, and then clicking on the "Network Port Parameters" link in the resulting fly-out menu.

- **Administrator Mode:** Permits/denies port access to accounts that allow Administrator or SuperUser level commands. When enabled (Permit), the port will be allowed to invoke Administrator and SuperUser level commands, providing they are issued by an account that permits them. If disabled (Deny), then accounts that permit Administrator and SuperUser level commands will not be allowed to access command mode via this port. (Default = Permit)
- **Logoff Character:** Defines the Logoff Character for this port. This determines which command(s) must be issued at this port in order to disconnect from a second port. (Default = ^x ([Ctrl] plus [X]))

**Note:** *The Sequence Disconnect parameter can be used to pick a one character or a three character logoff sequence.*

- **Sequence Disconnect:** Enables/Disables and configures the Resident Disconnect command. Offers the option to either disable the Sequence Disconnect, or select a one character, or three character command format. (Default = One Character).

#### Notes:

- *The One Character Disconnect is intended for situations where the destination port should **not** receive the disconnect command. When the Three Character format is selected, the disconnect sequence **will** pass through to the destination port prior to breaking the connection.*
- *When Three Character format is selected, the Resident Disconnect uses the format "[Enter]LLL[Enter]", where L is the selected Logoff Character.*
- **Inactivity Timeout:** Enables and selects the Inactivity Timeout period for the Network Port. If enabled, and the port does not receive or transmit data for the specified time period, the port will disconnect. (Default = 5 Minutes).
- **Command Echo:** Enables or Disables the command echo for the Network Port. (Default = On).
- **Accept Break:** Determines whether the port will accept breaks received from the attached device, and pass them along to a connected port. When enabled, breaks received at this port will be passed to any port this port is connected to, and sent to the device connected to the other port. When disabled, breaks will be refused at this port. (Default = On)
- **Multiple Logins:** (Text Interface Only) If the CCM is installed in an environment that *does not* include communication via an open network (local communication only), then the Multiple Logins parameter can be used to determine whether or not multiple users will be able to communicate with the unit at the same time. If this parameter is set to "Off" then only one user will be allowed to communicate with the unit at a time. (Default = On)

### 5.9.2. Network Parameters

In the Text Interface, these parameters are accessed via the main Network Configuration menu, which can be activated by typing `/N` (for IPv4 parameters) or `/N6` (for IPv6 parameters) and then pressing **[Enter]**. In the Web Browser Interface, these parameters are found by placing the cursor over the "Network Configuration" link on the left hand side of the screen, and then clicking on the "Network Port Parameters" link in the resulting fly-out menu.

**Note:** *The IP Address, Subnet Mask, Gateway Address and DHCP status cannot be changed via the Web Browser Interface. In order to change these parameters, you must access the CCM via the Text Interface.*

- **IP Address:** (Default = 192.168.168.168)
- **Subnet Mask:** (IPv4 Only; Default = 255.255.255.0)
- **Subnet Prefix:** (IPv6 Only; Default = undefined)
- **Gateway Address:** (Default = undefined)
- **DHCP:** Enables/Disables Dynamic Host Configuration Protocol. When this option is "On", the CCM will perform a DHCP request. Note that in the Text Interface, the MAC address for the CCM is listed on the Network Status Screen. (Default = Off)

**Note:** *Before configuring this feature, make certain your DHCP server is set up to assign a known, fixed IP address. You will need this new IP address in order to reestablish a network connection with the CCM unit.*

- **IP Security:** Provides access to a submenu that is used to enable and define the IP Security filter as described in Section 5.9.3. (Default = Off)

**Note:** *In the Web Browser Interface, IP Security parameters are defined via the IP Security Submenu, which may be accessed via the Network Configuration Menu.*

- **Static Route:** Provides access to a submenu that is used to enable and define Static Route functions as described in Section 5.9.4. (Default = Off)

**Note:** *In the Web Browser Interface, Static Route parameters are defined via the Static Route Submenu, which may be accessed via the Network Configuration Menu.*

- **DNS Servers:** Provides access to a submenu that is used to define Domain Name Server parameters as described in Section 5.9.5. (Default = undefined)

**Note:** *In the Web Browser Interface, DNS Server parameters are defined via the DNS Server Submenu, which may be accessed via the Network Configuration Menu.*

- **Telnet Access:** Enables/disables Telnet access. When Telnet Access is "Off," users will not be allowed to establish a Telnet connection to the unit. Note that in the Text Interface, this item also provides access to the "Telnet Port" and "Maximum per Source" parameters. (Default = On)
- **Telnet Port:** Selects the TCP/IP port number that will be used for Telnet connections. In the Text Interface, this item is defined via a submenu, displayed when the Telnet Access parameter is selected. (Default = 23)
- **Max. Per Source:** The maximum number of Telnet sessions that will be allowed per user MAC address. (Default = 4)

**Notes:**

- *In the Text Interface, the "Per Source" parameter is defined via a submenu of item 21 (Telnet Access) in the Network Parameters menu.*
- *After changing the "Max Per Source" parameter, you must log out of all pre-existing Telnet sessions in order for the new maximum value to be applied.*
- **SSH Access:** Enables/disables SSH communication. (Default = On)
- **SSH Port:** Selects the TCP/IP port number that will be used for SSH connections. Note that in the Text Interface, this option is defined via a submenu that is displayed when the SSH Access parameter is selected (item number 22). (Default = 22)
- **SSH View Port Enable:** (Text Interface Only) Allows monitoring of Serial Port activity. (Default = Off)
- **SSH View Port Bidirection:** (Text Interface Only) Allows monitoring of bidirectional Serial Port Activity. (Default = Off)
- **HTTP Access (Web Access):** Enables/disables the Web Browser Interface. When disabled, users will not be allowed to contact the unit via the Web Browser Interface. (Default = Off)
- **HTTP Port:** Selects the TCP/IP port number that will be used for Web Access. (Default = 80)
- **HTTPS Access:** Enables/disables HTTPS communication. For instructions on setting up SSL encryption, please refer to Section 14. (Default = On)
- **HTTPS Port:** Selects the TCP/IP port number that will be used for HTTPS connections. (Default = 443)

**Notes:**

- *In the Text Interface, HTTP and HTTPS parameters reside in a separate submenu. To enable and configure HTTP and HTTPS Access via the Text Interface, access the Network Configuration Menu as described in Section 5.9, then type 23, press **[Enter]** and use the resulting submenu to select parameters.*
- *When the Web Access parameter is defined via the Text Interface, the resulting submenu will also allow you to select SSL (encryption) parameters as described in Section 14.*

- **Harden Web Security:** When the Harden Web Security feature is On (default,) only the high and medium cypher suites for SSLv3 and TLSv1 will be enabled. When the Harden Web Security feature is Off, all SSL protocols will be enabled, allowing compatibility with older browsers. (Default = On.)

**Note:** *In the Text Interface, this option is enabled/disabled via the Web Access submenu.*

- **TLS Mode:** Selects TLSv1 or TLSv1.1. Although TLSv1.1 provides better security, the default settings of most browsers do not support TLSv1.1. For more information, please refer to Section 14.4. (Default = TLSv1)

**Note:** *In the Text Interface, the TLS Mode parameter is located in the Web Access submenu.*

- **SYSLOG Addresses:** Defines the IP addresses for the Syslog Daemon(s) that will receive log records generated by the CCM. Allows definition of IP addresses for both a primary Syslog Daemon and an optional secondary Syslog Daemon. SYSLOG Addresses can be entered in either IPv4 or IPv6 format, or in domain name format (up to 64 characters.) For more information, please refer to Section 11. (Default = undefined)

**Notes:**

- *The Syslog Address submenu in the Text Interface and the Network Parameters submenu in the Web Browser Interface both include a Ping Test function that can be used to ping the user-selected Syslog IP Addresses in order to verify that valid IP addresses have been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping the currently defined Syslog Addresses in order to make certain that the IP addresses are responding.*
- **Ping Access:** Configures the CCM's response to ping commands. Ping Access can be set to block all ping commands, allow all ping commands or only accept ping commands from user specified IP addresses (Limited.) When the "Limited" option is selected, up to four permitted IP address can be defined via the submenu. Note that disabling Ping Access at the Network Port will not effect the operation of the Ping-No-Access Alarm. (Default = Allow All)

- **Raw Socket Access:** Enables/disables Raw Socket Protocol access to the Network Port via Direct Connect and selects the port number for Raw Socket Access. This item can be used to enable or disable Raw Socket Protocol access and select either port 23 or port 3001 for use for Raw Socket connections. (Default = Off)

**Notes:**

- *The Raw Socket Access option is often useful for users who encounter network problems when attempting to communicate with the CCM using a script that was previously written for our legacy IPS product line.*
  - *If the "On (23)" option is selected, you must either disable Telnet Port 23 or use the Telnet Access option to select a port other than Port 23.*
  - *When the Raw Socket Access option is enabled, you must connect to the CCM using the port number selected for Raw Socket Access. For example, if the CCM IP address is "1.2.3.4", and port 3001 has been selected for Raw Socket Access, in order to establish a Raw Socket connection to the CCM's Network Port, then on a UNIX system, the connection command would be: \$ telnet 1.2.3.4 3001 [Enter].*
- **Ping Syslog Servers:** (Ping Test) Pings the IP addresses which have been defined for the SYSLOG Servers in order to check for a response.

**Notes:**

- *The Syslog Address submenu in the Text Interface and the Network Parameters submenu in the Web Browser Interface both include a Ping Test function that can be used to ping the user-selected Syslog IP Addresses in order to verify that valid IP addresses have been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping the currently defined Syslog Addresses in order to make certain that the IP addresses are responding.*

### 5.9.3. IP Security

The IP Security feature allows the CCM to restrict unauthorized IP addresses from establishing inbound connections to the unit via telnet or Web Browser. This allows you to grant access to only a specific group of Telnet or Web IP addresses, or block a particular IP address completely. In the default state, the CCM accepts incoming IP connections from all hosts.

In the Text Interface, IP Security parameters are defined via the Network Configuration menu. In the Web Browser Interface, these parameters are found by placing the cursor over the "Network Configuration" link, and then clicking on the "IP Security" link in the resulting fly-out menu. In the default state, IP Security is disabled. The IP Security Function employs a TCP Wrapper program which allows the use of standard, Linux operators, wild cards and net/mask pairs to create a host based access control list.

The IP Security configuration menus include "hosts.allow" and "hosts.deny" client lists. When setting up IP Security, you must enter IP addresses for hosts that you wish to allow in the Allow list, and addresses for hosts that you wish to deny in the Deny list. Since Linux operators, wild cards and net/mask pairs are allowed, these lists can indicate specific addresses, or a range of addresses to be allowed or denied.

When the IP Security feature is properly enabled, and a client attempts to connect, the CCM will perform the following checks:

1. If the client's IP address is found in the "hosts.allow" list, the client will be granted immediate access. Once an IP address is found in the Allow list, the CCM will not check the Deny list, and will assume you wish to allow that address to connect.
2. If the client's IP address is not found in the Allow list, the CCM will then proceed to check the Deny list.
3. If the client's IP Address *is* found in the Deny list, the client *will not* be allowed to connect.
4. If the client's IP Address *is not* found in the Deny list, the client *will* be allowed to connect, even if the address was not found in the Allow list.

#### **Notes:**

- *If the CCM finds an IP Address in the Allow list, it will not check the Deny list, and will allow the client to connect.*
- *If both the Allow and Deny lists are left blank, then the IP Security feature will be disabled, and all IP Addresses will be allowed to connect (providing that the proper password and/or SSH key is supplied.)*
- *When the Allow and Deny lists are defined, the user is only allowed to specify the Client List; the Daemon List and Shell Command cannot be defined.*

### 5.9.3.1. Adding IP Addresses to the Allow and Deny Lists

To add an IP Address to the Allow or Deny list, and begin configuring the IP Security feature, proceed as follows.

#### Notes:

- *Both the Allow and Deny list can include Linux operators, wild cards, and net/mask pairs.*
- *In some cases, it is not necessary to enter all four "digits" of the IP Address. For example, if you wish to allow access to all IP addresses that begin with "192," then you would only need to enter "192."*
- *The IP Security Configuration menu is only available when you have accessed command mode using an account that permits Administrator level commands.*
- *In order to use domain names in the Allow List and/or Deny List, you must first define IP address(es) for the desired Domain Name Server(s) as described in Section 5.9.5.*

1. Access the IP Security Configuration Menu.
  - a) **Text Interface:** Type `/N [Enter]` to define addresses in IPv4 format, or type `/N6` and press `[Enter]` to define addresses in IPv6 format. The Network Configuration Menu will be displayed. From the Network Configuration Menu, type `5 [Enter]` to display the IP Security Menu.
  - b) **Web Browser Interface:** Place the cursor over the "Network Configuration" link on the left hand side of the screen. When the fly-out menu appears, click on the "IP Security" Link to display the IP Security Menu. The IP Security menu in the Web Browser Interface will accept addresses in either IPv4 or IPv6 format.
2. **Allow List:** Enter the IP Address(es) for the clients that you wish to allow. Note that if an IP Address is found in the Allow list, the client will be allowed to connect, and the CCM will not check the Deny list.
  - a) **Text Interface:** Note the number for the first empty field in the Allow list, then type that number at the command prompt, press `[Enter]`, and then follow the instructions in the resulting submenu.
  - b) **Web Browser Interface:** Place the cursor in the first empty field in the parameters menu, then key in the desired IP Address, operators, wild cards, and/or net/mask pairs.
3. **Deny List:** Enter the IP Address(es) for the clients that you wish to deny. Note that if the client's IP Address is not found in the Deny List, that client will be allowed to connect.

### 5.9.3.2. Linux Operators and Wild Cards

In addition to entering a specific IP address or partial IP address in the Allow or Deny list, you may also use standard Linux operators or wild cards. In most cases, the only operator used is "EXCEPT" and the only wild card used is "ALL," but more experienced Linux users may note that other operators and wild cards may also be used.

**EXCEPT:** This operator creates an exception in either the "allow" list or "deny" list. For example, if the Allow list includes a line which reads "192. EXCEPT 192.255.255.6," then all IP address that begin with "192." will be allowed; except 192.255.255.6 (providing that this address appears in the Deny list.)

**ALL:** The ALL wild card indicates that all IP Addresses should be allowed or denied. When ALL is included in the Allow list, all IP addresses will be allowed to connect; conversely, if ALL is included in the Deny list, all IP Addresses will be denied (except for IP addresses listed in the Allow list.) For example, if the Deny list includes a line which reads "ALL EXCEPT 168.255.192.192," then all IP addresses except 168.255.192.192 will be denied (except for IP addresses that are listed in the Allow list.)

**Net/Mask Pairs:** An expression of the form "n.n.n.n/m.m.m.m" is interpreted as a "net/mask" pair. A host address is matched if "net" is equal to the bitwise AND of the address and the "mask." For example, the net/mask pattern "131.155.72.0/255.255.254.0" matches every address in the range "131.155.72.0" through "131.155.73.255."

### 5.9.3.3. IP Security Examples

1. **Mostly Closed:** Access is denied by default and the only clients allowed, are those explicitly listed in the Allow list. To deny access to all clients except 192.255.255.192 and 168.112.112.05, IP Security would be defined as follows:
  - Allow List:
    1. 192.255.255.192
    2. 168.112.112.05
  - Deny List:
    1. ALL
2. **Mostly Open:** Access is granted by default, and the only clients denied access, are those explicitly listed in the Deny list. To allow access to all clients except 192.255.255.192 and 168.112.112.05, the IP Security would be defined as follows:
  - Allow List:
    1. ALL EXCEPT 192.255.255.192, 168.112.112.05
  - Deny List:
    1. 192.255.255.192, 168.112.112.05

#### Notes:

- *When defining a line in the Allow or Deny list that includes several IP addresses, each individual address is separated by either a space, a comma, or a comma and a space as shown in Example 2 above.*
- *Take care when using the "ALL" wild card. When ALL is included in the Allow list, it should always include an EXCEPT operator in order to allow the unit to proceed to the Deny list and determine any addresses you wish to deny.*



#### 5.9.4. Static Route

The Static Route menu allows you to type in Linux routing commands that will be automatically executed each time that the unit powers up or reboots. In the Text Interface, the Static Route menu is accessed via the Network Configuration menu. In the Web Browser Interface, the Static Route menu is accessed via the flyout menus under the Network Configuration link. Note that parameters defined via this menu will be applied to both IPv4 and IPv6 communication.

#### 5.9.5. Domain Name Server

The DNS menu is used to select IPv4 or IPv6 format IP addresses for Domain Name Servers. When web and network addresses are entered, the Domain Name Server interprets domain names (e.g., www.wti.com), and translates them into IP addresses. In the Text Interface, the DNS menu is accessed via the Network Configuration menu. In the Web Browser Interface, the DNS menu is accessed via the flyout menus under the Network Configuration link. Note that if you don't define at least one DNS server, then IP addresses must be used, rather than domain names. Note that parameters defined via this menu will be applied to both IPv4 and IPv6 communication.

The Domain Name Server menu includes a Ping Test feature, that allows you to ping the IP addresses for each user-defined domain name server in order to check that a valid IP address has been entered.

**Note:** *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*

### 5.9.6. SNMP Access Parameters

These menus are used to select access parameters for the SNMP feature. The SNMP Access Parameters Menu allows the following parameters to be defined:

**Notes:**

- *After you have configured SNMP Access Parameters, you will then be able to manage the CCM's User Directory and display unit status via SNMP, as described in Section 13.*
- *In the Text Interface, SNMP Access Parameters are defined via two separate menus that are accessed via either the /**n** command (IPv4) or the /**n6** command (IPv6.)*
- *In the Web Browser interface, both IPv4 and IPv6 SNMP Access Parameters are defined via a single menu. When defining IPv6 parameters, make certain that the IPv6 checkbox in the SNMP Access Parameters menu is checked.*
- **Enable:** Enables/disables SNMP Polling. (Default = Off)
 

**Note:** *This item only applies to external SNMP polling of the CCM; it does not effect the ability of the CCM to send SNMP traps.*
- **Version:** Determines which SNMP Version the CCM will respond to. For example, if this item is set to V3, then clients who attempt to contact the CCM using SNMPv2 will not be allowed to connect. (Default = V1/V2 Only)
- **Read Only:** Enables/Disables the "Read Only Mode", which controls the ability to access configuration functions and invoke switching commands. When Enabled ("Yes"), you will not be able to change configuration parameters or invoke other commands when you contact the CCM via SNMP. (Default = No)
 

**Note:** *In order to define user names for the CCM via your SNMP client, the Read Only feature must be disabled. When the Read Only feature is enabled, you will not be able to issue configuration commands to the CCM unit via SNMP.*
- **Authentication / Privacy:** Configures the Authentication and Privacy features for SNMPv3 communication. The Authentication / Privacy parameter offers two options, which function as follows:
  1. **Auth/noPriv:** An SNMPv3 username and password will be required at log in, but encryption will not be used. (Default Setting.)
  2. **Auth/Priv:** An SNMPv3 username and password will be required at log in, and all messages will be sent using encryption.

**Notes:**

- *The Authentication / Privacy item is not available when the Version parameter is set to V1/V2.*
- *If the Version Parameter is set to V1/V2/V3 (all) and Authentication / Privacy parameter is set to "Auth/Priv", then only V3 data will be encrypted.*
- *The CCM does not support "noAuth/noPriv" for SNMPv3 communication.*

- **SNMPv3 User Name:** Sets the User Name for SNMPv3. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined)
- **SNMPv3 Password:** Sets the password for SNMPv3. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined)
- **SNMPv3 Password Confirm:** This prompt is used to confirm the SNMPv3 password that was entered at the prompt above. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined)
- **Authentication Protocol:** This parameter determines which authentication protocol will be used. The CCM supports both MD5 and SHA1 authentication. (Default = MD5)

**Notes:**

- *The Authentication Protocol that is selected for the CCM must match the protocol that your SNMP client will use when querying the CCM unit.*
- *The Authentication Protocol option is not available when the Version parameter is set to V1/V2*
- **SNMP Contact:** (Default = undefined)
- **SNMP Location:** (Default = undefined)
- **Read Only Community:** Note that this parameter is not available when the SNMP Version is set to V3. (Default = Public)
- **Read/Write Community:** Note that this parameter is not available when the SNMP Version is set to V3. (Default = Public)

### 5.9.7. SNMP Trap Parameters

These menus are used to select parameters that will be used when SNMP traps are sent. For more information on SNMP Traps, please refer to Section 12. In the Text Interface, the SNMP Trap Parameters menu is accessed via the Network Configuration menu. In the Web Browser Interface, the SNMP Trap Parameters menu is accessed via the flyout menus under the Network Configuration link. The SNMP Trap Parameters menu allows the following parameters to be defined:

**Notes:**

- *In the Text Interface, SNMP Trap parameters are defined via two separate menus that are accessed via either the /N command (IPv4) or the /N6 command (IPv6.)*
  - *In the Web Browser interface, SNMP Trap parameters are defined via two separate submenus that are accessed via the IPv4 or IPv6 flyout menus, under the SNMP Traps link.*
  - **SNMP Manager 1:** The IP Address for the first SNMP Manager. For more information, please refer to Section 12. (Default = Undefined)
- Note:** *In order to enable the SNMP Trap feature, you must define at least one SNMP Manager.*
- **SNMP Manager 2:** (Default = Undefined)
  - **Trap Community:** (Default = Public)
  - **Trap Version:** The assigned security level for SNMP traps. (Default = V1)
  - **V3 Trap Engine ID:** The V3 SNMP agent's unique identifier. (Default = undefined)
  - **Ping Test:** Allows you to ping the IP addresses or domain names defined via the SNMP Manager 1 and SNMP Manager 2 prompts in order to check that a valid IP address or domain name has been entered.

**Notes:**

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping the currently defined SNMP Managers in order to make certain that the IP addresses are responding.*

### 5.9.8. LDAP Parameters

The CCM supports LDAP (Lightweight Directory Access Protocol,) which allows authentication via the "Active Directory" network Directory Service. When LDAP is enabled and properly configured, command access rights can be granted to new users without the need to define individual new accounts at each CCM unit, and existing users can also be removed without the need to delete the account from each CCM unit. This type of authentication also allows administrators to assign users to LDAP groups, and then specify which plugs the members of each group will be allowed to control at each CCM unit.

In order to apply the LDAP feature, you must first define User Names and associated Passwords and group membership via your LDAP server, and then access the CCM command mode to configure LDAP settings and define port access rights and command access rights for each group specified at the LDAP server. To access the LDAP Parameters menu, login to CCM command mode using a password that permits Administrator level commands. In the Text Interface, the LDAP Parameters menu is accessed via the Network Configuration menu (/N for IPv4 parameters or /N6 for IPv6 parameters.) In the Web Browser Interface, both IPv4 and IPv6 parameters are defined via a single LDAP Parameters menu, which is accessed via the flyout menus under the Network Configuration link.

#### Notes:

- *Plug access rights are not defined at the LDAP server. They are defined via the LDAP Group configuration menu on each CCM unit and are specific to that CCM unit alone.*
- *When LDAP is enabled and properly configured, LDAP authentication will supersede any passwords and access rights that have been defined via the CCM user directory.*
- *If no LDAP groups are defined on a given CCM unit, then access rights will be determined as specified by the "default" LDAP group.*
- *The "default" LDAP group cannot be deleted.*

The LDAP Parameters Menu allows you to define the following parameters:

- **Enable:** Enables/disables LDAP authentication. (Default = Off)
- **Primary Host IPv4:** Defines the IP address or domain name for the primary LDAP server when IPv4 protocol is used to communicate with the CCM unit. (Default = undefined)
- **Primary Host IPv6:** Defines the IP address or domain name for the primary LDAP server when IPv6 protocol is used to communicate with the CCM unit. (Default = undefined)
- **Secondary Host IPv4:** Defines the IP address or domain name for the secondary (fallback) LDAP server when IPv4 protocol is used. (Default = undefined)
- **Secondary Host IPv6:** Defines the IP address or domain name for the secondary (fallback) LDAP server when IPv6 protocol is used. (Default = undefined)
- **LDAP Port:** Defines the port that will be used to communicate with the LDAP server. (Default = 389)

- **TLS/SSL:** Enables/Disables TLS/SSL encryption. Note that when TLS/SSL encryption is enabled, the LDAP Port should be set to 636. (Default = Off)
- **Bind Type:** Sets the LDAP bind request password type. In the Text Interface, when the Bind Type is set to "Kerberos," the LDAP menu will include an additional prompt used to select Kerberos parameters. In the Web Interface, Kerberos parameters are defined using the prompts at the bottom of the menu. (Default = Simple)
- **Search Bind DN:** The username that will be allowed to search the LDAP directory. (Default = undefined)
- **Search Bind Password:** The Password for the user who is allowed to search the LDAP directory. (Default = undefined)
- **User Search Base DN:** The directory location for user searches. (Default = undefined)
- **User Search Filter:** Selects the attribute that lists the user name. Note that this attribute should always end with "=%s" (no quotes.) (Default = undefined)
- **Group Membership Attribute:** Selects the attribute that list group membership(s). (Default = undefined)
- **Group Membership Value Type:** (Default = DN)
- **Fallback:** Enables/Disables the LDAP fallback feature. When enabled, the CCM will revert to it's own internal user directory if no defined users are found via the LDAP server. In this case, port access rights will then be granted as specified in the default LDAP group. (Default = Off)
- **Kerberos Setup:** Kerberos is a network authentication protocol, which provides a secure means of identity verification for users who are communicating via a non-secure network. In the Text Interface, Kerberos parameters are selected via a submenu that is only available when Kerberos is selected as Bind Type. In the Web Browser Interface, Kerberos parameters are defined via the main LDAP Parameters menu. The following parameters are available:
  - ◆ **Port:** (Default = 88)
  - ◆ **Realm:** (Default = Undefined)
  - ◆ **Key Distribution Centers (KDC1 through KDC5):** (Default = Undefined)
  - ◆ **Domain Realms 1 through 5:** (Default = Undefined)
- **LDAP Group Setup:** Provides access to a submenu, which is used to define LDAP Groups as described in the Sections 5.9.8.1 through 5.9.8.4.
- **Debug:** This option is used to assist WTI Technical Support personnel with the diagnosis of LDAP issues. (Default = Off)

- **Ping Test:** Allows you to ping IP addresses or domain names that have been defined via the LDAP Parameters menus in order to check that a valid IP address or domain name has been entered.

**Note:** *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*

**Notes:**

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

#### 5.9.8.1. Adding LDAP Groups

Once you have defined users and passwords via your LDAP server, and assigned users to LDAP Groups, you must then grant command and port access rights to each LDAP Group at each individual CCM unit. In order to Add an LDAP Group, you must access the CCM command mode using a password that permits Administrator Level commands. The Add LDAP Group menu allows the following to be defined:

- **Group Name:** Note that this name must match the LDAP Group names that you have assigned to users at your LDAP server. (Default = undefined)
- **Access Level:** Sets the command access level to either Administrator, SuperUser, User or ViewOnly. For more information on Access Levels, please refer to Section 5.4.1. (Default = User)
- **Port Access:** Enables/disables this LDAP Group's access to the serial Setup Port. (Default = Disabled)
- **Plug Access:** Determine which contacts/plug members of this group will be allowed to control. (Default = All Plugs Off)
- **Plug Group Access:** Determines which plug groups the members of this LDAP Group will be allowed to control. (Default = undefined)
- **Service Access:** Selects access methods for this LDAP Group. Determines whether members of this LDAP Group will be allowed to access command mode via Serial Port, Telnet/SSH, Web and/or to establish outbound connections. Also enables/disables Outbound Telnet. (Default; Serial Port = On, Telnet/SSH = On, Outbound Access = Off.)
- **Current/Power Metering:** (Applies to Switched AC Plug Only) Determines whether or not members of this LDAP Group will be allowed to view current, voltage and temperature readings.

**Note:** *After you have defined LDAP Group parameters, make certain to save changes before proceeding. In the Web Browser Interface, click on the "Add LDAP Group" button to save parameters; in the Text Interface, press the [Esc] key several times until the CCM displays the "Saving Configuration" message.*

### 5.9.8.2 Viewing LDAP Groups

If you need to examine an existing LDAP group definition, the "View LDAP Groups" function can be used to review the group's parameters and Plug Access Settings.

### 5.9.8.3. Modifying LDAP Groups

If you want to modify an existing LDAP Group in order to change parameters or plug access rights, the "Modify LDAP Group" function can be used to reconfigure group parameters. To Modify an existing LDAP Group, you must access the CCM command mode using a password that permits access to Administrator Level commands. Once you have accessed the Modify LDAP Group menu, use the menu options to redefine parameters in the same manner that is used for the Add LDAP Group menu, as discussed in Section 5.9.8.1.

**Note:** *After you have finished modifying LDAP Group parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Modify LDAP Group" button to save parameters; in the Text Interface, press the [Esc] key several times until the CCM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 5.9.8.4. Deleting LDAP Groups

The Delete LDAP Group function is used to delete LDAP Groups that are no longer in use. In order to Delete an existing LDAP Group, you must access the CCM command mode using a password that permits access to Administrator Level commands.



### 5.9.9. TACACS Parameters

The TACACS Configuration Menus offer the following options:

- **Enable:** Enables/disables the TACACS feature at the Network Port. (Default = Off)
- **Primary Address:** Defines the IP address or domain name (up to 64 characters) for your primary TACACS server. (Default = undefined)
- **Secondary Address:** Defines the IP address or domain name (up to 64 characters) for your secondary, fallback TACACS server (if present.) (Default = undefined)
- **Secret Word:** Defines the shared TACACS Secret Word for both TACACS servers. (Default = undefined)
- **Fallback Timer:** Determines how long the CCM will continue to attempt to contact the primary TACACS Server before falling back to the secondary TACACS Server. (Default = 15 Seconds)
- **Fallback Local:** Determines whether or not the CCM will fallback to its own password/username directory when an authentication attempt fails. When enabled, the CCM will first attempt to authenticate the password by checking the TACACS Server; if this fails, the CCM will then attempt to authenticate the password by checking its own internal username directory. This parameter offers three options:
  - ◆ **Off:** Fallback Local is disabled (Default.)
  - ◆ **On (All Failures):** Fallback Local is enabled, and the unit will fallback to its own internal user directory when it cannot contact the TACACS Server, or when a password or username does not match the TACACS Server.
  - ◆ **On (Transport Failure):** Fallback Local is enabled, but the unit will only fallback to its own internal user directory when it cannot contact the TACACS Server.
- **Authentication Port:** The port number for the TACACS function. (Default = 49)
- **Default User Access:** When enabled, this parameter allows TACACS users to access the CCM command mode without first defining a TACACS user account on the CCM. When new TACACS users access the CCM command mode, they will inherit the default Access Level, Port Access, Plug Access, Plug Group Access, Service Access and Current/Power Metering parameters that are defined via the items listed below: (Default = On)
  - **Enable:** Enables/disables the Default User Access function. (Default = On)
  - **Access Level:** Determines the default Access Level setting for new TACACS users. This option can set the default access level for new TACACS users to "Administrator", "SuperUser", "User" or "ViewOnly." For more information on Command Access Levels, please refer to Section 5.4.1 and Section 17.2. (Default = User)
  - **Port Access:** Determines the default Port Access setting for new TACACS users. The Port Access setting determines whether or not the account will be allowed to connect to the serial Setup Port. (Defaults; Administrator and SuperUser = Always Enabled, User = Disabled)

**Note:** *ViewOnly level accounts cannot be granted access to the Setup Port.*

- **Plug Access:** Determines the default contact/plug access setting for new TACACS users. (Defaults; Administrator and SuperUser = All Switched Contacts and Switched Outlet On, User = All Switched Contacts and Switched Plug Off, ViewOnly = All Switched Contacts and Switched Plug Off)

**Notes:**

- Administrator and SuperUser level accounts always have access to all Switched Contacts plus the Switched Plug.
- User level accounts will only have access to the contacts and/or switched plug defined via the "Plug Access" parameter.
- ViewOnly accounts are not allowed to invoke switching and reboot commands.

- **Plug Group Access:** Determines the default Plug Group Access setting for new TACACS users. For more information on Plug Groups, please refer to Section 5.6. (Defaults; Administrator and SuperUser = All Plug Groups On, User = All Plug Groups Off, ViewOnly = All Plug Groups Off)

**Notes:**

- In order to use this feature, at least one Plug Group must first be defined as described in Section 5.6.
- Administrator and SuperUser level accounts will always have access to all plug groups.
- User Level accounts will only have access to the plug groups that are defined via the Plug Group Access parameter.
- ViewOnly accounts are not allowed to invoke switching and reboot commands.

- **Service Access:** Selects the default Service Access setting for new TACACS users. The Service Access setting determines whether each account will be able to access command mode via Serial Port, Telnet/SSH or Web. For example, if Telnet/SSH Access is disabled for an account, then the account will not be able to access command mode via Telnet or SSH. (Default = Serial Port = On, Telnet/SSH = On, Web = On)

- **Current/Power Metering:** (Applies to Switched AC Plug Only) Selects the default enable/disable status for the Current/Power Metering setting for the Switched AC Plug. When Current/Power Metering is disabled, an account will not be able to view current or power readings or display current or power history. Note that in order for accounts to be able to display these logs, Current and Power Metering must be enabled via the Systems Parameters menu as described in Section 5.3. (Default = On)

- **Ping Test (Ping TACACS Servers):** Allows you to ping IP addresses or domain names that have been defined via the TACACS Parameters menus in order to check that a valid IP address or domain name has been entered.

**Note:** In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.

### 5.9.10. RADIUS Parameters

In the Text Interface, the RADIUS Parameters menu is accessed via the Network Configuration menu (/N for IPv4 parameters or /N6 for IPv6 parameters.) In the Web Browser Interface, both IPv4 and IPv6 parameters are defined via a single RADIUS Parameters menu, which is accessed via the flyout menus under the Network Configuration link. The RADIUS Configuration Menus offer the following options:

- **Enable:** Enables/Disables the RADIUS feature at the Network Port. (Default = Off)
- **Primary Address IPv4:** Defines the IP address or domain name for your primary RADIUS server when IPv4 protocol is used. (Default = undefined)
- **Primary Address IPv6:** Defines the IP address or domain name for your primary RADIUS server when IPv6 protocol is used. (Default = undefined)
- **Primary Secret Word:** Defines the RADIUS Secret Word for the primary RADIUS server. (Default = undefined)
- **Secondary Address IPv4:** Defines the IP address or domain name for your secondary, fallback RADIUS server when IPv4 protocol is used. (Default = undefined)
- **Secondary Address IPv6:** Defines the IP address or domain name for your secondary, fallback RADIUS server when IPv6 protocol is used. (Default = undefined)
- **Secondary Secret Word:** Defines the RADIUS Secret Word for the secondary RADIUS server. (Default = undefined)
- **Fallback Timer:** Determines how long the CCM will continue to attempt to contact the primary RADIUS Server before falling back to the secondary RADIUS Server. (Default = 3 Seconds)
- **Fallback Local:** Determines whether or not the CCM will fallback to its own password/username directory when an authentication attempt fails. When enabled, the CCM will first attempt to authenticate the password by checking the RADIUS Server; if this fails, the CCM will then attempt to authenticate the password by checking its own internal username directory. This parameter offers three options:
  - ◆ **Off:** Fallback Local is disabled (Default.)
  - ◆ **On (All Failures):** Fallback Local is enabled, and the unit will fallback to its own internal user directory when it cannot contact the Radius Server, or when a password or username does not match the Radius Server.
  - ◆ **On (Transport Failure):** Fallback Local is enabled, but the unit will only fallback to its own internal user directory when it cannot contact the Radius Server.
- **Retries:** Determines how many times the CCM will attempt to contact the RADIUS server. Note that the retries parameter applies to both the Primary RADIUS Server and the Secondary RADIUS Server. (Default = 3)
- **Authentication Port:** The Authentication Port number for the RADIUS function. (Default = 1812)

- **Accounting Port:** The Accounting Port number for the RADIUS function. (Default = 1813)
- **Debug:** (Text Interface Only) When enabled, the CCM will put RADIUS debug information into Syslog. (Default = Off)
- **Ping Test:** Allows you to ping IP addresses or domain names that have been defined via the RADIUS Parameters menus in order to check that a valid IP address or domain name has been entered.

**Note:** *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*

#### 5.9.10.1. Dictionary Support for RADIUS

The RADIUS dictionary file allows you to define users and assign command access rights and power control access rights from a central location. The RADIUS dictionary file, "dictionary.wti" is included on the CDROM along with this user's guide. To install the dictionary file on your RADIUS server, refer to the documentation provided with your server; some servers require the dictionary file to reside in a specific directory, others require the dictionary file to be appended to an existing RADIUS dictionary file. The WTI RADIUS dictionary file provides the following commands: .

- **WTI-Super** - Sets the command access level for the user. This command provides the following arguments:
  - 0 = ViewOnly
  - 1 = User
  - 2 = SuperUser
  - 3 = Administrator

For example, to set the access level to "SuperUser", the command line would be:

```
WTI-Super="2"
```

- **WTI-Plug-Access** - Determines which contacts/plug the user will be allowed to control. This command provides an argument that consists of a character string, with one character for the CCM's switched plug and switched contacts. The following options are available:
  - 0 = Off (Deny Access)
  - 1 = On (Allow Access)

For example, to allow access to contacts 1 and 3, the command would be:

```
WTI-Plug-Access="01010"
```

- **WTI-Group-Access** - Determines which plug group(s) the user will be allowed to access. The argument for this command includes a character for each, defined plug group. The first character in the string is used to represent the first plug group defined, and the last character in the string represents the last plug group defined. The following options are available for each plug group:

0 = Off (Deny Access)  
1 = On (Allow Access)

For example, to allow access to the first three defined plug groups out of a total of six defined plug groups, the command line would be:

**WTI-Group-Access="111000"**

**Example:**

The following command could be used to set the command access level to "User", allow access to the switched plug, plus contacts 1 and 4, and also allow access to the first two of five defined plug groups:

```
tom Auth-Type:=Local, User-Password=="tom1"  
Login-Service=Telnet,  
Login-TCP-Port=Telnet,  
User-Name="HARRY-tom",  
WTI-Super="1",  
WTI-Plug-Access="11004",  
WTI-Group-Access="11000",
```

### 5.9.11. Email Messaging Parameters

The Email Messaging menu is used to define parameters for email messages that the CCM can send to notify you when an alarm is triggered. To define email message parameters, you must access the CCM Command Mode using a password that permits access to Administrator Level commands and then proceed as follows:

- **Text Interface:** Type `/N` (for IPv4 parameters) or `/N6` (for IPv6 parameters) and press **[Enter]** to access the Network Configuration Menu. Key in the number for the Email Messaging option and press **[Enter]** to display the Email Messaging Menu.
- **Web Browser Interface:** Place the cursor over the "Network Configuration" link on the left hand side of the screen. When the fly-out menu appears select either the link for IPv4 parameters or IPv6 parameters to display the Email Messaging Menu.

The Email Messaging menu offers the following options:

- **Enable:** Enables/Disables the Email Messaging feature. When disabled, the CCM will not be able to send email messages when an alarm is generated. (Default = On)
- **SMTP Server:** This prompt is used to define the address of your SMTP Email server. (Default = undefined)
- **Port Number:** Selects the TCP/IP port number that will be used for email connections. (Default = 25)
- **Domain:** The domain name for your email server. (Default = undefined)  
**Note:** *In order to use domain names, you must first define Domain Name Server parameters as described in Section 5.9.5.*
- **User Name:** The User Name that will be entered when logging into your email server. (Default = undefined)
- **Password:** The password that will be used when logging into your email server. (Default = undefined)
- **Auth Type:** The Authentication type; the CCM allows you to select None, Plain, Login, or CRAM-MD5 Authentication. (Default = Plain)
- **From Name:** The name that will appear in the "From" field in email sent by the CCM. (Default = undefined)
- **From Address:** The email address that will appear in the "From" field in email sent by the CCM. (Default = undefined)
- **To Address:** The address(es) that will receive email messages generated by the CCM. Note that up to three "To" addresses may be defined, and that when Alarm Configuration parameters are selected as described in Section 7, you may then designate one, two or all three of these addresses as recipients for email messages that are generated by the alarms. (Default = undefined)
- **Send Test Email:** Sends a test email, using the parameters that are currently defined for the Email configuration menu.

## 5.10. Save User Selected Parameters

It is strongly recommended to save all user-defined parameters to an ASCII file as described in Section 15. This will allow quick recovery in the event of accidental deletion or reconfiguration of port parameters.

When changing configuration parameters via the Text Interface, make certain that the CCM has saved the newly defined parameters before exiting from command mode. To save parameters, press the **[Esc]** key several times until you have exited from all configuration menus and the CCM displays the "Saving Configuration" menu and the cursor returns to the command prompt. If newly defined configuration parameters are not saved prior to exiting from command mode, then the CCM will revert to the previously saved configuration after you exit from command mode.

### 5.10.1. Restore Configuration

If you make a mistake while configuring the CCM unit, and wish to return to the previously saved parameters, the Text Interface's "Reboot System" command (**/I**) offers the option to reinitialize the unit using previously backed up parameters. This allows you to reset the unit to previously saved parameters, even after you have changed parameters and saved them.

#### Notes:

- *The CCM will automatically backup saved parameters once a day, shortly after Midnight. This configuration backup file will contain only the most recently saved CCM parameters, and will be overwritten by the next night's daily backup.*
- *When the **/I** command is invoked, a submenu will be displayed which offers several Reboot options. Option 5 is used to restore the configuration backup file. The date shown next to option 5 indicates the date that you last changed and saved unit parameters.*
- *If the daily automatic configuration backup has been triggered since the configuration error was made, and the previously saved configuration has been overwritten by newer, incorrect parameters, then this function will not be able to restore the previously saved (correct) parameters.*

To restore the previously saved configuration, proceed as follows:

1. Access command mode via the Text Interface, using a username/password that permits access to Administrator level commands (see Section 5.1.1.)
2. At the CCM command prompt, type **/I** and press **[Enter]**. The CCM will display a submenu that offers several different reboot options.
3. At the submenu, choose Item 5 (Reboot & Restore Last Known Working Configuration). Key in the number for the desired option, and then press **[Enter]**.
4. The CCM will reboot and previously saved parameters will be restored.

## 6. Reboot Options

In addition to performing reboot cycles in response to commands, the CCM can also be configured to automatically reboot the switched plug and switched contact when an attached device does not respond to a Ping command (Ping-No-Answer Reboot) or according to a user defined schedule (Scheduled Reboot.)

- **Ping-No-Answer Reboot:** When the Ping-No-Answer feature is enabled, the CCM will Ping a user selected IP address at regular intervals. If the IP address does not respond to the Ping command, the CCM will reboot the Switched Plug and/or one or more user selected Switched Contact. Typically, this feature is used to reboot devices when they cease to respond to the Ping command.
- **Scheduled Reboot:** A scheduled reboot is used to initiate a reboot cycle at a user selected time and day of the week. When properly configured and enabled, the CCM will reboot the Switched Plug and/or one or more user selected Switched Contacts on a daily or weekly basis. The Scheduled Reboot feature can also be used to switch plug/contacts Off at a user selected time, and then switch them back On again at a later, user selected time.

This section describes the procedure for configuring and enabling Ping-No-Answer Reboots and Scheduled Reboots.

**Note:** *When defining parameters via the Text Interface, make certain to press the [Esc] key to completely exit from the configuration menus and save newly defined parameters. When parameters are defined via the Text Interface, newly defined parameters will not be saved until the "Saving Configuration" message is displayed.*



## 6.1. Ping-No-Answer Reboot

A Ping-No-Answer Reboot can be used to reboot the Switched Plug and/or one or more user-selected Switched Contacts when an attached device does not respond to a Ping Command. In addition, the Ping-No-Answer Reboot feature can also be configured to send an email, Syslog Message or SNMP Trap to notify you whenever a Ping-No-Answer Reboot occurs. Please refer to Section 7.4 for instructions on setting up email alarm notification for Ping-No-Answer reboots.

To set up a Ping-No-Answer Reboot, you must access command mode using a password that permits Administrator level commands. In the Text Interface, the Ping-No-Answer configuration menu is accessed via the Reboot Options menu (/RB). In the Web Browser Interface, the Ping-No-Answer configuration menu is accessed via the Reboot Options link. The Ping-No-Answer configuration menu can be used to Add, Modify, View or Delete Ping-No-Answer Reboot functions.

**Note:** *In order for the Ping-No-Answer Reboot feature to work properly, your network and/or firewall, as well as the device at the target IP address must be configured to allow ping commands.*

### 6.1.1. Adding Ping-No-Answer Reboots

Up to 54 Ping-No-Answer Reboots can be defined. The Add Ping-No-Answer menu is used to define the following parameters for each new Ping-No-Answer Reboot:

- **IP Address or Domain Name:** The IP address or Domain Name for the device that you wish to Ping. When the device at this address fails to respond to the Ping command, the CCM will reboot the selected plugs. (Default = undefined)

**Notes:**

- *In order to use domain names, DNS Server parameters must first be defined as described in Section 5.9.5.*
  - *In the Text Interface, a submenu will be displayed that allows the user to choose either IPv4 protocol or IPv6 protocol.*
  - *In the Web Browser Interface, the Add Ping-No-Answer Reboot menu includes a menu item that is used to select IPv4 protocol or IPv6 protocol.*
  - **Ping Interval:** Determines how often the Ping command will be sent to the selected IP Address. The Ping Interval can be any whole number, from 1 to 3,600 seconds. (Default = 60 Seconds)
- Note:** *If the Ping Interval is set lower than 20 seconds, it is recommended to define the "IP Address or Domain Name" parameter using an IP Address rather than a Domain Name. This ensures more reliable results in the event that the Domain Name Server is unavailable.*
- **Interval After Failed Ping:** Determines how often the Ping command will be sent after a previous Ping command receives no response. (Default = 10 Seconds)

- **Ping Delay After PNA Action:** Determines how long the CCM will wait to send additional Ping commands, after a Ping-No-Answer Reboot has been initiated. Typically, this option is used to allow time for a device to fully "wake up" after a Ping-No-Answer Reboot before attempting to Ping the device again. (Default = 15 Minutes)
- **Consecutive Failures:** Determines how many consecutive failures of the Ping command must be detected in order to initiate a Ping-No-Answer Reboot. For example, if this value is set to "3", then after three consecutive Ping failures, a Ping-No-Answer Reboot will be performed. (Default = 5)
- **Reboot:** Enables/Disables the Ping-No-Answer Reboot function for the specified IP address. When this item is disabled, the CCM will not reboot the specified plug and/or contacts when a Ping-No-Answer is detected. However, the CCM can continue to notify you via Email, Syslog Message and/or SNMP Trap, providing that parameters for these functions have been defined as described in Section 5.9 and email notification for the Ping-No-Answer function has been enabled as described in Section 7.4. (Default = No)

**Notes:**

- *In order for Email/Text Message Notification to function, you must first define Email/Text Message parameters as described in Section 5.9.11.*
- *In order for Syslog Message Notification to function, you must first define a Syslog Address as described in Section 5.9.2.*
- *In order for SNMP Trap Notification to function, you must first define SNMP parameters as described in Section 5.9.7.*
- **PNA Action:** Determines how the CCM will react when the IP address fails to respond to a ping. The CCM can either continuously reboot the specified plug/contacts and send notification until the IP address responds and the Ping-No-Answer Reboot is cleared (Continuous Alarm/Reboot), or the CCM can reboot the specified plug/contacts and send notification only once each time the Ping-No-Answer Reboot is initially triggered (Single Alarm/Reboot.) (Default = Continuous Alarm/Reboot)
- **Plug Access:** Determines which switched plug/contacts will be rebooted when the IP address for this Ping-No-Answer operation does not respond to a Ping command. Note that in the Text Interface, Plug Access is defined via a separate submenu; in the Web Browser Interface, Plug Access is defined via a drop down menu, accessed by clicking on the "plus" sign in the "Configure Plug Access" field. (Default = undefined)
- **Plug Group Access:** Determines which Plug Group(s) the Ping-No-Answer Reboot for this IP Address will be applied to. Note that in the Text Interface, Plug Group Access is defined via a separate submenu; in the Web Browser Interface, Plug Group Access is defined via a drop down menu, which may be accessed by clicking on the "plus" sign. (Default = undefined)

- **Ping Test:** Sends a test Ping command to the IP Address defined for this Ping-No-Answer Reboot.

**Notes:**

- *In order for the Ping Test function to work properly, your network and/or firewall as well as the device at the target IP address must be configured to allow ping commands.*
- *After you have finished defining or editing Ping-No-Answer Reboot parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Add Ping No Answer" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the MPC displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### **6.1.2. Viewing Ping-No-Answer Reboot Profiles**

After you have defined one or more Ping-No-Answer Reboot profiles, you can review the parameters selected for each profile using the View Ping-No-Answer feature. In order to view the configuration of an existing Ping-No-Answer profile, you must access command mode using a password that allows Administrator level commands and then use the Ping-No-Answer menu's "View/Modify Ping-No-Answer" function.

### **6.1.3. Modifying Ping-No-Answer Reboot Profiles**

After you have defined a Ping-No-Answer profile, you can modify the configuration of the profile using the Modify Ping-No-Answer feature. In order to modify the configuration of an existing Ping-No-Answer profile, you must access the command mode using a password that allows Administrator level commands and then use the Ping-No-Answer menu's "View/Modify Ping-No-Answer" function.

The CCM will display a screen which allows you to modify parameters for the selected Ping-No-Answer Reboot Profile. Note that this screen functions identically to the Add Ping-No-Answer Reboot menu, as discussed in Section 6.1.1.

**Note:** *After you have finished defining or editing Ping-No-Answer Reboot parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Change Ping No Answer" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the CCM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### **6.1.4. Deleting Ping-No-Answer Reboot Profiles**

After you have defined one or more Ping-No-Answer profiles, you can delete profiles that are no longer needed using the Delete Ping-No-Answer feature. In order to delete an existing Ping-No-Answer profile, you must access the command mode using a password that allows Administrator level commands and then use the Ping-No-Answer menu's "Delete Ping-No-Answer" function.

## 6.2. Scheduled Reboot

The Scheduled Reboot feature can be used to reboot the Switched AC Plug plus one or more user-selected Switched Contacts according to a user-defined schedule, or to automatically turn the Switched AC Plug and/or Switched Contacts Off and then On according to a user defined schedule.

In order to configure a Scheduled Reboot, you must access command mode using a password that permits access to Administrator level commands. In the Text Interface, the Scheduled Reboot configuration menu is accessed via the Reboot Options menu (/RB). In the Web Browser Interface, the Scheduled Reboot configuration menu is accessed via the Reboot Options link. The Scheduled Reboot configuration menu can be used to Add, Modify, View or Delete Scheduled Reboot functions.

**Note:** *After you have finished defining or editing Scheduled Reboot parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Add Scheduled Reboot" button to save parameters; in the Text Interface, press the [Esc] key several times until the CCM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

### 6.2.1. Adding Scheduled Reboots

The CCM allows up to 54 individual Scheduled Reboots to be defined. The Add Scheduled Reboot menu allows you to define the following parameters for each new Scheduled Reboot:

- **Scheduled Reboot Name:** Assigns a name to this Scheduled Reboot. (Default = undefined)
- **Plug Action:** Determines whether the Scheduled Reboot will result in the plug and/or contacts being switched Off, or cycled Off and then On again (Reboot.) Note that when "Off" is selected, the "Day On" option and the "Time On" option can be used to select a time and day when the plug/contact will be switched back On again. (Default = Off)
- **Time:** Determines the time of the day that this Scheduled Reboot will occur on. (Default = 12:00)
- **Day Access:** This prompt provides access to a submenu which is used to determine which day(s) of the week this Scheduled Reboot will be performed. The Day Access parameter can also be used to schedule a daily reboot; to schedule a daily reboot, use the Day Access submenu to select every day of the week. (Default = undefined)

**Note:** *If you wish to Schedule the CCM to switch a plug or contact On at one time and then switch the plug or contact Off at another time, you must define two separate scheduled actions. The first action would be used to switch the plug or contact On, and the second action would be used to switch the plug or contact Off.*

- **Plug Access:** Determines which plug/contacts this Scheduled Reboot action will be applied to. (Default = undefined)
- **Plug Group Access:** Determines which Plug Group(s) this Scheduled Reboot action will be applied to. Note that in the Text Interface, Plug Group Access is defined via a separate submenu; in the Web Browser Interface, Plug Group Access is defined via a drop down menu, which may be accessed by clicking on the "plus" sign in the Plug Group Access field. (Default = undefined)

### **6.2.2. Viewing Scheduled Reboot Actions**

After you have defined one or more Scheduled Reboots, you can review the parameters selected for each Reboot using the View Scheduled Reboot feature. In order to view the configuration of an existing Scheduled Reboot, you must access the command mode using a password that allows Administrator level commands and then use the Scheduled Reboot menu's "View/Modify Scheduled Reboot" function.

The CCM will display a screen which lists all defined parameters for the selected Scheduled Reboot action.

### **6.2.3. Modifying Scheduled Reboots**

After you have defined a Scheduled Reboot, you can edit the configuration of the Reboot action using the Modify Scheduled Reboot feature. In order to modify the configuration of an existing Scheduled Reboot action, you must access the command mode using a password that allows Administrator level commands and then use the Scheduled Reboot menu's "View/Modify Scheduled Reboot" function.

The CCM will display a screen which allows you to modify parameters for the selected Scheduled Reboot action. Note that this screen functions identically to the Add Scheduled Reboot menu, as discussed in Section 6.2.1.

### **6.2.4. Deleting Scheduled Reboots**

After you have defined one or more Scheduled Reboot actions, you can delete Reboot actions that are no longer needed using the Delete Scheduled Reboot feature. In order to delete an existing Scheduled Reboot, access the command mode using a password that allows Administrator level commands and then use the Scheduled Reboot menu's "Delete Scheduled Reboot" function.

## 7. Alarm Configuration

When properly configured, CCM units can monitor rack temperature, ping command response and other factors at network installation sites. In addition to the monitoring abilities listed above, the CCM's Switched Plug can also meter and record current, power and voltage conditions. Note however that the Switched Contacts do not support current consumption, power and voltage monitoring functions.

If user defined trigger levels for temperature are exceeded, the CCM can also perform load shedding; automatically shutting off user-designated power plugs and contacts in order to reduce the amount of heat generated in the rack. When rack temperatures return to acceptable levels, the CCM can then switch the plug or contacts back on again. The CCM can also perform load shedding when current consumption rises above user-defined threshold values. When any of the user-defined alarms are triggered, the CCM can send an alarm message to the proper personnel via Email, Syslog Message or SNMP trap.

This section describes the procedure for setting up the CCM to send alarm messages when critical situations are detected. For instructions regarding configuration of the Log function, please refer to Section 5.3.3.

### Notes:

- *Current and Power Monitoring features are not available on the switched contacts.*
- *In order to send alarm notification via email, email addresses and parameters must first be defined. Email alarm notification will then be sent for all alarms that are enabled as described in this Section.*
- *In order to send alarm notification via Syslog Message, a Syslog address must first be defined. Once the Syslog address has been defined, Syslog Messages will be sent for every alarm discussed in this Section, providing that the Trigger Enable parameter for the alarm has been set to "On."*
- *In order to send alarm notification via SNMP Trap, SNMP Trap parameters must first be defined. Once SNMP Trap Parameters have been defined, SNMP Traps will be sent for every alarm discussed in this Section, providing that the Trigger Enable parameter for the alarm has been set to "On."*
- *When defining parameters via the Text Interface, make certain to press the **[Esc]** key to completely exit from the configuration menu and save newly defined parameters. When parameters are defined via the Text Interface, newly defined parameters will not be saved until the "Saving Configuration" message is displayed.*

To configure the CCM Alarm functions, access command mode using a password that allows Administrator level commands and then activate the Alarm Configuration menu (in the Text Interface, type `/AC` and press **[Enter]**; in the Web Browser Interface, click on the "Alarm Configuration" link.)

## 7.1. The Over Current Alarms (Switched Plug Only)

The Over Current Alarms are designed to inform you when current consumption reaches or exceeds user-defined levels.

- The Over Current (Initial) Alarm
- The Over Current (Critical) Alarm

**Note:** *Current and Power Monitoring features are not available on the switched contacts.*

The Initial alarm is used to provide notification when the level of current consumption reaches a point where you *might* want to investigate, whereas the Critical alarms can provide notification when the level of current consumption approaches the maximum allowed level. The trigger levels for the Initial alarms are generally set lower than the trigger levels for the Critical alarms.

If user-defined trigger levels for current load at the Switched Plug are exceeded, the CCM can automatically shut off power to non-essential devices ("Load Shedding") in order to decrease current load. After Load Shedding has taken place, the CCM can also restore power to the non-essential devices when current load drops to user-defined acceptable levels.

### Notes:

- *In order for the CCM to provide alarm notification via Email, communication parameters must first be defined.*
- *In order for the CCM to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled.*
- *In order for the CCM to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled.*

To configure the Over Current Alarms, access the CCM command mode using a password that permits Administrator Level commands, and then use the Alarm Configuration menu to select the desired alarm feature.

Note that the configuration menus for both Over Current Alarms offer essentially the same set of parameters, but the parameters defined for each alarm are separate. Therefore, parameters defined for a Critical Alarm will not be applied to an Initial Alarm and vice versa. The Current Alarm Configuration menus offer the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

### Notes:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all CCM alarms. For example, if the Over Current Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers)", then the triggers for all other CCM alarms will also be enabled.*

- **Alarm Set Threshold:** The trigger level for this alarm. When current load exceeds the Alarm Set Threshold, the CCM can send an alarm and/or begin load shedding (if enabled.) Note that the Alarm Set Threshold is entered as a percentage of maximum capacity. (Defaults: Initial = 80%; Critical = 90%)
- **Alarm Clear Threshold:** Determines how low the current load must drop in order for the Alarm condition to be cancelled and for load shedding recovery (if enabled) to occur. The Alarm Clear Threshold is entered as a percentage of maximum capacity. (Defaults: Initial Alarms = 70%; Critical Alarms = 80%)
- **Resend Delay:** Determines how long the CCM will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)
- **Notify Upon Clear:** When this item is enabled, the CCM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the CCM will first send notification when it detects that current consumption has exceeded the trigger value, and then send a second notification when it determines that the current consumption has fallen below the trigger value. (Default = On)
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 5.9.11) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)  
  
**Note:** *If Email addresses have been previously defined, then the text under the parameters will list the current, user selected email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by the alarm. (Defaults = "Alarm: Over Current (Initial)" or "Alarm: Over Current (Critical)")
- **Load Shedding:** Provides access to a submenu which is used to configure and enable the Load Shedding feature for the Over Current Alarm as described in Section 7.1.1. When Load Shedding is enabled and properly configured, the CCM can switch the Switched Plug (A1) and/or one or more switched contacts whenever the current load exceeds the Alarm Set Threshold value. If Auto Recovery is enabled, the CCM can also return the Switched Plug and Switched Contacts to their prior status when current load falls below the Alarm Clear Threshold value.



### 7.1.1. Over Current Alarms - Load Shedding and Auto Recovery

The Load Shedding feature is used to switch the Switched Plug and/or one or more of the Switched Contacts On or Off whenever current load exceeds the Alarm Set Threshold value. This allows the CCM to automatically shut Off plugs in order to reduce current load when the load approaches user-defined critical levels. When Auto Recovery is enabled, the CCM can also automatically "undo" the effects of Load Shedding if the current load again falls to a user-defined non-critical level.

Together, the Load Shedding and Auto Recovery features allow the CCM to shut off power to non-essential devices when the current load is too high, and then switch those same non-essential devices back On again when the load falls to an acceptable level.

The Load Shedding Configuration Menus allow you to define the following parameters:

#### Notes:

- *Current and Power Monitoring features are not available on the switched contacts.*
- *The Load Shedding Configuration Menus for all Over Current Alarms offer essentially the same set of parameters, but parameters defined for each alarm are separate and unique. For example, parameters defined for Over Current (Initial) Alarm Load Shedding will not be applied to Over Current (Critical) Alarm Load Shedding and vice versa.*
- *The "Unit to Configure," "Branch A," "Branch B" and "Line" parameters are used to determine which unit or branch Load Shedding will be applied. These parameters do not apply to some CCM models.*
- **Line Input:** Provides access to a submenu that is used to define Load Shedding actions that will be executed when an Over Current Alarm is triggered.

Use the following parameters to configure Load Shedding functions:

- **Enable:** Enables/Disables Load Shedding for the corresponding alarm. When enabled, the CCM will switch the Switched Plug and/or one or more Switched Contacts whenever current load exceeds the Alarm Set Threshold value. (Default = Disable)
- **Plug State:** Determines whether the Switched Plug and/or one or more Switched Contacts or plug groups will be switched On or Off when Load Shedding is enabled and current load exceeds the user-defined Alarm Set Threshold. (Default = Off)
- **Auto Recovery:** Enables/Disables the Auto Recovery feature. When both Load Shedding and Auto Recovery are enabled, the CCM will return the Switched Plug and/or Switched Contacts to their former On/Off state after current load falls below the Alarm Clear Threshold value. This allows the CCM to "undo" the effects of Load Shedding after current load has returned to an acceptable level. (Default = Off)

- **Plug Access:** This parameter is used to select the Switched Plug and/or one or more Switched Contacts which will be switched when current load exceeds the Alarm Set Threshold and Load Shedding is triggered. For example, Switched Contacts 2 and 3 are selected, then these contacts will be switched On or Off whenever current load exceeds the Alarm Set Threshold. (Default = undefined)
- **Plug Group Access:** Determines which Plug Group(s) will be switched when the Load Shedding feature is triggered. (Default = undefined)

**Note:** *Plug Groups must first be defined before they will be displayed in the Load Shedding menu's Plug Group Access submenu.*

## 7.2. The Over Temperature Alarms

The Over Temperature Alarms are designed to inform you when the temperature level inside your equipment rack reaches or exceeds user-defined threshold levels. There are two separate Over Temperature Alarms; the Initial Threshold Alarm and Critical Threshold Alarm.

Typically, the Initial Threshold alarm is used to provide notification when temperatures within your equipment rack reach a point where you *might* want to investigate, whereas the Critical Threshold alarm is used to provide notification when temperatures approach a level that may harm equipment or inhibit performance. The trigger for the Initial Threshold Alarm is generally set lower than the Critical Threshold Alarm.

If user-defined trigger levels for temperature are exceeded, the CCM can automatically shut off power to non-essential devices ("Load Shedding") in order to reduce the amount of temperature generated within the rack. In addition, Load Shedding can also be used to switch On additional components, such as fans or cooling systems in order to dissipate excess heat. After Load Shedding has taken place, the Load Shedding Recovery feature can be used to return plugs/contacts to their previous state after temperatures drop to an acceptable level.

### Notes:

- *In order for the unit to provide alarm notification via Email, communication parameters must first be defined.*
- *In order for the unit to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled.*
- *In order for the unit to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled.*

To configure the Over Temperature Alarms, access the CCM command mode using a password that permits Administrator Level commands, and then use the Alarm Configuration menu to select the desired alarm feature.

Both the Initial Threshold menus and Critical Threshold menus offer essentially the same parameters, but the parameters defined for each alarm are separate. Therefore, parameters defined for the Critical Threshold Alarm will not be applied to the Initial Threshold Alarm and vice versa. Both the Over Temperature (Initial Threshold) alarm and the Over Temperature (Critical Threshold) alarm offer the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all CCM alarms. For example, if the Over Temperature Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers)", then all other CCM alarms will also be enabled.*

- **Alarm Set Threshold:** The trigger level for this alarm. When temperature exceeds the Alarm Set Threshold, the CCM can send an alarm message (if enabled) and/or begin Load Shedding (if enabled.) For more information, please refer to Section 7.2.1. (Initial Threshold: Default = 90°F or 32°C, Critical Threshold: Default = 100°F or 38°C)
- **Alarm Clear Threshold:** Determines how low the temperature must drop in order for the Alarm condition to be cancelled and for Load Shedding Recovery (if enabled) to occur. For more information, please refer to Section 7.2.1. (Initial Threshold: Default = 80°F or 27°C, Critical Threshold: Default = 90°F or 38°C)

**Note:** *The System Parameters menu is used to set the temperature format for the CCM unit to either Fahrenheit or Celsius.*

- **Resend Delay:** Determines how long the CCM will wait to resend an email message generated by this alarm when the initial attempt to send notification was unsuccessful. (Default = 60 Minutes)
- **Notify Upon Clear:** When this item is enabled, the CCM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the CCM will send initial notification when it detects that the temperature has exceeded the trigger value, and then send a second notification when it determines that the temperature has fallen below the trigger value. (Default = On)
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses, defined via the "Email Messages" menu will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)

**Note:** *If Email addresses have been previously defined, then the text under the parameters will list the current, user defined email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Over Temperature (Initial)" or "Alarm: Over Temperature (Critical)")
- **Load Shedding:** Provides access to a submenu, which is used to configure and enable Load Shedding for the Over Temperature alarms. When Load Shedding is enabled and properly configured, the CCM will switch the Switched Plug and/or one or more Switched Contacts On or Off whenever temperature exceeds the Alarm Set Threshold value. If Auto Recovery is enabled, the CCM can also return these user-selected plugs/contacts to their prior status, if the temperature falls below the Alarm Clear Threshold value. For more information, please refer to Section 7.2.1.

### 7.2.1. Over Temperature Alarms - Load Shedding and Auto Recovery

For Over Temperature Alarms, the Load Shedding feature is used to switch the CCM's Switched Plug and/or one or more Switched Contacts On or Off whenever temperature exceeds the Alarm Set Threshold value. This allows the CCM to automatically shut Off non-essential devices in order to reduce temperature generated within the rack, or automatically switch On devices such as fans or cooling systems in order to dissipate heat. When Auto Recovery is enabled, the CCM can also automatically "undo" the effects of the Load Shedding feature when the temperature again falls to a user-defined non-critical level.

**Note:** *Load Shedding Configuration Menus for both the Initial and Critical Over Temperature Alarms offer essentially the same set of parameters, but parameters defined for each alarm are separate and unique. For example, parameters defined for Over Temperature (Initial) Alarm Load Shedding will not be applied to Over Temperature (Critical) Alarm Load Shedding and vice versa.*

The Load Shedding Configuration menus allow you to defined the following parameters:

- **Configure Loadshedding for Unit:** In the Text Interface, this item is used to access the Load Shedding parameters listed below. In the Web Browser Interface, Load Shedding parameters are accessed via the "Load Shedding" button in the Temperature Alarm configuration menus.
- **Enable:** Enables/Disables Load Shedding for the Over Temperature Alarm. When enabled, the CCM will switch the selected plugs/contacts whenever temperature exceeds the Alarm Set Threshold value. (Default = Disable)
- **Plug State:** Determines whether the CCM's Switched Plug and/or one or more Switched Contacts will be switched On or Off when Load Shedding is enabled and temperature exceeds the Alarm Set Threshold. For example, if the Plug State is set to "Off", then the selected plugs, contacts and/or plug groups will be switched Off when the Alarm Set Threshold is exceeded. (Default = Off)
- **Auto Recovery:** Enables/Disables Auto Recovery. When both Load Shedding and Auto Recovery are enabled, the CCM will return plugs/contacts to their former On/Off state if temperature falls below the Alarm Clear Threshold value. This allows the CCM to "undo" the effects of the Load Shedding feature after temperature has returned to an acceptable level. (Default = Off)
- **Plug Access:** Determines which plugs/contacts will be switched when temperature exceeds the Alarm Set Threshold and Load Shedding is triggered. For example, if contacts C2 and C3 are selected, then these contacts will be switched On or Off if temperature exceeds the Alarm Set Threshold. (Default = undefined)
- **Plug Group Access:** Determines which Plug Group(s) will be switched when the Load Shedding feature is triggered. (Default = undefined)

**Note:** *Plug Groups must first be defined (as described in Section 5.6) before they will be displayed in the Load Shedding menu's Plug Group Access submenu.*

### 7.3. The Circuit Breaker Open Alarm

The Circuit Breaker Alarm is intended to provide notification in the event that one of the CCM's circuit breakers is opened. When a circuit breaker is open, the CCM can provide notification via Email, Syslog Message or SNMP Trap.

**Notes:**

- *The Circuit Breaker Open Alarm is not applicable to some CCM models.*
- *In order for the CCM to provide alarm notification via Email, communication parameters must first be defined.*
- *In order for the CCM to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled.*
- *In order for the CCM to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled.*

To configure the Circuit Breaker Alarm, you must access the CCM command mode using a password that permits Administrator Level commands. The Circuit Breaker Open Alarm Configuration Menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

**Note:**

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
  - *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all CCM alarms. For example, if the Circuit Breaker Open Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other CCM alarms will also be enabled.*
  - **Resend Delay:** Determines how long the CCM will wait to resend an email message generated by this alarm when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)
  - **Notify Upon Clear:** When this item is enabled, the CCM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the CCM can send initial notification when it detects an open circuit breaker, and then send a second notification when it determines that the circuit breaker has been closed. (Default = On)
  - **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
  - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)
- Note:** *If Email addresses have been previously defined, then the text under the parameters will list the current, user selected email addresses.*
- **Subject:** Defines the text that will appear in the "Subject" field for email notification messages generated by this alarm. (Default = "Alarm: Circuit Breaker Open")

## 7.4. The Ping-No-Answer Alarm

The Ping-No-Answer Alarm is intended to provide notification when one of the IP addresses defined via the Ping-No-Answer Reboot feature (described in Section 6.1) fails to respond to a Ping command. When one of the user-defined IP addresses fails to answer a Ping command, the CCM can provide notification via Email, Syslog Message or SNMP Trap.

### Notes:

- *In order for the Ping-No-Answer Alarm to work properly, your network and/or firewall, as well as the device at the target IP address, must be configured to allow ping commands.*
- *In order for this alarm to function, IP Addresses for the Ping-No-Answer reboot feature must first be defined as described in Section 6.1.*
- *When a Ping-No-Answer condition is detected, the CCM can still reboot the user-selected plug/contacts, and can also send an email, Syslog Message and/or SNMP trap as described in this section.*
- *In order for the CCM to provide Email alarm notification, communication parameters must first be defined.*
- *In order for the CCM to provide Syslog Message notification, Syslog parameters must first be defined and Syslog Messages must be enabled.*
- *In order for the CCM to provide SNMP Trap notification when this alarm is triggered, SNMP parameters must first be defined, and SNMP Traps must be enabled.*

To configure the Ping-No-Answer Alarm, you must access CCM command mode using a password that permits Administrator Level commands. The Ping-No-Answer alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all CCM alarms. For example, if the Ping-No-Answer Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other CCM alarms will also be enabled.*
- **Resend Delay:** Determines how long the CCM will wait to resend an email message generated by this alarm when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)
- **Notify Upon Clear:** When this item is enabled, the CCM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the CCM will send initial notification when it detects that a Ping command has failed, and then send a second notification when it determines that the IP address is again responding to the Ping command. (Default = On)

- **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)

**Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages that are generated by this alarm. (Default = "Alarm: Ping-No-Answer")



## 7.5. The Serial Port Invalid Access Lockout Alarm

The Serial Port Invalid Access Lockout Alarm can provide notification when the CCM has locked the serial SetUp Port due to repeated, invalid attempts to access command mode. Normally, the Invalid Access Lockout feature (discussed in Section 5.3.2) can lock the serial SetUp Port whenever the unit detects that the threshold value for invalid access attempts at the SetUp Port is exceeded. When a serial port lockout occurs, the unit can provide notification via Email, Syslog Message or SNMP Trap.

### Notes:

- *Note that Serial Port Invalid Access Lockout Alarm is only intended to provide notification when the Invalid Access Lockout feature has locked the serial SetUp Port. To apply the Invalid Access Lockout feature to the Network Port, please refer to Section 5.3.2.*
- *In order for this alarm to function, Invalid Access Lockout parameters for the serial port must first be configured and enabled.*
- *If desired, the CCM can be configured to count Invalid Access attempts at the serial SetUp port, and provide notification when the counter exceeds a user defined trigger level, without actually locking the serial SetUp Port. To do this, enable the Invalid Access Lockout Alarm as described here, but when you configure Invalid Access Lockout parameters as described in Section 5.3.2, set Lockout Attempts and Lockout Duration as you would normally, and then set the "Lockout Enable" parameter to "Off."*
- *In order for the CCM to provide Email alarm notification, communication parameters must first be defined.*
- *In order for the CCM to provide Syslog Message notification, Syslog parameters must first be defined and Syslog Messages must be enabled.*
- *In order for the CCM to provide SNMP Trap notification when this alarm is triggered, SNMP parameters must first be defined, and SNMP Traps must be enabled.*

To configure the Serial Port Invalid Access Lockout Alarm, you must access the CCM command mode using a password that permits Administrator Level commands. The Invalid Access Lockout alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all CCM alarms. For example, if the Invalid Access Lockout Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then other CCM alarms will also be enabled.*

- **Resend Delay:** Determines how long the CCM will wait to resend an email message generated by this alarm when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)
  - **Notify Upon Clear:** When enabled, the CCM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the CCM will send initial notification when it detects that an Invalid Access Lockout has occurred, and then send a second notification when it determines that the port has been unlocked. (Default = On)
  - **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
  - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu will receive email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)
- Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Invalid Access Lockout")

## 7.6. The Power Cycle Alarm

The Power Cycle Alarm can provide notification when all input power to the CCM unit is lost and then restored. When the power supply is lost and then restored, the CCM can provide notification via Email, Syslog Message or SNMP Trap.

### Notes:

- *In order for the CCM to provide alarm notification via Email, communication parameters must first be defined.*
- *In order for the CCM to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled.*
- *In order for the CCM to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled.*

To configure the Power Cycle Alarm, you must access the CCM command mode using a password that permits Administrator Level commands. The Power Cycle Alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all CCM alarms. For example, if the Power Cycle Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then other CCM alarms will also be enabled.*
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu will receive email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)  
**Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Power Cycle")

## 7.7. The No Dialtone Alarm

The No Dialtone Alarm allows the CCM to monitor a telephone line connected to an external modem installed at the CCM Setup Port, and then provide notification if the CCM detects that the phone line is dead or no dialtone is present.

If the No Dialtone Alarm is enabled and the CCM determines that there is no dialtone signal, the No Dialtone Alarm can provide notification via email using a network connection. In the event that the CCM unit is not connected to a network cable, the CCM will also create an entry in the Alarm Log, indicating that the No Dialtone Alarm has been triggered.

### Notes:

- *In order for this alarm to function, the No Dialtone Alarm parameter in the Serial Port Configuration menu must first be configured and enabled.*
- *In order for the CCM to provide alarm notification via Email, communication parameters must first be defined.*
- *In order for the CCM to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled.*
- *In order for the CCM to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled.*

The configuration menu for the No Dialtone Alarm allows the following parameters to be defined:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

### Note:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify Upon Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all CCM alarms. For example, if the No Dialtone Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then all other CCM alarms will also be enabled.*
- **Resend Delay:** Determines how long the CCM will wait to resend an email message generated by this alarm when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)
- **Notify Upon Clear:** When enabled, the CCM will send additional notification if the situation that caused the alarm is cleared. For example, when Notify Upon Clear is enabled, the CCM will send initial notification when it detects that the dialtone for the external modem has been lost, and then send a second notification when it determines that the dialtone has been restored. (Default = On)
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On)

- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)

**Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: No Dial Tone")

## 8. The Status Screens

The Status Screens are used to display status information about the switched plug, switched contacts, Network Port and other important features. The Status Screens are available via both the Text Interface and Web Browser Interface.

### 8.1. Product Status

The Product Status Screen lists the model number, software version and other information regarding your CCM unit. To display the Product Status Screen via the Text Interface, type `/J *` and then press **[Enter]**. To display the Product Status Screen via the Web Browser Interface, click on the "Product Status" link.

**Note:** *The Information provided by the Product Status Screen is intended mainly to assist WTI support peronnel with the diagnosis of user equipment problems.*

### 8.2. The Network Status Screen

The Network Status screen shows activity at the CCM's 16 virtual network ports. To view the Network Status Screen, you must access command mode using a password that permits Administrator Level commands.

To display the Network Status Screen via the Text Interface, type `/SN` and press **[Enter]**. To display the Network Status Screen via the Web Browser Interface, click on the Network Status link.

### 8.3. The Plug Status Screen

The Plug Status screen shows the On/Off status of the CCM's Switched AC Plug and Switched Contacts, and also lists user-defined Plug Names, Boot/Sequence Delay values, and Default On/Off settings.

**Note:** *When the Plug Status Screen is viewed by an "Administrator" or "SuperUser" level account, all CCM contacts and the Switched Plug are listed. When the Plug Status Screen is viewed by a "User" or "ViewOnly" level account, the screen will list only the contacts/plug that are allowed by the account.*

To display the Plug Status Screen via the Text Interface, type `/s` and press **[Enter]**. To display the Plug Status Screen via the Web Browser Interface, click on the "Plug Status" link. Note that when the `/s` command is invoked via the Text Interface, the command line can also include arguments that display On/Off status for an individual plug/contact, two or more specific plugs/contacts, or a range of plugs/contacts:

- `/s` Displays configuration details and ON/Off status for the Switched Plug and all Switched Contacts.
- `/s s` Displays On/Off status for the Switched Plug and individual Switched Contact, where `s` is the name or number of the desired plug or contact.
- `/s s+s` Displays On/Off status for two or more specific plugs/contacts, where `s` is the number or name of each desired plug/contact. A plus sign (+) is entered between each plug/contact number or name.
- `/s s:s` Displays On/Off status for a range of plugs/contacts, where `s` is the number or name of the plug/contact at the beginning and end of the range of desired plugs/contacts. A colon (:) is entered between the two plug/contact numbers or names that mark the beginning of the range and the end of the range.

## 8.4. The Plug Group Status Screen

The Plug Group Status screen shows the configuration details and On/Off status for the CCM's user-defined Plug Groups.

**Notes:**

- *Current and Power Monitoring features are not available for the switched contacts.*
- *When the Plug Group Status Screen is viewed by an "Administrator" or "SuperUser" level account, all CCM plugs, contacts and plug groups are listed. When the Plug Status Screen is viewed by a "User" or "ViewOnly" account, the screen will list only the plug groups allowed by the account.*
- *In order to display the Plug Group Status screen, you must first define at least one Plug Group as described in Section 5.6.*

To display the Plug Group Status Screen via the Text Interface, type /SG and then press **[Enter]**. To display the Plug Group Status Screen via the Web Browser Interface, click on the "Plug Group Status" link and then select the desired Plug Group from the resulting subment and click on the "Get Plug Group Status" button.



## 8.5. The Current Metering Status Screen

The Current Metering Status screen is used to display up-to-date readings for Amps, Watts, Voltage and temperature for the Switched AC Plug. To view the Current Metering Log screen, access command mode and then proceed as follows:

**Note:** *Current and Power Metering functions are not available for the switched contacts.*

- **Text Interface:** Type `/m` and press **[Enter]**.
- **Web Browser Interface:** Place the cursor over the "Current Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the "Current Metering Status" link.

The Current Metering Status screen lists the following parameters:

- **Current A:** The total current consumption, in Amps, for power circuit A.
- **Voltage A:** The total voltage for power circuit A.
- **Power A:** The total power consumption, in Watts, for power circuit A.
- **Current B:** The total current consumption, in Amps, for power circuit B (if present.)
- **Voltage B:** The total voltage for power circuit B (if present.)
- **Power B:** The total power consumption, in Watts, for power circuit B (if present.)
- **Temperature:** The rack temperature(s) currently detected by the unit.
- **Total Current:** The total current, in Amps, for both power circuits.
- **Total Power:** The total power, in Watts, for both power circuits.
- **Power Factor:** The user-defined Power Factor value.
- **Power Efficiency:** The user-defined Power Efficiency value.
- **Over Temperature:** (Text Interface Only) Lists the values for the Initial Threshold and Critical Threshold for the Over Temperature Alarms. Note that when the Current Metering Status Screen is viewed via the Web Browser Interface, Over Temperature Alarm settings are not listed. To view Over Temperature Alarm settings via the Web Browser Interface, please use the Current History Screen.
- **Over Current:** (Text Interface Only) Lists the values (as a percentage) for the Initial Threshold and Critical Threshold for the Over Current Alarms.

## 8.6. The Current History Screen

The Current History Screen displays current, voltage and temperature readings as a function of time. In the Web Browser Interface, the Current History can be displayed as a graph or downloaded in ASCII, CSV or XML format. In the Text Interface, the Current History can be displayed as straight ASCII data, or can be downloaded in CSV or XML format. To view the Current History Screen, access command mode, and proceed as follows:

**Note:** *Current and Power Metering functions are not available for the Switched Contacts. Current and Power Metering functions are only available for the Switched AC Plug.*

**Text Interface:** Type `/L` and press **[Enter]** to access the "Display Logs" menu. From the "Display Logs" menu, enter the appropriate option number and then press **[Enter]** to display the Current Metering Log Menu. The Text Interface also offers the option to select the following display parameters:

- **Display Data Option:** Determines whether data will be displayed in "Unit" format or "Plug" format (Note that this option is not applicable to some CCM models.)
- **Display Current Metering Log:** Displays the Current Metering Log according to the currently selected Display Data Option.
- **Download Current Metering Log in CSV Format:** Downloads the Current Metering Log (as determined by the current Display Data Option) in CSV format.
- **Download Current Metering Log in XML Format:** Downloads the Current Metering Log (as determined by the current Display Data Option) in XML format.
- **Erase Current Metering Log:** Clears all Current Metering Log data. Note that when the Current Metering Log is erased, the Power Metering Log will also be erased.

**Web Browser Interface:** Place the cursor over the "Current Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the "Current History" link to display the Current Metering Log menu. At the Current Metering Log menu, you can display current history data as a graph, or download or display the log in ASCII, CSV or XML format. Current Metering Log data can be displayed or downloaded for specific plug(s) or plug group(s.) When the Current Metering Log is displayed as a graph, a date range can also be selected, allowing data to be displayed Live or for the previous Day, Week, Month or Year.

When the Current History Screen is displayed in ASCII, CSV or XML format, the CCM will show Branch Current, Branch Voltage and temperature readings in tabular format. When the Current History Screen is displayed in graph format, via the Web Browser Interface, the CCM will display a page with up to four graphs:

- **Branch Current:** Shows current consumption versus time for each available branch (if present.)
- **Plug Current:** Shows current consumption vs time for the Switched Plug.
- **Branch Voltage:** Shows voltage consumption vs time for each available branch (if present.)
- **Line Current:** Shows current consumption vs time for each available line (if present.)

**Notes:**

- *Current and power metering data is not available for the switched contacts.*
- *Branch and Line metering functions are not available on some CCM models.*

To save Current History data, access command mode using an account that permits Administrator level commands, and then proceed as follows:

- **Text Interface:** Type `/I` and press **[Enter]** to show the Display Logs menu. From the Display Logs menu, key in the number for the desired option and then press **[Enter]** to display the Current History menu, which allows you to either display the Current History log in ASCII format, download and save in CSV or XML format, or erase the Current History Log.
- **Web Browser Interface:** Place the cursor over the "Current Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the desired action and then select graph format, or display/download the Current History in ASCII, CSV or XML format.

For more information on Current Metering and Current History, please refer to Section 5.3.3

## 8.7. The Power Range Status Screen

The Power Range Status Screen can display power consumption readings over a user-selected period of time, for the CCM unit's Switched AC Plug.

**Note:** *Current and Power Metering functions are not available for the Switched Contacts. Current and Power Metering functions are only available at the Switched AC Plug.*

To view the Power Range Status Screen, access command mode using an account that permits Administrator or SuperUser level commands and proceed as follows:

### Text Interface:

1. Type `/L` and press **[Enter]** to access the "Display Logs" menu. From the Display Logs menu, key in the number for the Power Metering Log option and then press **[Enter]** to display the Power Metering Log menu.
2. **Power Metering Log Menu:** The "Display Data Option" determines whether the CCM will display total current consumption for each branch (Unit) or current consumption for the Switched Plug. The Power Metering Log Menu also allows you to either display Power Metering Data or download Power History Data. Note that the Branch and Line options are not available on all CCM models.
  - a) **Display Power Metering:** Key in the number for the Display Power Metering option and press **[Enter]**. The CCM will display the Power Metering menu, which allows you to set a date range and display the data selected.
  - b) **Download Power History:** See Section 8.8.

### Web Browser Interface:

1. Place the cursor over the "Power Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the "Power Range" link to display the "Select Plugs" menu.
2. Select the Switched Plug, then click the "Select Plugs" button to display the "List Power Range" menu.
3. Use the List Power Range menu to select the desired date range, and then click on the "Get Chart" button.

In the Text Interface, Power Metering data will be displayed in table format. In the Web Browser Interface, Power Metering data will be displayed in both table and graph format. Both the Text Interface and Web Browser Interface will list the following data:

- **Kilowatt Hours:** The number of Kilowatt Hours consumed by the Switched Plug or plug group during the specified time period.
- **Average Current:** The average current draw for the Switched Plug or plug group during the specified time period.
- **Average % of Max.:** (Text Interface Only) The average percentage of maximum available current that was used by the Switched Plug or plug group during the specified time period.
- **Average Power:** The average power consumption for the Switched Plug or plug group during the specified time period.

## 8.8. The Power History Screen

The Power History Screen shows power consumption versus time. To view the Power History Screen, access command mode using an account that permits access to Administrator or SuperUser level commands, and then proceed as follows:

**Note:** *Current and Power Metering functions are not available for the switched contacts. Current and Power Metering functions are only available for the Switched AC Plug.*

### Text Interface:

Type `/L` and press **[Enter]** to access the "Display Logs" menu. From the Display Logs menu, key in the number for the Power Metering Log option and press **[Enter]** to display the Power Metering Log menu. From the Power Metering Log menu, key in the number for the Download Power History option and press **[Enter]** to display the Power History Menu.

The Power History menu offers the following options:

1. **Display Data Option:** The Display Data Option determines whether the CCM will display total current consumption (Unit) or current consumption for each the switched AC outlet (Plug).
2. **Display Power Metering:** The Display Power Metering menu allows you to select the duration period (date) for the Power History screen and then display the resulting data.
2. **Download Power History:** Type 2 or 3 and press **[Enter]** to download Power History data in CSV or XML format.

### Web Interface:

Place the cursor over the "Power Metering" link on the left hand side of the screen. When the fly-out menu appears, click on the "Power History" link to display the Power History menu.

The Power History menu offers the options to display Power History as a graph, or display/download the Power History in ASCII, CSV or XML format; click on the link for the desired option. The CCM will display a screen that allows you to select the Switched AC Plug and one or more plug groups. Check the box next to the desired option, then click on the "Select Plugs" button to display the Power History graph.

### Notes:

- *Power History Data does not include the Switched Contacts. Power History Data is only applicabel to the Switched AC Plug.*
- *When the "Unit" Display Data Option is selected, the Power Metering Log will list power data for the Switched Plug.*
- *When the "Plugs" Display Data Option is selected, the Power Metering Log will list data for the Switched Plug.*

## 8.9. The Port Diagnostics Screen

The Port Diagnostics Screen provides more detailed information about the CCM's Serial Port. To display the Port Diagnostics Screen, access the Text Interface command mode and type `/SD` **[Enter]**.

**Note:** *The Port Diagnostics Screen is only available via the Text Interface.*

## 8.10. Alias Status Screen

The Alias Status Screen lists user defined IP alias for the CCM's Serial Port.

**Note:** *The Alias Status Screen is only available via the Text Interface.*

To display the Alias Status Screen via the Text Interface, type `/SA` and press **[Enter]**.

## 8.11. The Alarm Status Screen

The Alarm Status Screen lists all available user-defined alarms and indicates whether or not each alarm has been triggered. The resulting screen will display "Yes" (or 1) for alarms that have been triggered or "No" (or 0) for alarms that have not been triggered. If desired, the `/AS` command line can also include an optional alarm argument that will cause the unit to display the status of one individual alarm. For a list of alarm arguments, please refer to Section 17.3.1.

To display the Alarm Status Screen, type `/AS` and press **[Enter]**.

## 8.12. The Serial Port Parameters Screen

The `/W` (Who) command displays more detailed information about the CCM's Serial Port. Rather than listing general connection information, the Port Parameters screen lists all defined parameters for the Serial port. To display the Serial Port Parameters Screen, type `/w` and press **[Enter]**.

The `/W` command uses the following format:

`/w xx` **[Enter]**

**Note:** *The Serial Port Parameters screen is only available via the Text Interface.*

## 9. Operation

The CCM offers two separate command interfaces; the Web Browser Interface and the Text Interface. Both interfaces offer essentially the same command options and features, and in most cases, parameters defined via the Web Browser Interface will also apply when communicating via the Text Interface (and vice versa.)

### 9.1. Operation via the Web Browser Interface

When using the Web Browser Interface, switching commands are invoked via the Plug Control Screen and Plug Group Control Screen.

#### 9.1.1. The Plug Control Screen - Web Browser Interface

The Plug Control Screen lists the On/Off status of the CCM's Switched Plug and Switched contacts and is used to control power switching and rebooting functions. To invoke power switching commands, access CCM command mode, then click on the "Plug Control" link on the left hand side of the screen to display the Plug Control Screen.

When the Plug Control Screen appears, click the down arrow in the "Action" column for the desired Switched Plug or Switched Contact(s), then select the desired switching option from the dropdown menu and click on the "Confirm Actions" button.

When the "Confirm Actions" button is pressed, the CCM will display a screen which lists the selected action(s) and asks for confirmation before proceeding. To implement the selected action(s), click on the "Execute Actions" button. The CCM will display a screen which indicates that a switching operation is in progress, then display the Plug Status screen when the command is complete. At that time, the Status Screen will list the updated On/Off status of each Switched Plug and/or Switched Contact.

#### Notes:

- *If AC power to the CCM unit is lost, all contacts will be automatically set to their "Normal" positions. For example, all "NC" contacts will be set to the Closed Position.*
- *When switching and reboot operations are initiated, Boot/Sequence Delay times will be applied as described in Section 5.7.1.*
- *If a switching or reboot command is directed to a plug or contact that is already in the process of being switched or rebooted by a previous command, then the new command will be placed in a queue until the plug or contact is ready to receive additional commands.*
- *If the Status column in the Plug Control Screen includes an asterisk, this means that the corresponding plug or contact is busy completing a previously invoked command.*
- *When the Plug Control Screen is displayed by an account that permits Administrator or SuperUser level commands, the Plug Control Screen will list the Switched AC Plug plus all Switched Contacts.*
- *When the Plug Control Screen is displayed by a User level account, the screen will only include the Switched Plug/Contacts allowed by the account.*

### 9.1.2. The Plug Group Control Screen - Web Browser Interface

The Plug Group Control Screen is used to send switching and reboot commands to the user-defined Plug Groups. As described in Section 5.6, Plug Groups allow you to assign the Switched AC Plug and Switched Contacts to groups that contain plugs/contacts that are dedicated to a similar purpose or client, and then direct switching commands to the group, rather than switching one plug/contact at a time.

To apply power switching commands to Plug Groups, first access CCM Command Mode. Click on the "Plug Group Control" link on the left hand side of the screen to display the Plug Group Control Screen. When the Plug Group Control Screen appears, click the down arrow in the "Action" column for the desired Plug Group(s), then select the desired switching option from the dropdown menu and click on the "Confirm Plug Actions" button

When the "Confirm Plug Group Actions" button is pressed, the CCM will display a screen which lists the selected action(s) and asks for confirmation before proceeding. To implement the selected plug group action(s), click on the "Execute Plug Group Actions" button. The CCM will display a screen which indicates that a switching operation is in progress, then display the Plug Status screen when the command is complete. At that time, the Status Screen will list the updated On/Off status of each plug/contact.

#### Notes:

- *If AC power to the CCM unit is lost, all contacts will be automatically set to their "Normal" positions. For example, all "NC" contacts will be set to the Closed Position.*
- *When switching and reboot operations are initiated, Boot/Sequence Delay times will be applied as described in Section 5.7.1.*
- *If a switching or reboot command is directed to a plug or contact that is already in the process of being switched or rebooted by a previous command, then the new command will be placed in a queue until the plug or contact is ready to receive additional commands.*
- *When the Plug Group Control Screen is displayed by an account that permits Administrator or SuperUser level commands, all user-defined Plug Groups will be displayed.*
- *When the Plug Control Screen is displayed by a User level account, the screen will only include Plug Groups specifically allowed for the account.*



## 9.2. Operation via the Text Interface

When using the Text Interface, all switching functions are performed by invoking simple, ASCII commands. To display the Text Interface Help Menu, type `/H` and press **[Enter]**.

### Notes:

- *If AC power to the CCM unit is lost, all contacts will be automatically set to their "Normal" positions. For example, all "NC" contacts will be set to the Closed Position.*
- *Current and Power Monitoring features are not available for the switched contacts. The Current and Power Monitoring features are only available to the Switched AC Plug (Switched Plug.)*
- *When the Help Menu is displayed by a SuperUser, User or ViewOnly level account, the screen will not include commands that are only available to Administrator level accounts.*

### 9.2.1. Switching and Reboot Commands - Text Interface

These commands are used to switch or reboot the CCM's Switched Plug and Switched Contacts, and can also be used to set the plug and/or contacts to their user-defined Power-Up Default values. Plugs and contacts may be specified by name or number.

### Notes:

- *If AC power to the CCM unit is lost, all contacts will be automatically set to their "Normal" positions. For example, all "NC" contacts will be set to the Closed Position.*
- *If a switching or reboot command is directed to a plug or contact that is already being switched or rebooted by a previous command, then the new command will be placed in a queue until the plug or contact is ready to receive additional commands.*
- *If an asterisk appears in the "Status" column for any given plug or contact, this indicates that the plug or contact is currently busy, processing a previously issued command.*
- *Commands are not case sensitive. All commands are invoked by pressing **[Enter]**.*
- *When you have accessed command mode using an account that permits Administrator or SuperUser level commands, then switching and reboot commands can be applied to the Switched Plug and all Switched Contacts.*
- *When you have accessed command mode via a User level account, switching and reboot commands can only be applied to the plug/contacts that are specifically allowed for the account.*
- *If command confirmation is enabled, the CCM will display the Status Screen after commands are successfully completed.*
- *When switching and reboot operations are initiated, Boot/Sequence Delay times will be applied as described in Section 5.7.1.*
- *When used in On/Off/Reboot command lines, plug/contact names and plug group names are **not** case sensitive.*

When switching and reboot commands are executed, the CCM will display a "Sure?" prompt, wait for user response, and then complete the command. The unit will pause for a moment while the command is executed, and then return to the Plug Status Screen. To switch the plug or contacts, or initiate a Reboot Cycle, proceed as follows:

1. **Reboot Plug or Contacts:** Type `/BOOT n` and press **[Enter]**. Where "n" is the alphanumeric number or name of the desired plug, contact or Plug Group. Note that the `/BOOT` command can also be entered as `/BO`. For example:

`/BOOT C3 [Enter]` or `/BO ATMSWTCH [Enter]`

2. **Switch Plug On:** Type `/ON n` and press **[Enter]**. Where "n" is the alphanumeric number (A1) or name of the Switched Plug or Plug Group. For example:

`/ON A1 [Enter]` or `/ON ROUTER [Enter]`

3. **Switch Plug Off:** Type `/OFF n` and press **[Enter]**. Where "n" is the alphanumeric number (A1) or name of the Switched Plug or Plug Group. Note that the `/OFF` command can also be entered as `/OF`. For example:

`/OFF A1 [Enter]` or `/OF ROUTER [Enter]`

4. **Switch Contact to Normal Position (On):** Type `/ON n` and press **[Enter]**. Where "n" is the alphanumeric number or name of the Switched Contact or Plug Group. For example:

`/ON C1 [Enter]` or `/ON GROUP1 [Enter]`

5. **Switch Contact to Non-Normal Position (Off):** Type `/OFF n` and press **[Enter]**. Where "n" is the alphanumeric number or name of the Switched Contact or Plug Group. Note that the `/OFF` command can also be entered as `/OF`. For example:

`/OFF C1 [Enter]` or `/OF GROUP1 [Enter]`

6. **Set All Plugs and Contacts to Power Up Defaults:** Type `/DPL` and press **[Enter]**. All plugs and/or contacts permitted by your account will be set to their default On/Off status, which is defined via the Plug Parameters Menu.

**Notes:**

- *When you have accessed command mode using an Administrator or SuperUser level account, the Default command will be applied to both the Switched Plug and all Switched Contacts.*
- *When you have accessed command mode using an account that permits only User level command access, the Default command will only be applied to the plug/contacts specifically allowed by the account.*
- *The /DPL command is not available in ViewOnly mode.*

7. **Suppress Command Confirmation Prompt:** To execute a power switching command without displaying the "Sure?" prompt, include the ", Y" option at the end of the command line. For example:

`/ON ROUTER,Y` or `/BOOT B2,Y`

### 9.2.2. Applying Commands to Several Contacts/Plugs - Text Interface

As described below, switching and reboot commands can be applied to only one plug or contact, or to an assortment of plugs or contacts.

**Note:** *When switching and reboot operations are initiated, Boot/Sequence Delay times will be applied.*

1. **Switch Several Plugs/Contacts:** To apply a command to the Switched AC Plug and/or one or more Switched Contacts, enter the numbers of the desired plug/contacts, separated by commas or plus signs. For example to switch the Switched Plug (A1) plus contacts C3 and C4 to the Off position, enter either of the following commands:

**/OFF A1+C3+C4 [Enter]**

or

**/OFF A1 ,C3 ,C4 [Enter]**

**Note:** *In order for the "+" or "," operators to work, there must be no spaces between the plug/contact name or number and the plus sign or comma.*

2. **Switch a Series of Plugs/Contacts:** To apply a command to the Switched Plug and/or one or more Switched Contacts, enter the numbers for the plug/contacts that mark the beginning and end of the series, separated by a colon. For example to switch On contacts C1 through C3 enter the following:

**/ON C1 :C3 [Enter]**

4. **All Plugs/Contacts:** To apply a command to the Switched Plug, plus all Switched Contacts, enter an asterisk in place of the name or number. For example, to Boot the Switched Plug and all Switched Contacts, enter the following:

**/BO \* [Enter]**

**Note:** *When this command is invoked by a User level account, it will only be applied to the plug/contacts that are specifically allowed for the account.*

### 9.3. The Automated Mode

The Automated Mode allows the CCM to execute switching and reboot commands, without displaying menus or generating response messages. Automated Mode is designed to allow the CCM to be controlled by a device which can generate commands to control power switching functions without human intervention.

When Automated Mode is enabled, the /ON, /OFF, /BOOT, /DPL and /X commands are executed without a "Sure?" confirmation prompt and without command response messages; the only response to these commands is the command prompt, which is displayed when the command is complete.

Note that although Automated Mode can be enabled using either the Web Browser Interface or Text Interface, Automated Mode is designed primarily for users who wish to send ASCII commands to the CCM without operator intervention, and therefore does not specifically apply to the Web Browser Interface. When Automated Mode is enabled, the Web Browser Interface can still be used to invoke On / Off / Boot commands.

#### Notes:

- *When Automated Mode is enabled, all CCM password security functions are disabled, and users are able to access Administrator Level command functions (including the configuration menus) and control the Switched Plug and Switched Contacts without entering a password.*
- *If you need to enable the Automated Mode, but want to restrict network access to CCM command functions, it is recommended to enable and configure the IP Security Function as described in Section 5.9.3.*

To enable/disable Automated Mode, access the System Parameters menu, then set the "Automated Mode" option to "On". When Automated Mode is enabled, CCM functions will change as follows:

1. **All Password Security Suppressed:** When a user attempts to access command mode, the password prompt will not be displayed at either the SetUp Port or Network Port. Unless restricted by the IP Security Function, all users will be allowed to access both switching and configuration functions, and all commands will be immediately accepted without the requirement to enter a password.
2. **Status Screen Suppressed:** The status screens will not be automatically displayed after commands are successfully executed. Note however, that the status screens can still be displayed by invoking the appropriate commands.
3. **"Sure?" Prompt Suppressed:** All commands are executed without prompting for user confirmation.
4. **Error Messages Suppressed:** If the [Enter] key is pressed without entering a command, the CCM will not respond with the "Invalid Command" message. Note however, that an error message will still be generated if commands are invoked using invalid formats or arguments.

All other status display and configuration commands will still function as normal.

## 9.4. The SSH/Telnet Connect Function (Web Browser Interface Only)

The SSH/Telnet Connect function allows you to open an SSH Shell Session or Telnet Session without leaving the Web Browser interface. Once you have successfully opened an SSH Shell Session or Telnet Session, you can then use ASCII commands to configure and operate the CCM unit as described in Section 9.2 and Section 17.

### 9.4.1. Initiating an SSH Shell Session via the Web Browser Interface

To initiate an SSH Shell Session from the CCM Web Browser Interface, proceed as follows:

1. Place the cursor over the "SSH/Telnet Connect" button on the left hand side of the screen. When the flyout menu appears, click on the SSH option.

**Note:** *If the RSP displays a message that indicates that your browser does not include the Java plugin, go to the Java website and download the latest version of the Java plugin.*

2. Start Java: Click on the File menu and select "Open Shell Session"
3. The CCM will display a prompt that asks the user to enter a valid username and host name (IP Address.) Key in the username and host name (IP address) using the following format and then click on the "OK" button:

`username@ip_address`

**Notes:**

- *The username entered must be a valid username that has been previously defined via the CCM User Directory as described in Section 5.5.*
  - *The IP Address (host name) can either be the address to the machine that you are currently communicating with via the Web Browser Interface, or you can enter the IP address for another CCM unit, providing that the username entered is present on the other CCM unit too.*
4. After the username and host name are entered, the CCM will prompt you to enter your password. Key in the password that has been defined for the username entered in step 3 above and then click on the "OK" button.
  5. The CCM will display the Circuit Status Screen, followed by the command prompt. You may now invoke CCM commands as described in Section 9.2 and 17.
  6. To terminate the SSH Session, type `/x` and press **[Enter]**.

### 9.4.2. Initiating a Telnet Session via the Web Browser Interface

To initiate a Telnet Session from the CCM Web Browser Interface, proceed as follows:

1. Place the cursor over the "SSH/Telnet Connect" button on the left hand side of the screen. When the flyout menu appears, click on the Telnet option.

**Note:** *If the RSP displays a message that indicates that your browser does not include the Java plugin, go to the Java website and download the latest version of the Java plugin.*

2. Log in to the Telnet Session:
  - a) The CCM will display the "login" prompt. Key in a valid username that has been previously defined via the CCM User directory and then press **[Enter]**.
  - b) The CCM will display the "password" prompt. Key in the valid password for the username entered above and then press **[Enter]**.

**Notes:**

- *The username entered must be a valid username that has been previously defined via the CCM User Directory as described in Section 5.5.*
  - *The IP Address (host name) can either be the address to the machine that you are currently communicating with via the Web Browser Interface, or you can enter the IP address for another CCM unit, providing that the username entered is present on the other CCM unit too.*
3. The CCM will display the Circuit Status Screen, followed by the command prompt. You may now invoke CCM commands as described in Section 9.2 and 17.
  4. To terminate the Telnet Session, type **/x** and press **[Enter]**.

## 9.4. Manual Operation

In addition to the command driven functions available via the Web Browser Interface and Text Interface, some CCM functions can also be controlled manually. For a summary of front panel control functions, please refer to Section 2.3.

## 9.5. Logging Out of Command Mode

When you have finished communicating with the CCM, it is important to always disconnect using either the "LogOut" link (Web Browser Interface) or the **/X** command (Text Interface), rather than by simply closing your browser window or communications program. When communicating via a PDA, use the PDA's "Close" function to disconnect and logout.

When you disconnect using the LogOut link or **/X** command, this ensures that the CCM has completely exited from command mode, and is not waiting for the inactivity timeout period to elapse before allowing additional connections.

## 10. SSH Encryption

In addition to standard Telnet protocol, the CCM also supports SSH connections, which provide secure, encrypted access via network. In order to communicate with the CCM using SSH protocol, your network node must include an appropriate SSH client.

Note that when the /K (Send SSH Key) command is invoked, the CCM can also provide you with a public SSH key, which can be used to streamline connection to the CCM when using SSH protocol.

Although you can establish an SSH connection to the unit *without* the public key, the public key provides validation for the CCM, and once this key is supplied to the SSH client, the client will no longer display a warning indicating that the CCM is not a recognized user when the client attempts to establish a connection.

The /K command uses the following format:

```
/K <k> [Enter]
```

Where **k** is an argument that determines which type of public key will be displayed, and the **k** argument offers the following options:

1. SSH1
2. SSH2 RSA
3. SSH2 DSA

For example, to obtain the public SSH key for an SSH2 RSA client, type /K 2 and then press **[Enter]**. Note that when capturing the SSH key, you can either configure your terminal application to receive the parameter file, or simply copy and paste the resulting SSH key.

### Notes:

- *Although the CCM does not support SSH1, the /K 1 command will still return a key for SSH1.*
- *When capturing the SSH key, you can either configure your terminal application to receive the parameter file, or simply copy and paste the resulting key*

## 11. Syslog Messages

The Syslog feature can create log records of each Alarm Event. As these event records are created, they are sent to a Syslog Daemon, located at an IP address defined via the Network Parameters menu.

### 11.1. Configuration

If you wish to employ this feature, you must set the real-time clock and calendar via the System Parameters Menu, and define the IP address for the Syslog Daemon via the Network Port Configuration menu.

To configure the Syslog function, please proceed as follows:

1. **Access command mode:** Note that the following configuration menus are only available to accounts that permit Administrator level commands.
2. **System Parameters Menu:** Access the System Parameters Menu as described in Section 5.3, then set the following parameters:
  - a) **Set Clock and Calendar:** Set the Real Time Clock and Calendar and/or configure and enable the NTP server feature.
3. **Network Parameters Menu:** Access the Network Parameters Menu as described in Section 5.9, then set the following parameters:
  - a) **Syslog IP Address:** Determine the IP address for the device that will run the Syslog Daemon, then use the Network Port Configuration menu to define the IP Address for the Syslog Daemon.

**Note:** *The Syslog Address submenu in the Text Interface includes a Ping Test function that can be used to ping the user-selected Syslog IP Address to verify that a valid IP address has been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
4. **Syslog Daemon:** In order to capture messages sent by the CCM, a computer must be running a Syslog Daemon (set to UDP Port 514) at the IP address specified in Step 3 above.

Once the Syslog Address is defined, Syslog messages will be generated whenever one of the alarms discussed in Section 7 is triggered.



## 12. SNMP Traps

The SNMP Trap function allows the CCM to send Alarm Notification messages to two different SNMP managers, each time one of the Alarms discussed in Section 7 is triggered.

**Note:**

- *The SNMP feature cannot be configured via the SNMP Manager.*
- *SNMP reading ability is limited to the System Group.*
- *The SNMP feature includes the ability to be polled by an SNMP Manager.*
- *Once SNMP Trap Parameters have been defined, SNMP Traps will be sent each time an Alarm is triggered. For more information on Alarm Configuration, please refer to Section 7.*

### 12.1. Configuration:

To configure the SNMP Trap function, proceed as follows:

1. Access command mode using an account that permits Administrator level commands.
2. **SNMP Trap Parameters:** Access the SNMP Trap Parameters Menu as described in Section 5.9.7. Set the following:
  - a) **SNMP Managers 1 and 2:** The address(es) that will receive SNMP Traps generated by the Alarms discussed in Section 7. Consult your network administrator to determine the IP address(es) for the SNMP Manager(s), then use the Network Parameters menu to set the IP address for each SNMP Manager. Note that it is not necessary to define both SNMP Managers.

**Notes:**

- *To enable the SNMP Trap feature, you must define at least one SNMP Manager. SNMP Traps are automatically enabled when at least one SNMP Manager has been defined.*
  - *The SNMP Trap submenu includes a Ping Test function that can be used to ping the user-selected SNMP Managers to verify that a valid IP address has been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
  - *Addresses for SNMP Managers can be defined in either IPv4 or IPv6 format, as described in Section 5.9.7.*
- b) **Trap Community:** Consult your network administrator, and then use the Network Parameters menus to set the Trap Community.

Once SNMP Trap Parameters have been defined, the CCM will send an SNMP Trap each time an alarm is triggered.

## 13. Operation via SNMP

If SNMP Access Parameters have been defined, then you will be able to manage user accounts, control power and reboot switching and display unit status via SNMP. This section describes SNMP communication with the CCM unit, and lists some common commands that can be employed to manage users, control switching and reboot actions and display unit status.

**Note:** *SNMP Commands are not available if the IPS mode is active.*

### 13.1. CCM SNMP Agent

The CCM's SNMP Agent supports various configuration, control, status and event notification capabilities. Managed objects are described in WTI-MPC-VMR-MIB.txt, which can be found on the CDROM included with the CCM unit, or in the user's guide archive on the WTI web site (<http://www.wti.com/manuals.htm>).

The WTI-MPC-VMR-MIB.txt document can be compiled for use with your SNMP client.

### 13.2. SNMPv3 Authentication and Encryption

The major limitations of SNMPv2 were the failure to include proper username/password login credentials (v2 only used a password type of login, i.e., community name) and the lack of support for encryption of transmitted data. SNMPv3 addresses both of these shortcomings.

For SNMPv3, the CCM supports two forms of Authentication/Privacy: Auth/noPriv which requires a username/password, but does not encrypt data going over the internet and Auth/Priv which requires a username/password AND encrypts the data going over the internet using DES or AES (in the case of the CCM, the default encryption format for SNMPv3 is DES.) For the Password protocol, the SRM supports either MD5 or SHA1.

### 13.3. Configuration via SNMP

CCM User accounts can be viewed, created, modified, and deleted via SNMP. User accounts are arranged in a table of 128 rows, and indexed 1-128. User account parameters, as seen through the SNMP, are summarized below.

**Note:** *Current and Power Monitoring features are not available for the switched contacts.*

- **userTable::userName** – 32 character username
- **userTable::userPasswd** – 16 character password
- **userTable::userAccessLevel** – Account access level.
  - 0 – View Access
  - 1 – User Access
  - 2 – Superuser Access
  - 3 – Administrator Access
- **userTable::userLocalAccess** – A string of 5 characters, with one character for each of the Switched Plug plus the four Switched Contacts on the CCM unit. A '0' indicates that the account **does not** have access to the plug or contact, and a '1' indicates that the user *does* have access to the plug or contact.
- **userTable::userGroupAccess** – A string of 54 characters, with one character for each of the 54 possible plug groups in the system. '0' indicates that the account **cannot** access the group, and '1' indicates that the user *can* access the group.
- **userTable::userSerialAccess** – Access to the serial interface
  - 0 – No access
  - 1 – Access
- **userTable::userTelnetSshAccess** – Access to the Telnet/SSH interface.
  - 0 – No access
  - 1 - Access
- **userTable::userWebAccess** – Access to the Web interface.
  - 0 – No access
  - 1 - Access
- **userTable::userCurrentPowerMetering** – (Switched Plug Only) Access to the systems current/power metering.
  - 0 – No access
  - 1 – Access
- **userTable::userCallbackNum** – 32 character callback number for account.
- **userTable::userSubmit** – Set to 1 to submit changes.

### **13.3.1. Viewing Users**

To view users, issue a GET request on any of the user parameters for the index corresponding to the desired user.

### **13.3.2. Adding Users**

For an empty index, issue a SET request on the desired parameters. Minimum requirement is a username and password to create a user, all other parameters will be set to defaults if not specified. To create the user, issue a SET request on the userSubmit object.

### **13.3.3. Modifying Users**

For the index corresponding to the user you wish to modify, issue a SET request on the desired parameters to be modified. Once complete, issue a SET request on the userSubmit object.

### **13.3.4. Deleting Users**

For the index corresponding to the user you wish to delete, issue a SET request on the username with a blank string. Once complete, issue a SET request on the userSubmit object.

## 13.4. Plug and Contact Control via SNMP

### 13.4.1. Plug and Contact Status and Control

ON, OFF, BOOT, and DEFAULT commands can be issued for the Switched Plug and Switched Contacts via SNMP. The Switched Plug and Switched Contacts are arranged in a table of N rows, where N is the total number of plugs plus contacts in the system. Plug/contact parameters are described below.

- **plugTable::plugID** – String indicating the plug or contact's ID.
- **plugTable::plugName** – String indicating the plug or contact's user-defined name.
- **plugTable::plugStatus** – Current state of the plug or contact.
  - 0 – Plug or contact is OFF
  - 1 – Plug or contact is ON
- **plugTable::plugAction** – Action to be taken on plug or contact.
  - 1 – Mark to turn ON (does not execute)
  - 2 – Mark to turn OFF (does not execute)
  - 3 – Mark to BOOT (does not execute)
  - 4 – Mark to DEFAULT (does not execute)
  - 5 – Mark to turn ON and execute plug actions
  - 6 – Mark to turn OFF and execute plug actions
  - 7 – Mark to BOOT and execute plug actions
  - 8 – Mark to DEFAULT and execute plug actions

Set **plugTable::plugAction** to desired action, as specified by values 1-4 above, for each plug or contact index the action is to be applied to. For the last plug or contact you wish to set before executing the commands, use values 5-8 instead, which will invoke the requested commands all at once.

- **plugTable::plugCurrent** – The current, in tenths of an Amp, that is being consumed by the Switched Plug.
- **plugTable::plugPower** – The power, in Watts, that is being consumed by the Switched Plug.

### 13.4.2. Plug Group Status and Control

ON, OFF, BOOT, and DEFAULT commands can be issued for plug groups via SNMP. Plug groups are arranged in a table of 54 rows, one row for each plug group in the system. Plug Group parameters are described below.

- **plugGroupTable::plugGroupName** – String indicating the plug groups name.
- **plugGroupTable::plugGroupAction** – Action to be taken on plug group
  - 1 – Mark to turn ON (does not execute)
  - 2 – Mark to turn OFF (does not execute)
  - 3 – Mark to BOOT (does not execute)
  - 4 – Mark to DEFAULT (does not execute)
  - 5 – Mark to turn ON and execute plug group actions
  - 6 – Mark to turn OFF and execute plug group actions
  - 7 – Mark to BOOT and execute plug group actions
  - 8 – Mark to DEFAULT and execute plug group actions

Set **plugGroupTable::plugGroupAction** to desired action, as specified by values 1-4 above, for each plug group index the action is to be applied to. For the last plug group you wish to set before executing the commands, use values 5-8 instead, which will invoke the requested commands all at once.

- **plugGroupTable::plugGroupCurrent** – The current, in tenths of an Amp, that is being consumed by each Plug Group.
- **plugGroupTable::plugGroupPower** – The power, in Watts, that is being consumed by each Plug Group.

## 13.5. Viewing CCM Status via SNMP

Status of various components of the CCM can be retrieved via SNMP. Plug Status, and Environmental Status are currently supported.

### 13.5.1. System Status - Ethernet Port Mac Addresses

The Mac Address for the Ethernet Port can be displayed using the command below:

- `environmentUnitTable::environmentMacEth0` The Mac Address for Ethernet Port 0.

### 13.5.2. Plug and Contact Status

The status of each contact and the switched plug can be retrieved using the command below.

- `plugTable::plugStatus` – The status of the plug or contact.
  - 0 – Plug is OFF
  - 1 – Plug is ON
- `plugTable::plugName` - String indicating the plug or contact's user-defined name.

### 13.5.3. Unit Environment Status

The environment status can be retrieved for various variables for all of the CCM units in the system. The `environmentUnitTable` contains four rows, one row for each unit in the system (LOCAL, AUX1, AUX2, AUX3.)

**Note:** *Current and Power Monitoring features are not available for the switched contacts. Current and Power Monitoring features are only available for the Switched Plug.*

- `environmentUnitTable::environmentUnitName` – The unit (LOCAL.)
- `environmentUnitTable::environmentUnitTemperature` – The temperature of the given unit.
- `environmentUnitTable::environmentUnitCurrentA` – Total current for for the Switched AC Outlet. Note that Current will be reported in tenths of an Amp (divide result by ten to determine value in Amps.)
- `environmentUnitTable::environmentUnitVoltageA` – Voltage for the Switched AC Outlet
- `environmentUnitTable::environmentUnitPowerA` – Power drawn by the Switched AC Outlet
- `environmentMonthlyPowerLog` - The monthly power usage log for the Switched Plug.

#### 13.5.4. Alarm Status

The status of the CCM unit's alarm functions can be retrieved and displayed using the following commands:

**Notes:**

- *When an alarm status command returns a zero (0), this indicates that the alarm is inactive.*
- *When an alarm status command returns a one (1), this indicates that the alarm is active (triggered.)*
- **alarmTables::alarmOverCurrentInitial** - (VMR Series Units Only) Displays the status of the Over Current (Initial) Line Alarm.
- **alarmTables::alarmOverCurrentCritical** - (VMR Series Units Only) Displays the status of the Over Current (Critical) Line Alarm.
- **alarmTables::alarmOverTemperatureInitial** - Displays the status of the Over Temperature (Initial) Alarm.
- **alarmTables::alarmOverTemperatureCritical** - Displays the status of the Over Temperature (Critical) Alarm.
- **alarmTables::alarmPingNoAnswer** - Displays the status of the Ping-No-Answer Alarm.
- **alarmTables::alarmInvalidAccessLockout** - Displays the status of the Serial Port Invalid Access Lockout Alarm.
- **alarmTables::alarmPowerCycle** - Displays the status of the Power Cycle Alarm.
- **alarmTables::alarmNoDialtone** - Displays the status of the No Dialtone Alarm.
- **alarmTables::alarmEmergencyShutoff** - Displays the status of the Emergency Shut Off feature. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).



## 13.6. Sending Traps via SNMP

Traps that report various unit conditions can be sent to an SNMP Management Station from the CCM. The following traps are currently supported.

- **WarmStart** Trap – Trap indicating a warm start
- **ColdStart** Trap – Trap indicating a cold start
- **Test** Trap – Test trap invoked by user via the Text Interface (CLI.)

The CCM can send an SNMP trap to notify you when any of the available alarm functions have been triggered. In all cases except the Power Cycle Alarm, there will be one trap sent when the alarm is triggered, and a second trap sent when the alarm is cleared. For more information on alarm functions, please refer to Section 7.

- **Alarm** Trap – Trap indicating an alarm condition. A trap with a unique enterprise OID is defined for every possible alarm in the system, under which several specific trap-types are defined to indicate the setting or clearing of that particular alarm condition.
- **overCurrentInitialSetTrap** - (Switched AC Outlet Only) Indicates that the Over Current (Initial) Alarm has been triggered.
- **overCurrentInitialClearTrap** - (Switched AC Outlet Only) Indicates that the Over Current (Initial) Alarm has been cleared.
- **overCurrentCriticalSetTrap** - (Switched AC Outlet Only) Indicates that the Over Current (Critical) Alarm has been triggered.
- **overCurrentCriticalClearTrap** - (Switched AC Outlet Only) Indicates that the Over Current (Critical) Alarm has been cleared.
- **overTemperatureInitialSetTrap** - Indicates that the Over Temperature (Initial) Alarm has been triggered. The trap will also include a numerical value that indicates the current unit temperature.
- **overTemperatureInitialClearTrap** - Indicates that the Over Temperature (Initial) Alarm has been cleared.
- **overTemperatureCriticalSetTrap** - Indicates that the Over Temperature (Critical) Alarm has been triggered. The trap will also include a numerical value that indicates the current unit temperature.
- **overTemperatureCriticalClearTrap** - Indicates that the Over Temperature (Critical) Alarm has been cleared.
- **pingNoAnswerSetTrap** - Indicates that the Ping No Answer Alarm has been triggered. The trap will also include a numerical value that indicates the IP address of the device that failed to respond to the ping command.
- **pingNoAnswerClearTrap** - Indicates that the Ping No Answer Alarm has been cleared.
- **lockoutSetTrap** - Indicates that the Invalid Access Lockout Alarm has been triggered. The trap will also include a numerical value that indicates the number of the serial port where the lockout occurred.
- **lockoutClearTrap** - Indicates that the Invalid Access Lockout Alarm has been cleared.

- **powercycleSetTrap** - Indicates that the Power Cycle Alarm has been triggered (Note that there is no corresponding Clear Trap for the Power Cycle Alarm.)
- **noDialtoneSetTrap** - Indicates that the No Dialtone Alarm has been triggered.
- **noDialtoneClearTrap** - Indicates that the No Dialtone Alarm has been cleared.
- **emergencyShutoffSetTrap** - Indicates that an emergency shut off has been implemented. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).
- **emergencyShutoffClearTrap** - Indicates that an emergency shut off has been cleared. For more information regarding the Emergency Shut Off feature, please contact WTI Tech Support at [service@wti.com](mailto:service@wti.com).

## 14. Setting Up SSL Encryption

This section describes the procedure for setting up a secure connection via an https web connection to the CCM.

**Note:** *SSL parameters cannot be defined via the Web Browser Interface. In order to set up SSL encryption, you must contact the CCM via the Text Interface.*

There are two different types of https security certificates: "Self Signed" certificates and "Signed" certificates.

Self Signed certificates can be created by the CCM, without the need to go to an outside service, and there is no need to set up your domain name server to recognize the CCM. The principal disadvantage of Self Signed certificates, is that when you access the CCM command mode via the Web Browser Interface, the browser will display a message which warns that the connection might be unsafe. Note however, that even though this message is displayed, communication will still be encrypted, and the message is merely a warning that the CCM is not recognized and that you may not be connecting to the site that you intended.

Signed certificates must be created via an outside security service (e.g., VeriSign®, Thawte™, etc.) and then uploaded to the CCM unit to verify the user's identity. In order to use Signed certificates, you must contact an appropriate security service and set up your domain name server to recognize the name that you will assign to the CCM unit (e.g., service.wti.com.) Once a signed certificate has been created and uploaded to the CCM, you will then be able to access command mode without seeing the warning message that is normally displayed for Self Signed certificate access.

```
WEB ACCESS: [eth0] IPv4

HTTP:
1. Enable: On
2. Port: 80

HTTPS:
3. Enable: On
4. Port: 443

SSL Certificates:
5. Common Name:
6. State or Province:
7. Locality:
8. Country:
9. Email Address:
10. Organization Name:
11. Organizational Unit:
12. Create CSR:
13. View CSR:
14. Import CRT:
15. Export Server Private Key:
16. Import Server Private Key:
17. Harden Web Security: Medium
18. TLS Mode: TLSv1

Enter: #<CR> to change,
      <ESC> to return to previous menu ...
```

**Figure 14.1: Web Access Parameters (Text Interface Only)**

## 14.1. Creating a Self Signed Certificate

To create a Self Signed certificate, access the Text interface via Telnet or SSH, using a password that permits access to Administrator level commands and then proceed as follows:

1. Type `/N` and press **[Enter]** to display the Network Parameters menu.
2. At the Network Parameters menu, type `23` and press **[Enter]** to display the Web Access menu (Figure 14.1.) Type `3` and press **[Enter]** and then follow the instructions in the resulting submenu to enable HTTPS access.
3. Next, use the Web Access menu to define the following parameters.

**Note:** *When configuring the CCM, make certain to define all of the following parameters. Although most SSL applications require only the Common Name, in the case of the CCM all of the following parameters are mandatory.*

- **5. Common Name:** A domain name, that will be used to identify the CCM unit. If you will use a Self Signed certificate, then this name can be any name that you choose, and there is no need to set up your domain name server to recognize this name. However, if you will use a Signed certificate, then your domain name server must be set up to recognize this name (e.g., service.wti.com.)
- **6. State or Province:** The name of the state or province where the CCM unit will be located (e.g., California.)
- **7. Locality:** The city or town where the CCM unit will be located (e.g., Irvine.)
- **8. Country:** The two character country code for the nation where the CCM will be located (e.g., US.)
- **9. Email Address:** An email address, that can be used to contact the person responsible for the CCM (e.g., jsmith@yourcompany.com.)
- **10. Organizational Name:** The name of your company or organization (e.g., Western Telematic.)
- **11. Organizational Unit:** The name of your department or division; if necessary, any random text can be entered in this field (e.g., tech support.)

4. After you have defined parameters 5 through 11, type 12 and press **[Enter]** (Create CSR) to create a Certificate Signing Request. By default, this will overwrite any existing certificate, and create a new Self Signed certificate.
  - a) The CCM will prompt you to create a password. Key in the desired password (up to 16 characters) and then press **[Enter]**. When the CCM prompts you to verify the password, key it again and then press **[Enter]** once. After a brief pause, the CCM will return to the Web Access Menu, indicating that the CSR has been successfully created.
  - b) When the Web Access Menu is re-displayed, press **[Esc]** several times until you exit from the Network Parameters menu and the "Saving Configuration" message is displayed.
5. After the new configuration has been saved, test the Self Signed certificate by accessing the CCM via the Web Interface, using an HTTPS connection.
  - a) Before the connection is established, the CCM should display the warning message described previously. This indicates that the Self Signed certificate has been successfully created and saved.
  - b) Click on the "Yes" button to proceed. The CCM will prompt you to enter a user name and password. After keying in your password, the main menu should be displayed, indicating that you have successfully accessed command mode.

## 14.2. Creating a Signed Certificate

To create a Signed certificate, and eliminate the warning message, first set up your domain name server to recognize the Common Name (item 5) that you will assign to the unit. Next, complete steps one through five as described in Section 14.1 and then proceed as follows:

1. **Capture the Newly Created Certificate:** Type 13 and press **[Enter]** (View CSR). The CCM will prompt you to configure your communications (Telnet) program to receive the certificate. Set up your communications program to receive a binary file, and then press **[Enter]** to capture the file and save it. This is the Code Signing Request that you will send to the outside security service (e.g., VeriSign, Thawte, etc.) in order to have them sign and activate the certificate.
2. **Obtain the Signed Certificate:** Send the captured certificate to the outside security service. Refer to the security service's web page for further instructions.

3. **Upload the Signed Certificate to the CCM:** After the "signed" certificate is returned from the security service, return to the Web Access menu.
  - a) Access the CCM command mode via the Text Interface using an account that permits Administrator level commands as described previously, then type **/N** and press **[Enter]** to display the Network Parameters menu, and then type **23** and press **[Enter]** to display the Web Access menu.
  - b) From the Web Access menu, type **14** and press **[Enter]** (Import CRT) to begin the upload process. At the CRT Server Key submenu, type **1** and press **[Enter]** to choose "Upload Server Key."
  - c) Use your communications program to send the binary format Signed Certificate to the CCM unit. When the upload is complete, press **[Escape]** to exit from the CRT Server Key submenu.
  - d) After you exit from the CRT Server Key submenu, press **[Escape]** several times until you have exited from the Network Parameters menu and the "Saving Configuration" message is displayed.
4. After the configuration has been saved, test the signed certificate by accessing the CCM via the Web Browser Interface, using an HTTPS connection. For example, if the common name has been defined as "service.companyname111.com", then you would enter "**https://service.companyname111.com**" in your web browser's address field. If the Signed Certificate has been properly created and uploaded, the warning message should no longer be displayed.

### 14.3. Downloading the Server Private Key

When configuring the CCM's SSL encryption feature (or setting up other security/authentication features), it is recommended to download and save the Server Private Key. To download the Server Private Key, access the Text interface via Telnet or SSH, using a password that permits access to Administrator level commands and then proceed as follows:

1. Type **/N** and press **[Enter]** to display the Network Parameters menu.
2. At the Network Parameters menu, type **23** and press **[Enter]** to display the Web Access menu (Figure 14.1.)
  - a) To download the Server Private Key from the CCM unit, make certain that SSL parameters have been defined as described in Section 14.1, then type **15** and press **[Enter]** and store the resulting key on your hard drive.
  - b) To upload a previously saved Server Private Key to the CCM unit, make certain that SSL parameters have been defined as described in Section 14.1, then type **16** and press **[Enter]** and follow the instructions in the resulting submenu.

#### **14.4. TLS Mode**

The TLS Mode parameter in the Web Access menu (Text Interface Only) allows the TLS Mode to be set to either TLSv1 or TLSv1.1. Although TLSv1.1 provides better security, the default settings of most browsers do not support TLSv1.1. The default setting for this parameter is TLSv1.

## 15. Saving and Restoring Configuration Parameters

Once the CCM is properly configured, parameters can be downloaded and saved to a file. Later, if the configuration is accidentally altered, the saved parameters can be uploaded to automatically reconfigure the unit without the need to manually assign each parameter.

Saved parameters can also be uploaded to other identical CCM units, allowing rapid set-up when several identical units will be configured with the same parameters.

### Notes:

- *Configuration parameters can be downloaded and saved via either the Web Browser Interface or Text Interface. Saved configuration parameters can only be uploaded to the unit via the Text Interface.*
- *When CCM parameters are saved via the Text Interface, the procedure can be performed using any terminal emulation program (e.g. HyperTerminal™, TeraTerm®, etc.), that allows downloading of ASCII files.*

### 15.1. Sending Parameters to a File

#### 15.1.1. Downloading & Saving Parameters via Text Interface

1. Start your terminal emulation program and access the Text Interface command mode using an account that permits Administrator level commands.
2. When the command prompt appears, type `/U` and press **[Enter]**. The CCM will prompt you to configure your terminal emulation program to receive an ASCII download.
  - a) Set your terminal emulation program to receive an ASCII download, and then specify a name for a file that will receive the saved parameters (e.g. CCM.PAR).
  - b) Disable the Line Wrap function for your terminal emulation program. This will prevent command lines from being broken in two during transmission.
3. When the terminal emulation program is ready to receive the file, return to the CCM's Save Parameter File menu, and press **[Enter]** to proceed. CCM parameters will be saved on your hard drive in the file specified in Step 2 above.
4. The CCM will send a series of ASCII command lines which specify currently selected parameters. When the download is complete, press **[Enter]** to return to the command prompt.



### 15.1.2. Downloading & Saving Parameters via Web Browser Interface

The Web Browser Interface also includes a download function that can be used to save CCM parameters to an XML format file on your PC or laptop. To save parameters via the Web Browser Interface, proceed as follows:

**Notes:**

- *Although CCM parameters can be saved to a file via either the Text Interface or Web Browser Interface, saved parameters can only be restored via the Text Interface. The Restore Parameters function is not available via the Web Browser Interface.*
  - *This procedure may differ slightly, depending on the operating system and browser used. In some cases, your system may perform a security scan before proceeding with the download.*
1. Access the Web Browser Interface command mode using an account that permits Administrator level commands.
  2. When the Web Browser Interface appears, click on the "Download Unit Configuration" button on the left hand side of the screen.
  3. After a brief pause, your browser may display a prompt asking if you want to open or save the downloaded file. At this point, you can either select the "Save" option to save the parameters file to the download folder on your PC, or select "Save As" to pick a different location and/or filename for the saved parameters file.

## 15.2. Restoring Saved Parameters

This section describes the procedure for using your terminal emulation program to send saved parameters to the CCM.

1. Start your terminal emulation program and access the CCM's Text Interface command mode using an account that permits Administrator level commands.
2. Configure your terminal emulation program to upload an ASCII text file.
3. Upload the ASCII text file with the saved CCM parameters. If necessary, key in the file name and directory path.
4. Your terminal emulation program will send the ASCII text file to the CCM. When the terminal program is finished with the upload, make certain to terminate the Upload mode.

**Note:** *If the CCM detects an error in the file, it will respond with the "Invalid Parameter" message. If an error message is received, carefully check the contents of the parameters file, correct the problem, and then repeat the Upload procedure.*

5. If the parameter upload is successful, the CCM will send a confirmation message, and then return to the command prompt. Type `/s` and press **[Enter]**, the Status Screen will be displayed. Check the Status Screen to make certain the unit has been configured with the saved parameters.

### 15.3. Restoring Previously Saved Parameters

If you make a mistake while configuring the CCM unit, and wish to return to the previously saved parameters, the Text Interface's "Reboot System" command (/I) offers the option to reinitialize the CCM unit using previously backed up parameters. This allows you to reset the unit to previously saved parameters, even after you have changed parameters and saved them.

**Notes:**

- *The CCM will automatically backup saved parameters once a day, shortly after Midnight. This configuration backup file will contain only the most recently saved CCM parameters, and will be overwritten by the next night's daily backup.*
- *When the /I command is invoked, a submenu will be displayed which offers several Reboot options. Options 5 is used to restore the configuration backup file. The date shown next to options 5 indicates the date that you last changed and saved unit parameters.*
- *If the daily automatic configuration backup has been triggered since the configuration error was made, and the previously saved configuration has been overwritten by newer, incorrect parameters, then this function will not be able to restore the previously saved (correct) parameters.*

To restore the previously saved configuration, proceed as follows:

1. Access command mode via the Text Interface, using a username/password that permits access to Administrator level commands.
2. At the CCM command prompt, type /I and press **[Enter]**. The CCM will display a submenu that offers several different reboot options.
3. At the submenu, you may choose Item 5 (Reboot & Restore Last Known Working Configuration.) Type 5 and press **[Enter]**.

**Note:** *When invoking the /I command to restore configuration parameters, Item 5 is recommended.*

4. The CCM will reboot and previously saved parameters will be restored.

## 16. Upgrading CCM Firmware

When new, improved versions of the CCM firmware become available, either the Firmware Upgrade Utility (recommended) or the "Upgrade Firmware" function (Text Interface only) can be used to update the unit. The following Section describes the procedure for updating the CCM unit using the Firmware Upgrade Utility or the Upgrade Firmware function.

### 16.1. WMU Enterprise Management Software (Recommended)

The preferred method for updating CCM units is via the WMU Enterprise Management Software that is included with the unit. The WMU software allows you to manage firmware updates for multiple WTI units from a single interface. For a description of the process for managing firmware updates via the WMU, please refer to the WMU user's guide, which can be downloaded from the WTI User's Guide Archive at:

<http://www.wti.com/t-product-manuals.aspx>

Note that in order to use the WMU software, the firmware version for the CCM must be at least v1.48 or higher. When upgrading older CCM units that feature pre v1.48 firmware, it is recommended to use the WTI Firmware Upgrade Utility. A zip file that contains the installation files and other documentation for the WTI Firmware Upgrade Utility can be downloaded from WTI's FTP server, located at:

[ftp://wtiftp.wti.com/pub/TechSupport/Firmware/Upgrade\\_UTILITY/](ftp://wtiftp.wti.com/pub/TechSupport/Firmware/Upgrade_UTILITY/)

Please refer to the documentation included in the zip file for further instructions.

### 16.2. The Upgrade Firmware Function (Alternate Method)

The Upgrade Firmware function provides an alternative method for updating the CCM firmware. Updates can be uploaded via FTP or SFTP protocols.

#### **Notes:**

- *The FTP/SFTP servers can only be started via the Text Interface.*
  - *All other ports will remain active during the firmware upgrade procedure.*
  - *If the upgrade includes new parameters or features not included in the previous firmware version, these new parameters will be set to their default values.*
  - *The upgrade procedure will require approximately 15 minutes.*
1. Obtain the update file. Firmware modifications can either be mailed to the customer, or downloaded from WTI. Place the upgrade CDR in your disk drive or copy the file to your hard drive.
  2. Access Text Interface command mode via Serial Port, Telnet or SSH client session, using a username/password and port that permit Administrator level commands.

3. When the command prompt appears, type `/uF` and then press **[Enter]**. The CCM will display a screen which offers the following options:
  - a) **Start FTP/SFTP Servers Only (Do NOT default parameters):** To proceed with the upgrade, while retaining user-defined parameters, type 1 and press **[Enter]**. All existing parameter settings will be restored when the upgrade is complete.
  - b) **Start FTP/SFTP Servers & Default (Keep IP parameters & SSH Keys):** To proceed with the upgrade and default all user-defined parameters except for the IP Parameters and SSH Keys, type 2 and press **[Enter]**. When the upgrade is complete, all parameter settings except the IP Parameters and SSH Keys, will be reset to factory default values.
  - c) **Start FTP/SFTP Servers & Default (Default ALL parameters):** To proceed with the upgrade, and reset parameters to default settings, type 3 and press **[Enter]**. When the upgrade is complete, all parameters will be set to default values.
  - d) **Start FTP/SFTP Servers for Slip Stream Upgrade:** This option will upgrade only the WTI Management Utility, without updating the CCM's operating firmware. To update the WTI Management Utility only, type 4 and press **[Enter]**.

Note that after any of the above options is selected, the CCM will start the receiving servers and wait for an FTP/SFTP client to make a connection and upload a valid firmware binary image.

4. To proceed with the upgrade, select the desired option. The CCM will display a message that indicates that the unit is waiting for data. Leave the current Telnet/SSH client session connected at this time.
5. Open your FTP/SFTP application and (if you have not already done so,) login to the CCM unit, using a username and password that permit access to Administrator level commands.
6. Transfer the md5 format upgrade file to the CCM.
7. After the file transfer is complete, the CCM will install the upgrade file and then reboot itself and break all port connections. Note that it will take approximately 10 minutes to complete the installation process. The unit will remain accessible until it reboots.
  - a) Some FTP/SFTP applications may not automatically close when the file transfer is complete. If this is the case, you may close your FTP/SFTP client manually after it indicates that the file has been successfully transferred.
  - b) When the upgrade process is complete, the CCM will send a message to all currently connected network sessions, indicating that the CCM is going down for a reboot.

**Note:** Do not power down the CCM unit while it is in the process of installing the upgrade file. This can damage the unit's operating system.

8. If you have accessed the CCM via the Network Port, in order to start the FTP/SFTP servers, the CCM will break the network connection when the system is reinitialized.
  - If you initially selected "Start FTP/SFTP Servers and Save Parameters", you may then reestablish a connection with the CCM using your former IP address.
  - If you initially selected "Start FTP/SFTP Servers and Default Parameters", you must then login using the CCM's default IP address (Default = 192.168.168.168) or access command mode via Serial Port 1 or 2 or via Modem.

When firmware upgrades are available, WTI will provide the necessary files. At that time, an updated Users Guide or addendum will also be available.

## 17. Command Reference Guide

### 17.1. Command Conventions

Most commands described in this section conform to the following conventions:

- **Text Interface:** Commands discussed in this section, can only be invoked via the Text Interface. These commands *cannot* be invoked via the Web Browser Interface.
- **Slash Character:** Most CCM Text Interface commands begin with the Slash Character (/).
- **Apply Command to All Plugs/Contacts:** When an asterisk is entered as the argument of the `/ON` (Switch Plugs On), `/OFF` (Switch Plugs Off) or `/BOOT` (Reboot Plugs) commands, the command will be applied to the Switched AC Plug plus all Switched Contacts. For example, to reboot the Switched Plug plus all Switched Contacts, type `/BOOT * [Enter]`.
- **Command Queues:** If a switching or reboot command is directed to a plug or contact that is already being switched or rebooted by a previous command, then the new command will be placed into a queue until the plug or contact is ready to receive additional commands.
- **"Busy" Plugs and Contacts:** If the "Status" column in the Plug Status Screen includes an asterisk, this means that the corresponding plug or contact is currently busy, and is in the process of completing a previously issued command. If a new command is issued to a busy plug or contact, then the new command will be placed into a queue to be executed later, when the plug or contact is ready to receive additional commands.
- **Plug or Contact Name Wild Card:** It is not always necessary to enter the entire plug or contact name. Plug or contact names can be abbreviated in command lines by entering the first character(s) of the name followed by an asterisk (\*). For example, a plug or contact named "SERVER" could be specified as "s\*". Note however, that this command would also be applied to any other plug or contact name that begins with an "S".
- **Suppress Command Confirmation Prompt:** When the `/ON` (Switch Plug/Contact On), `/OFF` (Switch Plug/Contact Off), `/BOOT` (Reboot Plug/Contact) or `/DPL` (Default All Plugs/Contacts) commands are invoked, the " , y" option can be included to override the Command Confirmation ("Sure?") prompt. For example, to reboot Contact C4 without displaying the Sure prompt, type `/BOOT c4 , y [Enter]`.
- **Enter Key:** Most commands are invoked by pressing `[Enter]`.
- **Configuration Menus:** To exit from a configuration menu, press `[Esc]`.

## 17.2. Command Summary

Function	Command Syntax	Command Access Level			
		Admin.	SuperUser	User	ViewOnly
<b>Display</b>					
Plug/Contact Status	/S [s] [Enter]	X <sup>1</sup>	X <sup>1</sup>	X <sup>1</sup>	X <sup>1</sup>
Port Diagnostics	/SD [Enter]	X <sup>1</sup>	X <sup>1</sup>	X <sup>1</sup>	X <sup>1</sup>
Port Parameters (Who)	/W [n] [Enter]	X <sup>2</sup>	X <sup>2</sup>	X <sup>2</sup>	X <sup>2</sup>
Plug Group Status	/SG [Enter]	X <sup>2</sup>	X <sup>2</sup>	X <sup>2</sup>	X <sup>2</sup>
Network Status	/SN [Enter]	X	X	X	X
Network Configuration Summary	/RN [Enter]	X	X	X	X
IP Alias Summary	/SA [Enter]	X	X	X <sup>1</sup>	X <sup>1</sup>
Alarm Status	/AS [Enter]	X			
Help Menu	/H [Enter]	X <sup>3</sup>	X <sup>3</sup>	X <sup>3</sup>	X <sup>3</sup>
Log Functions	/L [Enter]	X	X		
Current Metering	/M [Enter] <sup>4</sup>	X	X		
Site ID / Unit Information	/J [*] [Enter] <sup>5</sup>	X	X	X	X
<b>Control</b>					
Exit Command Mode	/X [Enter]	X	X	X	X
Boot Plug/Contact <i>n</i>	/BOOT <s>[, Y] [Enter] <sup>6</sup>	X	X	X	
Turn Plug/Contact <i>n</i> On	/ON <s>[, Y] [Enter] <sup>6</sup>	X	X	X	
Turn Plug/Contact <i>n</i> Off	/OFF <s>[, Y] [Enter] <sup>6</sup>	X	X	X	
Default All Plugs/Contacts	/DPL[, Y] [Enter] <sup>6</sup>	X	X	X	
Connect to SetUp Port	/C [n] [Enter]	X	X	X	
Disconnect from Port	/D [n] [Enter]	X	X	X	
Send Parameter File	/U [Enter]	X			
Send SSH Keys	/K <k> [Enter]	X			
Unlock Invalid Access	/UL [Enter]	X			
Outbound Telnet	/TELNET <ip> [port] [raw] [Enter]	X <sup>7</sup>	X <sup>7</sup>	X <sup>7</sup>	
Outbound SSH	/SSH <ip> -l <username> [Enter]	X <sup>7</sup>			
<b>Configuration</b>					
System Parameters	/F [Enter]	X	<sup>8</sup>		
Serial Port Parameters	/P [n] [Enter]	X	<sup>8</sup>		
Plug/Contact Parameters	/PL [Enter]	X	<sup>8</sup>		
Plug Group Parameters	/G [Enter]	X	<sup>8</sup>		
Network Configuration - IPv4	/N [Enter]	X	<sup>8</sup>		
Network Configuration - IPv6	/N6 [Enter]	X	<sup>8</sup>		
Reboot Options	/RB [Enter]	X	<sup>8</sup>		
Alarm Configuration	/AC [Enter]	X	<sup>8</sup>		
Reboot System	/I [Enter]	X	X		
Upgrade Firmware	/UF [Enter]	X			
Test Network Configuration	/TEST [Enter]	X			

- <sup>1</sup> In Administrator Mode and SuperUser Mode, all CCM plugs and contacts are displayed. In User Mode and ViewOnly Mode, the Plug Status Screen will only include the plugs and contacts allowed by your account.
- <sup>2</sup> In Administrator Mode, all Plug Groups are displayed. In SuperUser Mode, User Mode and ViewOnly Mode, the Plug Group Status Screen will only include the Plug Groups allowed by the account.
- <sup>3</sup> In Administrator Mode, the Help Menus will list all CCM commands. In the SuperUser Mode, User Mode and ViewOnly Mode, the Help Menus will only list the commands allowed by the access level.
- <sup>4</sup> Current and Metering functions are not available for the switched contacts.
- <sup>5</sup> If the optional asterisk (\*) argument is included in the command line, this command will also show model numbers, current ratings and software versions for the CCM unit.
- <sup>6</sup> The ", Y" argument can be included in the command line to suppress the command confirmation prompt.
- <sup>7</sup> In order to invoke this command, Outbound Telnet/SSH and Outbound Service Access must be enabled for your account.
- <sup>8</sup> In SuperUser Mode, configuration menus can be displayed, but parameters cannot be changed.

## 17.3. Command Set

This Section provides information on all Text Interface commands.

### 17.3.1. Display Commands

#### **/S** Display Plug Status Screen

Displays the Plug Status Screen, which lists the current On/Off state, plus the plug number, plug name, Boot/Sequence Delay value and Default On/Off value for the Switched Plug and all Switched Contacts. Note that the /S command line can also include arguments that display the On/Off status for an individual plug or contact, two or more specific plugs and/or contacts, or a range of several plugs and/or contacts:

- /s** Displays configuration details and On/Off status for the Switched Plug plus all Switched Contacts.
- /s s** Displays On/Off status for an individual plug/contact, where *s* is the name or number of the desired plug/contact.
- /s s+s** Displays status information for two or more plugs and/or contacts, where *s* is the number or name of the desired plugs or contacts. A plus sign (+) is entered between each plug/contact number or name.
- /s s:s** Displays status information for a range of plugs and/or contacts, where *s* is the number or name of the plug/contact at the beginning and end of the range of desired plugs and/or contacts. A colon (:) is entered between the two plug/contact numbers or names that mark the beginning of the range and the end of the range.

#### **Notes:**

- *In Administrator and SuperUser Mode, the Switched Plug and all Switched Contacts are displayed. In User Mode and ViewOnly Mode, the Plug Status Screen will only include plugs and/or contacts allowed by the account.*
- *The CCM will return a "0" to indicate that the plug or contact is Off, or a "1" to indicate that the plug or contact is On.*

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /s [Enter]

#### **/SD** Display Port Diagnostics

Provides detailed information regarding the status of each port. When this command is issued by a User level or View Only level account, the resulting screen will only display parameters for the ports allowed by the account. For more information, please refer to Section 8.9.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /sd [Enter]

**Response:** Displays Port Diagnostics Screen.



---

**/W Display Port Parameters (Who)**

---

Displays configuration information for an individual port, but does not allow parameters to be changed. User and ViewOnly accounts can only display parameters for their resident port.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /w [x] [Enter]

Where **x** is the number or name of the Setup Port. If the "x" argument is omitted, parameters for your resident port will be displayed.

---

**/SG Display Plug Group Status Screen**

---

Displays the Plug Group Status Screen, which lists the available Plug Groups, the numbers of the plugs and/or contacts included in each Plug Group, the current On/Off state, the user-defined Boot/Sequence Delay value, and the Default On/Off value for each plug or contact.

**Notes:**

- *In Administrator Mode all user defined Plug Groups are displayed. In SuperUser Mode, User Mode and ViewOnly Mode, the Plug Group Status Screen will only include the Plug Groups allowed by your account.*
- *In order for this command to function, you must first define at least one Plug Group as described in Section 5.6.*

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /sg [Enter]

---

**/SN Display Network Status**

---

Displays the Network Status Screen, which lists network connections to the CCM's Network Port.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /sn [Enter]

---

**/RN Network Configuration Summary**

---

Displays a screen that lists currently selected communication settings, LDAP status, RADIUS status, Email Messaging status, NTP status and PPP status.

**Availability:** Administrator, SuperUser, User ViewOnly

**Format:** /rn [Enter]

---

**/SA IP Alias Status**

---

Displays the Alias Status Screen, which lists currently selected port name, alias IP address and Direct Connect status for the CCM's serial port. For more information, please refer to Section 8.10.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /sa [Enter]

**/H Help**

---

Displays a Help Screen, which lists all available Text Interface commands along with a brief description of each command.

**Note:** *In the Administrator Mode, the Help Screen will list the entire Text Interface command set. In SuperUser, User and ViewOnly Modes, the Help Screen will only list commands allowed by the account's access level.*

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /H [Enter]

**/L Log Functions**

---

Provides access to a menu which allows you to display the Audit Log, Alarm Log Current Metering Log and Power Metering Log.

**Note:** *Current and Power Metering functions are not available for the Switched Contacts. Current and Power Metering functions are only available for the Switched AC Plug.*

**Availability:** Administrator, SuperUser

**Format:** /L [Enter]

**/M Current Metering Status (Switched Plug Only)**

---

Displays the Current Metering Status Screen, which lists current, voltage and power readings for the Switched AC Plug, and also lists the trigger settings for the Over Temperature Alarm and the Over Current Alarm.

**Note:** *Current and Power Metering functions are not available for the Switched Contacts. Current and Power Metering functions are only available for the Switched AC Plug.*

**Availability:** Administrator, SuperUser

**Format:** /M [Enter]

---

**/AS Alarm Status Screen**

---

Lists all available user-defined alarms and indicates whether or not each alarm has been triggered as described in Section 8. The resulting screen will display "Yes" (or 1) for alarms that have been triggered or "No" (or 0) for alarms that have not been triggered. If desired, the /AS command line can also include an optional alarm argument that will cause the unit to display the status of one individual alarm as shown in the table below:

Alarm Name	Alarm Argument
Over Current (Initial)	OCI
Over Current (Critical)	OCC
Over Temperature (Initial)	OTI
Over Temperature (Critical)	OTC
Open Circuit Breaker	CBO
Ping No Answer	PNA
Serial Port Invalid Access Lockout	LO
Power Cycle (Cold Boot)	CB
No Dialtone	ND
Emergency Shutoff	ES

**Availability:** Administrator

**Format:** /AS [**a**larm] [Enter]

Where **a**larm is an optional argument, which can be used to display the status of an individual alarm as shown in the table above.

---

**/J Display Site ID / Unit Information**

---

Displays the user-defined Site I.D. message. If the optional asterisk (\*) argument is included in the command line, the command will also show model numbers, serial number, current ratings, and software versions for the CCM unit.

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /J [\*] [Enter]

Where \* (asterisk) is an optional command argument, that is used to display the model number, current rating and software version for the CCM unit.

**17.3.2. Control Commands**

---

**/X Exit Command Mode**

---

Exits command mode. When issued at the Network Port, also ends the Telnet session.

**Note:** *If the /X command is invoked from within a configuration menu, recently defined parameters may not be saved. In order to make certain that parameters are saved, always press the [Esc] key to exit from all configuration menus and then wait until "Saving Configuration" message has been displayed and the cursor has returned to the command prompt before issuing the /X command.*

**Availability:** Administrator, SuperUser, User, ViewOnly

**Format:** /x [Enter]

---

**/C Connect to Serial Port**

---

The /C command can be used to create a connection between the Network port and the SetUp Port.

**Notes:**

- *User level accounts can only connect to the SetUp Port when serial port access is specifically permitted by the account.*
- *To terminate a port connection, either type ^x ([Ctrl] plus [X]) or invoke the currently defined disconnect sequence.*

**Availability:** Administrator, SuperUser, User

**Format:** /C 1 [Enter]

---

**/BOOT Initiate Boot Cycle**

---

Initiates a boot cycle at the selected plug, contact(s) or Plug Group(s). When a Boot cycle is performed, the CCM will first switch the selected plug or contact(s) Off, then pause for the user-defined Boot/Sequence Delay Period, then switch the plug or contacts(s) back on. The /BOOT command can also be entered as /BO.

**Note:** *When this command is invoked in Administrator Mode or SuperUser Mode, it can be applied to all CCM plugs, contacts and Plug Groups. When this command is invoked in User Mode, it can only be applied to the plug, contact and/or Plug Groups that have been enabled for the account.*

**Availability:** Administrator, SuperUser, User

**Format:** /BOOT <s>[,Y] [Enter] or /BO <s> [Enter]

Where:

- s** The number or name of the plug, contact(s) or Plug Group(s) that you intend to reboot. To apply the command to the Switched Plug and/or several Switched Contacts, enter a plus sign (+) between each plug/contact number. To apply the command to a range of plug/contacts, enter the numbers for the first and last plug/contact in the range, separated by a colon character (:). To apply the command to the Switched Plug and all Switched Contacts allowed by your account, enter an asterisk character (\*).
- ,Y** (Optional) Suppresses the command confirmation prompt.

**Example:**

Assume that your account allows access to Plug A1 and Contact C3. To initiate a boot cycle at Plugs A1 and Contact C3, without displaying the optional command confirmation prompt, invoke either of the following command lines:

/BOOT A1+C3,Y [Enter] or /BO A1+C3,Y [Enter]

---

**/ON Switch Plug(s) ON**

---

Switches selected plug, contact(s) or Plug Group(s) On. When the /ON command is used to switch more than one plug or contact Boot/Sequence Delay Period will be applied.

**Note:** *When this command is invoked in Administrator Mode or SuperUser Mode, it can be applied to the Switched Plug plus all Switched Contacts and Plug Groups. When invoked in User Mode, the /ON command can only be applied to the plug, contacts and/or Plug Groups that are allowed by the account.*

Availability: Administrator, SuperUser, User

**Format:** /ON <s>[ ,y] [Enter]

Where:

- s The number or name of the plug, contact(s) or Plug Group(s) that you intend to Switch On. To apply the command to several plugs/contacts, enter a plus sign (+) between each plug/contact number. To apply the command to a range of plugs/contacts, enter the numbers for the first and last plug/contact in the range, separated by a colon character (:). To apply the command to all plugs/contacts allowed by your account, enter an asterisk character (\*).
- ,y (Optional) Suppresses the command confirmation prompt.

**Example:**

Assume that your account allows access to Plug A1 and Contact C3. To switch Plug A1 and Contact C3 On, without displaying the optional command confirmation prompt, invoke following command line:

/ON A1+C3,y [Enter]

---

**/OFF Switch Plug(s) OFF**

---

Switches the selected Switched Plug, Switched Contact(s) or Plug Group(s) Off. When the /OFF command is used to switch more than one plug/contact, the Boot/Sequence Delay Period will be applied. The /OFF command can also be entered as /OF.

**Note:** *When this command is invoked in Administrator Mode or SuperUser Mode, it can be applied to the Switched Plug, plus all Switched Contacts and Plug Groups. When invoked in User Mode, the /OFF command can only be applied to the Switched Plug, Switched Contacts and/or Plug Groups that are allowed by the account.*

**Availability:** Administrator, SuperUser, User

**Format:** /OFF <s>[ ,Y] [Enter] or /OF <s>[ ,Y] [Enter]

Where:

- s The number or name of the plug, contact(s) or Plug Group(s) that you intend to Switch Off. To apply the command to several plugs/contacts, enter a plus sign (+) between each plug/contact number. To apply the command to a range of plugs/contacts, enter the numbers for the first and last plug/contact in the range, separated by a colon character (:). To apply the command to all plugs/contacts allowed by your account, enter an asterisk character (\*).
- ,Y (Optional) Suppresses the command confirmation prompt.

**Example:**

Assume that your account allows access to Switched Plug A1 and Switched Contact C3. To switch Plug A1 and Contact C3 Off, without displaying the optional command confirmation prompt, invoke either of the following command lines:

/OFF A1+C3,Y [Enter] or /OF A1+C3,Y [Enter]

---

**/DPL Set All Plugs to Default States**

---

Sets the Switched Plug plus all Switched contacts to their user-defined default state.

**Note:** *When this command is invoked in Administrator Mode or SuperUser Mode, it will be applied to the Switched Plug and all Switched Contacts. When invoked in User Mode, the /DPL command will only be applied to the Switched Plug and/or Switched Contacts that are allowed by the account.*

**Availability:** Administrator, SuperUser, User

**Format:** /DPL[ ,Y] [Enter]

Where ,Y is an optional command argument, which can be included to suppress the command confirmation prompt.

**/U Send Parameters to File**

---

Sends all CCM configuration parameters to an ASCII text file. This allows you to back up the configuration of your CCM unit.

**Availability:** Administrator

**Format:** /U [Enter]

**/K Send SSH Key**

---

Instructs the CCM to provide you with a public SSH key for validation purposes. This public key can then be provided to your SSH client, in order to prevent the SSH client from warning you that the user is not recognized when you attempt to create an SSH connection.

**Availability:** Administrator

**Format:** /K k [Enter]

Where k is a required argument, which indicates the key type. The k argument provides the following options: 1 (SSH1), 2 (SSH2 RSA), 3 (SSH2 DSA.)

**/UL Unlock Port (Invalid Access Lockout)**

---

Manually cancels the CCM's Invalid Access Lockout feature. Normally, when a series of failed login attempts are detected, the Invalid Access Lockout feature can shut down the network port for a user specified time period in order to prevent further access attempts. When the /UL command is invoked, the CCM will immediately unlock all network ports that are currently in the locked state.

**Availability:** Administrator

**Format:** /UL [Enter]

**Response:** The CCM will unlock all CCM RS232 Ports.

---

**/TELNET Outbound Telnet**

---

Creates an outbound Telnet connection.

**Notes:**

- *In order for the /TELNET command to function, Telnet/SSH and Outbound Service Access must be enabled for your user account as described in Section 5.5. In addition, Telnet Access and Outbound Access must also be enabled via the Network Parameters menu, as described in Section 5.9.2.*
- *If you have logged in via the Network Port, the /TELNET command will not function.*

**Availability:** Administrator, SuperUser, User

**Format:** /TELNET <ip> [port] [raw] [Enter]

Where:

- ip** Is the target IP address. The IP Address can be entered in either IPv4 or IPv6 format.
- port** Is an optional argument which can be included to indicate the target port at the IP address.
- raw** Is an optional argument which can be included to indicate a raw socket connection. In order to create a raw socket connection, the command line must end with the text "raw".

---

**/SSH Outbound SSH**

---

Creates an outbound SSH connection.

**Notes:**

- *In order for the /SSH command to function, Telnet/SSH and Outbound Service Access must be enabled for your user account as described in Section 5.5. In addition, SSH Access and Outbound Access must also be enabled via the Network Parameters menu, as described in Section 5.9.2.*
- *If you have logged in via the Network Port, the /SSH command will not function.*

**Availability:** Administrator, SuperUser, User

**Format:** /SSH <ip> -l <username> [Enter]

Where:

- ip** Is the target IP address. The IP Address can be entered in either IPv4 or IPv6 format.
- l** (Lowercase letter "l") Indicates that the next argument will be the log on name.
- username** Is the username that you wish to use to log in to the target device.



### 17.3.3. Configuration Commands

#### **/F      Set System Parameters**

---

Displays a menu which is used to define the Site ID message, create user accounts, set the system clock and define other System Parameters. Note that all functions provided by the /F command are also available via the Web Browser Interface.

**Availability:** Administrator

**Format:** /F [Enter]

#### **/P      Set Serial Port Parameters**

---

Displays a menu that is used to select options and parameters for the CCM's serial Setup Port. Note that all functions provided by the /P command are also available via the Web Browser Interface.

**Availability:** Administrator

**Format:** /P [Enter]

#### **/PL     Set Plug/Contact Parameters**

---

Displays a menu that is used to select options and parameters for the CCM's Switched Plug and Switched Contacts. Note that all functions provided by the /PL command are also available via the Web Browser Interface.

**Availability:** Administrator

**Format:** /PL [Enter]

#### **/G      Plug Group Parameters**

---

Displays a menu that is used to View, Add, Modify or Delete Plug Groups.

**Availability:** Administrator

**Format:** /G [Enter]

---

**/N Network Port Parameters**

---

Displays a menu which is used to select parameters for the Network Port. Also allows access to the IP Security function, which can restrict network access by unauthorized IP addresses. Note that all of the functions provided by the /N command are also available via the Web Browser Interface.

**Availability:** Administrator

**Format:** /N [Enter]

---

**/N6 Network Port Parameters - IPv6**

---

Displays a menu used to select IPv6 protocol parameters for the Network Port. All functions provided by the /N6 command are also available via the Web Browser Interface. For more information, please refer to Section 5.9.

**Availability:** Administrator

**Format:** /N6 [Enter]

---

**/RB Reboot Options**

---

Displays a menu that is used to configure Scheduled Reboots and Ping-No-Answer Reboots. Scheduled Reboots allow the Switched Plug and Switched Contacts to be rebooted on a regular basis, according to a user defined schedule. Ping-No-Answer Reboots allow the CCM to automatically reboot user-designated plugs or contacts when a user-specified IP address does not respond to a Ping command.

**Note:** *If desired, the Ping-No-Answer Reboot function can also be configured to send email notification whenever a Ping-No-Answer Reboot is generated.*

**Availability:** Administrator

**Format:** /RB [Enter]

---

**/AC Alarm Configuration Parameters**

---

Displays a menu that is used to configure and enable the Over Current Alarms, Over Temperature Alarms and other user-defined alarms. When properly configured, the Over Current Alarms (Switched Plug Only) and Over Temperature Alarms offer the option of "Load Shedding", which allows the unit to automatically switch Off user-specified plugs and/or contacts when temperature or current readings exceed user-defined values.

**Note:** *Current and Power Metering functions are not available on the switched contacts. Current and Power Metering functions are only available to the Switched Plug.*

**Availability:** Administrator

**Format:** /AC [Enter]

**/I Reboot System (Default)**

---

Reinitializes the CCM unit and offers the option to keep user-defined parameters or reset to default parameters. As described in Section 5.10.1, the /I command can also be used to restore the unit to previously saved parameters. When the /I command is invoked, the unit will offer the following reboot options:

- Unit to Reboot
- Reboot Only (Do NOT default parameters)
- Reboot & Default (Keep IP Parameters & SSH Keys)
- Reboot & Default (Default ALL parameters)
- Reboot & Restore Last Known Working Configuration

**Availability:** Administrator, SuperUser

**Format:** /I [Enter]

**/UF Upgrade Firmware**

---

When new versions of the CCM firmware become available, this command is used to update existing firmware.

**Note:** *When a firmware upgrade is performed, it will take about 15 minutes to upgrade the CCM unit.*

**Availability:** Administrator

**Format:** /UF [Enter]

**/TEST Test Network Parameters**

---

Displays a menu which is used to test configuration of the Syslog and SNMP Trap functions and can also be used to invoke a Ping Command.

**Notes:**

- *In order for the ping command to function with domain names, Domain Name Server parameters must be defined.*
- *The Test Menu's Ping command is not effected by the status of the Network Parameters Menu's Ping Access function.*

**Availability:** Administrator

**Format:** /TEST [Enter]

## Appendix A. Specifications

**Ethernet Port:** 10/100Base-T, RJ45

**Serial SetUp Port:** (1) RJ45, RS232C

**Power:**

**Voltage:** 100 - 240 VAC, 50/60 Hz

**Power Output:** AC 1.2/2.8 kW / DC .4 kW

**Switched AC Outlet:** (1) IEC-60320-C13

**Switched Dry Contacts:** (4) Contact Relay Controllers (NC, COM, NO)

**Switched Dry Contact Power:** 100 to 240 Volts at 15 Amps AC;  
0 to 48 volts at 10 Amps DC

**Power Inlet:** (1) IEC-60320-C14

**Input Feed:** (1) 15 Amps

**Current:** 15 Amps

**Power Input Cables:** 120V: DPC-13-515P-6F (C13 to NEMA 5-15P) 6 Feet,  
240V: (varies)

**Physical/Environmental:**

**Size:**

Width: 8.25" (21 cm)

Depth: 5.85" (14.9 cm)

Height: 1.75" (4.5 cm) One Rack U

**Weight:** 4 Lbs. (1.8 Kg) Shipping Weight

**Operating Temperature:** 32°F to 122°F (0°C to 50°C)

**Humidity:** 10 - 90% RH

**Mounting:** Wall Mount Brackets Included

## Appendix B. Interface Descriptions




Figure B.1: RS232 SetUp Port Interface

### B.1. SetUp Port (RS232)

DCD and DTR hardware lines function as follows:

1. **When connected:**

- If either port is set for Modem Mode, the DTR output at either port reflects the DCD input at the other end.
- If *neither* port is set for Modem Mode, DTR output is held high (active).

2. **When not connected:**

- If the port is set for Modem Mode, upon disconnect DTR output is pulsed for 0.5 seconds and then held high.
- If the port is *not* set for Modem Mode, DTR output is controlled by the DTR Output option (Serial Port Parameters Menu, Option 23). Upon disconnect, Option 23 allows DTR output to be held low, held high, or pulsed for 0.5 seconds and then held high.

## Appendix C. Customer Service

Customer Service hours are from 8:00 AM to 5:00 PM, PST, Monday through Friday. When calling, please be prepared to give the name and make of the unit, its serial number and a description of its symptoms. If the unit should need to be returned for factory repair it must be accompanied by a Return Authorization number from Customer Service.

WTI Customer Service  
5 Sterling  
Irvine, California 92618

Local Phone: (949) 586-9950  
Toll Free Service Line: 1-888-280-7227  
Service Fax: (949) 583-9514

Email: [service@wti.com](mailto:service@wti.com)

### **Trademark and Copyright Information**

---

WTI and Western Telematic are trademarks of Western Telematic Inc.. All other product names mentioned in this publication are trademarks or registered trademarks of their respective companies.

Information and descriptions contained herein are property of Western Telematic, Inc.. Such information and descriptions may not be copied, disseminated, or distributed without the express written consent of Western Telematic Inc..

© Copyright Western Telematic Inc., 2014.

August, 2014

Part Number: 14184, Revision: C

### **Trademarks and Copyrights Used in this Manual**

Hyperterminal is a registered trademark of the Microsoft Corporation. Portions copyright Hilgraeve, Inc.

ProComm is a trademark of Datastorm Technologies, Inc™.

Teraterm is a copyright of Ayera Technologies, Inc.

APC is a copyright of the American Power Conversion Corporation.

BlackBerry is a registered trademark of Research In Motion Limited.

JavaScript is a trademark of Sun Microsystems, Inc.

Telnet is a trademark of Telnet Communications, Inc.

All other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.